

ALTERNATOR, 51A
CIRCUIT BREAKER
20 AMP
SPARK PLUGS
OIL PRESSURE SWITCH
CHOKE
OIL PRESSURE SENDER
OPTIONAL
LIFT PUMP
DISTRIBUTOR
WATER TEMP. SENDER
OPTIONAL
BATTERY SWITCH
STARTER
12 VDC
GROUND TO BLOCK
EXHAUST TEMP. SWITCH
WATER TEMP. SWITCH
STOP SWITCH
FUSE 2 15 AMP S.B.
HOUR METER
START SWITCH
FUSE 1 8 AMP
ON SWITCH
TB3
TB2
TB1
FOR CONNECTIONS TO REMOTE START AND REMOTE INSTRUMENT PANELS, SEE DRAWINGS #35706 & #35698.
REMOVE JUMPER BETWEEN TB1-1 AND TB1-2 WHEN USING REMOTE PANEL.
OVERSPEED CIRCUIT
ALTERNATOR, 35 AMP
PRESTOLITE 51 AMP ALT.
12 VDC
BATTERY SWITCH
STARTER SOLENOID
STARTER
ALTERNATOR
20 AMP CIRCUIT BREAKER
STOP SWITCH
OIL PRESS. SWITCH
WATER TEMP SWITCH
EXHAUST TEMP SWITCH
F2 15 AMP
F1 8 AMP
OIL PRESSURE SENDER (OPTIONAL)
WATER TEMP SENDER (OPTIONAL)
HOURMETER
CARBURETOR CHOKE
FUEL PUMP
COIL
DISTRIBUTOR
OVERSPEED SWITCH
100MFD/35V
K2-RUN
K1-START
ON SWITCH
START SWITCH
REMOTE PANEL CONNECTIONS
REMOVE JUMPER BETWEEN TB1-1 AND TB1-2 WHEN USING REMOTE PANEL.
OVERSPEED SWITCH
(ORIGINAL OVERSPEED SWITCH CONNECTIONS)
TO DISTRIBUTOR
TO TB3-1
TO COIL -
TO TB2-5
WESTERBEKE CORPORATION
AVON MA. 02322
WIRING DIAGRAM, 8.5, 12.5, AND 15.0 KW BTG GASOLINE GENSETS
E
44628