

# PARTS LIST

## WESTERBEKE

**5.0 BCD/5.0 BCDA/5.0 BCDB - 60 Hz**  
**4.0 BCD/4.0 BCDA/4.0 BCDB - 50 Hz**

### Marine Diesel Generators

Publication # 038677

Edition Two

July 1999



## **IMPORTANT**

### **PRODUCT SOFTWARE DISCLAIMER**

Product software of all kinds such as brochures, drawings, technical data, operator's and workshop manuals, parts lists and parts price lists, and other information, instructions and specifications provided from sources other than Westerbeke, is not within Westerbeke's control and, accordingly, is provided to Westerbeke customers only as a courtesy and service. **Westerbeke cannot be responsible for the content of such software, makes no warranties or representations with respect thereto, including the accuracy, timeliness or completeness thereof, and will in no event be liable for any type of damages or injury incurred in connection with, or arising out of, the furnishing or use of such software.**

For example, components and subassemblies incorporated in Westerbeke's products and supplied by others (such as engine blocks, fuel systems and components, transmissions, electrical components, pumps and other products) are generally supported by their manufacturers with their own software, and Westerbeke must depend on such software for the design of Westerbeke's own product software. Such software may be outdated and no longer accurate. Routine changes made by Westerbeke's suppliers, of which Westerbeke rarely has notice in advance, are frequently not reflected in the supplier's software until after such changes take place.

Westerbeke customers should also keep in mind the time span between printings of Westerbeke product software, and the unavoidable existence of earlier, non-current Westerbeke software editions in the field. Additionally, most Westerbeke products include customer-requested special features that frequently do not include complete documentation.


In summation, product software provided with Westerbeke products, whether from Westerbeke or other suppliers, must not and cannot be relied upon exclusively as the definitive authority on the respective product. It not only makes good sense but is imperative that appropriate representatives of Westerbeke or the supplier in question be consulted to determine the accuracy and currency of the product software being consulted by the customer.

| 60 Hertz Generator | 50 Hertz Generator |
|--------------------|--------------------|
| 5.0 BCD            | 4.0 BCD            |
| 5.0 BDCA           | 4.0 BCDA           |
| 5.0 BCDB           | 4.0 BCDB           |

## TABLE OF CONTENTS

| PAGE | DESCRIPTION                                      |
|------|--|
| 100  | CYLINDER BLOCK                                   |
| 104  | CYLINDER HEAD - VALVES - ROCKER SHAFT - SILENCER |
| 106  | CRANKSHAFT - PISTONS                             |
| 108  | CAMSHAFT - TIMING SYSTEM                         |
| 112  | COOLING SYSTEM - EXHAUST MANIFOLD                |
| 116  | SEA WATER PUMP                                   |
| 118  | GOVERNOR SYSTEM                                  |
| 120  | FUEL SYSTEM                                      |
| 124  | ELECTRICAL SYSTEM                                |
| 126  | BACK END - GENERATOR - MOUNTING SYSTEM           |
| 130  | GENERATOR AC OUTPUT                              |
| 132  | AC OUTPUT CIRCUIT BREAKER                        |
| 134  | CONTROL PANEL                                    |
| 138  | SEA RAY CONTROL PANEL                            |
| 140  | BELT - IDLER PULLEY - BELT GUARD                 |
| 142  | SOUND GUARD                                      |
| 144  | MISCELLANEOUS                                    |


# WESTERBEKE 5.0 BCD GENERATOR - CYLINDER BLOCK



WESTERBEKE 5.0 BCD GENERATOR - CYLINDER BLOCK

| REF  | PN     | NAME       | REMARKS                              | QUAN |
|------|--------|------------|--------------------------------------|------|
| 1-1  | 038499 | BLOCK      | ASSEMBLY INCLUDING HEAD 5.0 BCD NLA  | 1    |
| 1-2  | 038499 | BLOCK      | ASSEMBLY INCLUDING HEAD 5.0 BCDA NLA | 1    |
| 1-3  | 042400 | BLOCK      | ASSEMBLY INCLUDING HEAD 5.0 BCDB     | 1    |
| 2    | 024373 | PLUG       | EXPANSION-CUP 25 MM                  | 2    |
| 3    | 033212 | DOWEL      | TUBULAR 6 X 9                        | 2    |
| 4    | 030708 | DOWEL      | TUBULAR 10 X 9                       | 3    |
| 5    | 036963 | GASKET     | OIL SEAL FLANGE                      | 1    |
| 6    | 036917 | SEAL       | OIL                                  | 1    |
| 7    | 036945 | FLANGE     | OIL SEAL                             | 1    |
| 8    | 018804 | CAPSCREW   | M 6 X 20 DIN 933                     | 6    |
| 9    | 036940 | PLUG       | EXPANSION 35 MM DIN 470              | 1    |
| 10   | 030712 | PLUG       | 1/4 BSPT DIN 906                     | 1    |
| 11   | 033657 | PLUG       | EXPANSION-CUP 40 MM                  | 3    |
| 12   | 030272 | DOWEL      |                                      | 1    |
| 13   | 016789 | CAPSCREW   | M 8 X 16 DIN 933                     | 2    |
| 15   | 038679 | COVER      |                                      | 1    |
| 17   | 036987 | GASKET     | COVER TO BLOCK                       | 1    |
| 18   | 030712 | PLUG       | 1/4 BSPT DIN 906                     | 1    |
| 19   | 037073 | TUBE       | DIPSTICK                             | 1    |
| 20   | 037072 | DIPSTICK   |                                      | 1    |
| 21   | 036943 | DOWEL      |                                      | 2    |
| 22   | 030239 | PLUG       | 1/16                                 | 3    |
| 23   | 030214 | NIPPLE     | OIL FILTER                           | 1    |
| 24   | 036918 | FILTER     | LUBE OIL                             | 1    |
| 25-1 | 031810 | CAPSCREW   | M 6 X 14 DIN 933                     | 4    |
| 25-2 | 031783 | LOCKWASHER | M 6 DIN 127                          | 4    |
| 26   | 037045 | COVER      | TIE ROD                              | 1    |
| 27   | 036981 | GASKET     | TIE ROD COVER                        | 1    |
| 28-1 | 031810 | CAPSCREW   | M 6 X 14 DIN 933                     | 7    |
| 28-2 | 031783 | LOCKWASHER | M 6 DIN 127                          | 7    |
| 29   | 036997 | PLATE      | FRONT                                | 1    |
| 30   | 037004 | GASKET     | FRONT PLATE                          | 1    |
| 31   | 030707 | DOWEL      | TUBULAR 8 X 13                       | 2    |
| 32   | 037005 | SHAFT      | IDLER                                | 1    |
| 33   | 037114 | DOWEL      | TUBULAR 6 X 13                       | 1    |
| 34-1 | 037018 | BEARING    | SET MAIN STD                         | 1    |
| 34-2 | 037062 | BEARING    | SET MAIN 0.25 MM                     | 1    |
| 34-3 | 037063 | BEARING    | SET MAIN 0.50 MM                     | 1    |
| 35   | 036962 | SEAL       | SIDE MAIN BEARING CAP                | 4    |


WESTERBEKE 5.0 BCD GENERATOR - CYLINDER BLOCK



WESTERBEKE 5.0 BCD GENERATOR - CYLINDER BLOCK

| REF  | PN     | NAME       | REMARKS                  | QUAN |
|------|--------|------------|--------------------------|------|
| 36   | 037068 | STRAINER   | OIL PICKUP INCLUDING NUT | 1    |
| 37   | 031809 | NUT        | M14 X 1.5 JAM            | 1    |
| 38   | 036916 | BOLT       | MAIN BEARING CAP         | 8    |
| 39   | 036988 | GASKET     | LUBE OIL SUMP            | 1    |
| 40   | 037095 | SUMP       | LUBE OIL                 | 1    |
| 41-1 | 031825 | CAPSCREW   | M 6 X 12 DIN 933         | 18   |
| 41-2 | 031783 | LOCKWASHER | M 6 DIN 127              | 18   |
| 42   | 036493 | WASHER     | SUMP DRAIN BANJO         | 2    |
| 43   | 037393 | SEAL       | LEAD WIRE                | 1    |
| 44   | 036819 | BOLT       | BANJO, SUMP DRAIN        | 1    |
| 45   | 030846 | HOSE       | SUMP DRAIN               | 1    |
| 46   | 024922 | BRACKET    | SUMP DRAIN HOSE          | 1    |
| 47   | 024905 | CAP        | SUMP DRAIN HOSE          | 1    |


# WESTERBEKE 5.0 BCD GENERATOR - CYLINDER HEAD - VALVES - ROCKER SHAFT



WESTERBEKE 5.0 BCD GENERATOR - CYLINDER HEAD - VALVES - ROCKER SHAFT

| REF  | PN     | NAME       | REMARKS                                | QUAN |
|------|--------|------------|--|------|
| 1    | 037056 | TAPPET     |  | 6    |
| 2-1  | 038448 | GASKET     | CYLINDER HEAD 5.0 BCD, 5.0 BCDA        | 1    |
| 2-2  | 043550 | GASKET     | CYLINDER HEAD 5.0 BCDB                 | 1    |
| 3    | 036958 | VALVE      | INTAKE                                 | 3    |
| 4    | 036959 | VALVE      | EXHAUST                                | 3    |
| 5-1  | 038454 | HEAD       | CYLINDER INCL GUIDES 5.0 BCD, 5.0 BCDA | 1    |
| 5-2  | 043559 | HEAD       | CYLINDER INCL GUIDES 5.0 BCDB          | 1    |
| 6    | 030711 | PLUG       | 1/8 BSPT DIN 906                       | 1    |
| 7    | 033657 | PLUG       | EXPANSION-CUP 40 MM                    | 1    |
| 8    | 024369 | PLUG       | EXPANSION-CUP 20 MM                    | 3    |
| 9    | 033134 | GUIDE      | VALVE                                  | 6    |
| 10   | 036954 | BOLT       | CYLINDER HEAD M10 X 83                 | 8    |
| 11   | 036919 | BOLT       | CYLINDER HEAD M 8 X 70                 | 3    |
| 12   | 037007 | GASKET     | ROCKER COVER                           | 1    |
| 13   | 037087 | COVER      | ROCKER                                 | 1    |
| 14   | 031784 | WASHER     | M 6 DIN 125                            | 2    |
| 15   | 036936 | NUT        | CAP M 6                                | 2    |
| 16-1 | 033126 | CAP        | OIL FILLER INCLUDING O-RING - SCREW IN | 1    |
| 16-2 | 041487 | CAP        | OIL FILLER - PUSH IN                   | 1    |
| 17   | 033123 | O-RING     | OIL FILLER CAP 33126                   | 1    |
| 18   | 030219 | NIPPLE     | BREATHER HOSE                          | 2    |
| 19   | 037046 | HOSE       | BREATHER                               | 1    |
| 20   | 037191 | SILENCER   | AIR INTAKE                             | 1    |
| 21   | 034620 | SCREEN     | AIR INTAKE SILENCER                    | 1    |
| 22-1 | 017012 | CAPSCREW   | M 6 X 16 DIN 933                       | 1    |
| 22-2 | 031783 | LOCKWASHER | M 6 DIN 127                            | 1    |
| 22-3 | 031784 | WASHER     | M 6 DIN 125                            | 1    |
| 23   | 037008 | MANIFOLD   | INTAKE                                 | 1    |
| 24   | 036980 | GASKET     | INTAKE MANIFOLD TO HEAD                | 1    |
| 25   | 018804 | CAPSCREW   | M 6 X 20 DIN 933                       | 2    |
| 26   | 034642 | CAPSCREW   | M 6 X 45 DIN 931                       | 2    |
| 27   | 037026 | PUSHROD    |  | 6    |
| 28   | 030242 | SEAL       | VALVE STEM                             | 6    |
| 29   | 036986 | SPRING     | VALVE                                  | 6    |
| 30   | 033149 | SEAT       | VALVE SPRING                           | 6    |
| 31   | 030241 | COLLET     | VALVE SPRING                           | 12   |
| 32   | 036979 | CAP        | VALVE STEM                             | 6    |
| 33   | 037029 | SCREW      | ROCKER ADJUSTING                       | 6    |
| 34   | 037027 | ROCKER     |  | 6    |
| 35   | 033124 | RING       | RETAINING                              | 2    |
| 36   | 031801 | NUT        | M 6 JAM                                | 6    |
| 37   | 037053 | BOLT       | ROCKER BRACKET                         | 2    |
| 38   | 031786 | LOCKWASHER | M 8 DIN 127                            | 3    |
| 39   | 031787 | WASHER     | M 8 DIN 125                            | 3    |
| 40   | 033152 | BRACKET    | ROCKER                                 | 3    |
| 41   | 033151 | SPRING     | ROCKER SHAFT                           | 2    |
| 42   | 036967 | SHAFT      | ROCKER                                 | 1    |
| 43   | 031225 | CAPSCREW   | M 8 X 60 DIN 931                       | 1    |
| 44   | 036960 | PIN        | GROOVED                                | 1    |
| 45   | 041250 | EYE        | FRONT LIFTING                          | 1    |


WESTERBEKE 5.0 BCD GENERATOR - CRANKSHAFT - PISTONS.



WESTERBEKE 5.0 BCD GENERATOR - CRANKSHAFT -- PISTONS

| REF | PN     | NAME       | REMARKS                                 | QUAN |
|-----|--------|------------|---|------|
| 1-1 | 038449 | RING SET   | PISTON STD 5.0 BCD, 5.0 BCDA            | 3    |
| 1-2 | 038451 | RING SET   | PISTON 0.25 MM 5.0 BCD, 5.0 BCDA        | 3    |
| 1-3 | 038452 | RING SET   | PISTON 0.50 MM 5.0 BCD, 5.0 BCDA        | 3    |
| 1-4 | 043551 | RING SET   | PISTON STD 5.0 BCDB                     | 3    |
| 1-5 | 043553 | RING SET   | PISTON 0.25 MM 5.0 BCDB                 | 3    |
| 1-6 | 043554 | RING SET   | PISTON 0.50 MM 5.0 BCDB                 | 3    |
| 2-1 | 038456 | PISTON     | INCLUDING PIN STD 5.0 BCD, 5.0 BCDA     | 3    |
| 2-2 | 040892 | PISTON     | INCLUDING PIN 0.25 MM 5.0 BCD, 5.0 BCDA | 3    |
| 2-3 | 040893 | PISTON     | INCLUDING PIN 0.50 MM 5.0 BCD, 5.0 BCDA | 3    |
| 2-4 | 043556 | PISTON     | INCLUDING PIN STD 5.0 BCDB              | 3    |
| 2-5 | 043557 | PISTON     | INCLUDING PIN 0.25 MM 5.0 BCDB          | 3    |
| 2-6 | 043558 | PISTON     | INCLUDING PIN 0.50 MM 5.0 BCDB          | 3    |
| 3-1 | 038447 | ROD        | CONNECTING INCL 4 & 6 5.0 BCD, 5.0 BCDA | 3    |
| 3-2 | 043976 | ROD        | CONNECTING INCL 4 & 6 5.0 BCDB          | 3    |
| 4   | 036914 | BOLT       | CONNECTING ROD                          | 6    |
| 5-1 | 037069 | BEARING    | SET CONNECTING ROD STD                  | 3    |
| 5-2 | 037066 | BEARING    | SET CONNECTING ROD 0.25 MM              | 3    |
| 5-3 | 037067 | BEARING    | SET CONNECTING ROD 0.50 MM              | 3    |
| 6   | 030231 | NUT        | CONNECTING ROD BOLT                     | 6    |
| 7   | 030274 | KEY        | WOODRUFF                                | 2    |
| 8   | 040926 | CRANKSHAFT |   | 1    |
| 9   | 036994 | GEAR       | CRANKSHAFT                              | 1    |
| 10  | 036993 | PULLEY     | CRANKSHAFT                              | 1    |
| 11  | 037167 | WASHER     | M16                                     | 1    |
| 12  | 037168 | LOCKWASHER | M16                                     | 1    |
| 13  | 033538 | NUT        | M16 JAM                                 | 1    |


WESTERBEKE 5.0 BCD GENERATOR - CAMSHAFT - TIMING SYSTEM



WESTERBEKE 5.0 BCD GENERATOR - CAMSHAFT - TIMING SYSTEM

| REF  | PN     | NAME       | REMARKS                     | QUAN |
|------|--------|------------|-----------------------------|------|
| 1    | 036949 | BEARING    | BALL                        | 1    |
| 2    | 037075 | CAMSHAFT   | INJECTION PUMP              | 1    |
| 3    | 030273 | KEY        |                             | 1    |
| 4    | 036948 | BEARING    | BALL                        | 1    |
| 5    | 036950 | BEARING    | BALL                        | 1    |
| 6    | 036970 | WASHER     | CAMSHAFT RETAINING          | 2    |
| 7-1  | 031825 | CAPSCREW   | M 6 X 12 DIN 933            | 2    |
| 7-2  | 031783 | LOCKWASHER | M 6 DIN 127                 | 2    |
| 8    | 037006 | GEAR       | INJECTION PUMP CAMSHAFT     | 1    |
| 9    | 036996 | GEAR       | SEA WATER PUMP DRIVE        | 1    |
| 10   | 036948 | BEARING    | BALL                        | 1    |
| 11   | 030280 | RING       | RETAINING                   | 1    |
| 12   | 036978 | SPACER     |                             | 1    |
| 13   | 037025 | GEAR       | IDLER                       | 1    |
| 14   | 036995 | GEAR       | CAMSHAFT                    | 1    |
| 15   | 036948 | BEARING    | BALL                        | 1    |
| 16   | 030274 | KEY        | WOODRUFF                    | 1    |
| 17   | 037017 | CAMSHAFT   |                             | 1    |
| 18   | 018242 | NUT        | M 8 DIN 934                 | 4    |
| 19   | 031786 | LOCKWASHER | M 8 DIN 127                 | 4    |
| 20   | 031787 | WASHER     | M 8 DIN 125                 | 4    |
| 21   | 031281 | STUD       | M 8 X 40 DIN 939            | 3    |
| 22   | 015828 | STUD       | M 8 X 22 DIN 939            | 1    |
| 23   | 033636 | PUMP       | SEA WATER                   | 1    |
| 24   | 030326 | GASKET     | SEA WATER PUMP MOUNTING     | 1    |
| 25-1 | 013630 | CAPSCREW   | M 8 X 25 DIN 933            | 1    |
| 25-2 | 031786 | LOCKWASHER | M 8 DIN 127                 | 1    |
| 26   | 036946 | HOUSING    | BEARING                     | 1    |
| 27   | 036982 | GASKET     | HOUSING                     | 1    |
| 28   | 037019 | GASKET     | GEAR CASE                   | 1    |
| 29   | 037086 | CASE       | GEAR                        | 1    |
| 30   | 033126 | CAP        | OIL FILLER INCLUDING O-RING | 1    |
| 31   | 033123 | O-RING     | OIL FILLER CAP              | 1    |
| 32   | 036968 | CAP        | SEALING                     | 1    |
| 33   | 013340 | ELBOW      | 1/8 NPT STREET              | 2    |
| 34   | 037323 | SWITCH     | OIL PRESSURE                | 1    |
| 35   | 037508 | ADAPTER    | 1/8 BSPT TO 1/8 NPT         | 1    |
| 36   | 034397 | CAPSCREW   | M 6 X 65 DIN 931            | 1    |


WESTERBEKE 5.0 BCD GENERATOR - CAMSHAFT - TIMING SYSTEM



WESTERBEKE 5.0 BCD GENERATOR - CAMSHAFT - TIMING SYSTEM

| REF  | PN     | NAME       | REMARKS               | QUAN |
|------|--------|------------|-----------------------|------|
| 37   | 030244 | PLUNGER    | OIL RELIEF VALVE      | 1    |
| 38   | 037030 | SPRING     | OIL RELIEF VALVE      | 1    |
| 39   | 030225 | GASKET     | OIL RELIEF VALVE PLUG | 1    |
| 40   | 030461 | PLUG       | OIL RELIEF VALVE      | 1    |
| 41   | 024132 | SENDER     | OIL PRESSURE          | 1    |
| 42   | 036915 | SEAL       | OIL                   | 1    |
| 43   | 030146 | CAPSCREW   | M 6 X 55 DIN 931      | 4    |
| 44   | 031824 | CAPSCREW   | M 6 X 35 DIN 933      | 3    |
| 45   | 030712 | PLUG       | 1/4 BSPT DIN 906      | 1    |
| 46-1 | 031810 | CAPSCREW   | M 6 X 14 DIN 933      | 4    |
| 46-2 | 031783 | LOCKWASHER | M 6 DIN 127           | 4    |
| 47   | 036938 | O-RING     |                       | 2    |
| 48   | 037050 | GEAR       | OIL PUMP INNER        | 1    |
| 49   | 037051 | GEAR       | OIL PUMP OUTER        | 1    |
| 50   | 037070 | HOUSING    | OIL PUMP              | 1    |
| 51-1 | 013590 | CAPSCREW   | M 6 X 30 DIN 933      | 3    |
| 51-2 | 031783 | LOCKWASHER | M 6 DIN 127           | 3    |
| 52   | 024844 | ADAPTER    | 1/8 BSPT TO 1/8 NPT   | 1    |


WESTERBEKE 5.0 BCD GENERATOR - COOLING SYSTEM



WESTERBEKE 5.0 BCD GENERATOR - COOLING SYSTEM

| REF  | PN     | NAME       | REMARKS                          | QUAN |
|------|--------|------------|----------------------------------|------|
| 1    | 036616 | ELBOW      | 1/2 NPT TO 1 HOSE                | 1    |
| 2    | 036425 | GASKET     | EXHAUST ELBOW TO MANIFOLD        | 1    |
| 3    | 036541 | CLAMP      | EXHAUST ELBOW TO MANIFOLD        | 1    |
| 4    | 038114 | ELBOW      | WATER INJECTED EXHAUST 45 DEGREE | 1    |
| 5    | 035411 | NAMEPLATE  |                                  | 1    |
| 6    | 031935 | SCREW      | 8-32 X 1/4 SS OVAL HEAD          | 2    |
| 7    | 037312 | MANIFOLD   | EXHAUST                          | 1    |
| 8    | 018242 | NUT        | M 8 DIN 934                      | 6    |
| 9    | 031786 | LOCKWASHER | M 8 DIN 127                      | 6    |
| 10   | 031787 | WASHER     | M 8 DIN 125                      | 6    |
| 11   | 036955 | GASKET     | MANIFOLD TO HEAD                 | 1    |
| 12   | 015830 | STUD       | M 8 X 25 DIN 939                 | 6    |
| 13   | 024907 | ELBOW      | COOLANT RECOVERY TANK CONNECTION | 1    |
| 14   | 024306 | CAP        | PRESSURE                         | 1    |
| 15   | 011405 | CLAMP      | HOSE 16                          | 2    |
| 16   | 038079 | HOSE       | MANIFOLD TO EXCHANGER            | 1    |
| 17   | 011405 | CLAMP      | HOSE 16                          | 2    |
| 18   | 037383 | HOSE       | THERMOSTAT TO MANIFOLD           | 1    |
| 19   | 031784 | WASHER     | M 6 DIN 125                      | 2    |
| 20   | 031783 | LOCKWASHER | M 6 DIN 127                      | 2    |
| 21   | 018804 | CAPSCREW   | M 6 X 20 DIN 933                 | 2    |
| 22   | 039550 | SWITCH     | WATER TEMPERATURE                | 1    |
| 23   | 036228 | HOUSING    | THERMOSTAT                       | 1    |
| 24   | 036956 | GASKET     | THERMOSTAT                       | 1    |
| 25   | 037043 | THERMOSTAT |                                  | 1    |
| 26   | 037162 | GASKET     | ADAPTER TO HOUSING               | 1    |
| 27   | 024602 | ADAPTER    | M16 X 1.5 TO 1/8 NPT             | 1    |
| 28   | 035109 | SENDER     | WATER TEMPERATURE                | 1    |
| 29   | 037016 | GASKET     | LOWER THERMOSTAT HOUSING         | 1    |
| 30   | 037057 | HOUSING    | LOWER THERMOSTAT                 | 1    |
| 31   | 018804 | CAPSCREW   | M 6 X 20 DIN 933                 | 2    |
| 32   | 033351 | CAPSCREW   | M 6 X 60 DIN 931                 | 1    |
| 33   | 036957 | GASKET     | FRESH WATER PUMP                 | 1    |
| 34   | 037015 | PUMP       | FRESH WATER                      | 1    |
| 35   | 018804 | CAPSCREW   | M 6 X 20 DIN 933                 | 2    |
| 36   | 030146 | CAPSCREW   | M 6 X 55 DIN 931                 | 2    |
| 37-1 | 031825 | CAPSCREW   | M 6 X 12 DIN 933                 | 4    |
| 37-2 | 031783 | LOCKWASHER | M 6 DIN 127                      | 4    |
| 38   | 034642 | CAPSCREW   | M 6 X 45 DIN 931                 | 1    |
| 39   | 030386 | PULLEY     | FRESH WATER PUMP                 | 1    |
| 40   | 031824 | CAPSCREW   | M 6 X 35 DIN 933                 | 1    |
| 41   | 034497 | SPACER     | EXCHANGER TO BLOCK               | 2    |
| 42   | 036622 | NIPPLE     | 3/4 NPT TO 1 HOSE                | 1    |
| 43   | 022851 | GASKET     | EXCHANGER END COVER              | 2    |
| 44   | 019321 | O-RING     |                                  | 2    |
| 45   | 022850 | COVER      | EXCHANGER END                    | 2    |
| 46   | 022852 | CAPSCREW   | 3/8NC X 3/4 BRASS                | 2    |
| 47   | 038147 | EXCHANGER  | HEAT                             | 1    |


# WESTERBEKE 5.0 BCD GENERATOR - COOLING SYSTEM



WESTERBEKE 5.0 BCD GENERATOR - COOLING SYSTEM

| REF  | PN     | NAME       | REMARKS                        | QUAN |
|------|--------|------------|--------------------------------|------|
| 48   | 031753 | WASHER     | FLAT 1/4                       | 2    |
| 49   | 031752 | LOCKWASHER | 1/4                            | 2    |
| 50   | 031506 | CAPSCREW   | 1/4NC X 1-1/4                  | 2    |
| 51   | 031789 | WASHER     | M10 DIN 125                    | 2    |
| 52   | 019262 | LOCKWASHER | M10 DIN 127                    | 2    |
| 53   | 041130 | CAPSCREW   | M10 X 1.25 X 45 JIS            | 2    |
| 54   | 019369 | PLUG       | 1/8 NPT BRASS                  | 2    |
| 55   | 011885 | ZINC       |                                | 1    |
| 56   | 011386 | CLAMP      | HOSE 12                        | 2    |
| 57   | 038080 | HOSE       | SEA WATER PUMP TO EXCHANGER    | 1    |
| 58   | 032947 | NIPPLE     | 3/8 NPT TO 7/8 HOSE            | 1    |
| 59   | 013337 | ELBOW      | 3/8 NPT STREET 45              | 1    |
| 60   | 033636 | PUMP       | SEA WATER                      | 1    |
| 61   | 038076 | ELBOW      | 3/8 NPT TO 1 HOSE              | 1    |
| 62   | 024977 | KIT        | COOLANT RECOVERY TANK          | 1    |
| 63   | 024906 | CLAMP      | HOSE                           | 2    |
| 64   | 024858 | CAP        | COOLANT RECOVERY TANK          | 1    |
| 65   | 024704 | TANK       | COOLANT RECOVERY               | 1    |
| 66   | 024786 | STRAP      | COOLANT RECOVERY TANK MOUNTING | 1    |
| 67   | 024637 | TUBING     | INCHES REQUIRED                | 60   |
| 68   | 011405 | CLAMP      | HOSE 16                        | 2    |
| 69   | 012292 | CLAMP      | SUPPORT HOSE                   | 1    |
| 70   | 038064 | HOSE       | EXCHANGER TO PUMP              | 1    |
| 71-1 | 031783 | LOCKWASHER | M 6 DIN 127                    | 1    |
| 71-2 | 031784 | WASHER     | M 6 DIN 125                    | 1    |
| 72   | 031825 | CAPSCREW   | M 6 X 12 DIN 933               | 1    |
| 73   | 036947 | TUBE       | THERMOSTAT BYPASS              | 1    |
| 74   | 036937 | O-RING     |                                | 2    |


WESTERBEKE 5.0 BCD GENERATOR - SEA WATER PUMP



WESTERBEKE 5.0 BCD GENERATOR - SEA WATER PUMP

| REF | PN     | NAME    | REMARKS                    | QUAN |
|-----|--------|---------|----------------------------|------|
| 1-1 | 033636 | PUMP    | COMPLETE                   | 1    |
| 1-2 | 034457 | HOUSING | PUMP BODY                  | 1    |
| 1-3 | 034466 | KIT     | MAJOR REPAIR               | 1    |
| 2   | 034464 | BEARING |                            | 2    |
| 3   | 033044 | RING    | RETAINING                  | 1    |
| 4   | 034462 | SCREW   | PUMP HOUSING TO CAM        | 1    |
| 5   | 033037 | WASHER  |                            | 1    |
| 6   | 034458 | CAM     |                            | 1    |
| 7   | 033043 | SEAL    |                            | 2    |
| 8   | 034460 | SHAFT   |                            | 1    |
| 9   | 034440 | KIT     | IMPELLER-SCREW-GASKET      | 1    |
| 10  |        | SCREW   | IMPELLER-INCLUDED IN REF 9 | 1    |
| 11  | 034459 | GASKET  | IMPELLER COVER             | 1    |
| 12  | 034461 | COVER   | IMPELLER                   | 1    |
| 13  | 034463 | SCREW   | IMPELLER COVER             | 6    |
| 14  | 038678 | SPACER  | SEAL                       | 1    |
| 15  | 030326 | GASKET  | SEA WATER PUMP MOUNTING    | 1    |


WESTERBEKE 5.0 BCD GENERATOR - GOVERNOR SYSTEM



WESTERBEKE 5.0 BCD GENERATOR - GOVERNOR SYSTEM

| REF  | PN     | NAME       | REMARKS                             | QUAN |
|------|--------|------------|-------------------------------------|------|
| 1    | 031802 | NUT        | M 8 JAM                             | 1    |
| 2    | 031786 | LOCKWASHER | M 8 DIN 127                         | 1    |
| 3    | 043988 | LEVER      | STOP                                | 1    |
| 4    | 043986 | SPRING     | RETURN                              | 1    |
| 5    | 043982 | COVER      |                                     | 1    |
| 6    | 043985 | PIN        | GROOVED                             | 1    |
| 7    | 030277 | O-RING     |                                     | 1    |
| 8    | 043987 | LEVER      | STOP                                | 1    |
| 9    | 037090 | LEVER      | THROTTLE                            | 1    |
| 10   | 036942 | PIN        | GROOVED                             | 2    |
| 11   | 031825 | CAPSCREW   | M 6 X 12 DIN 933                    | 4    |
| 12   | 037024 | GASKET     | GOVERNOR COVER                      | 1    |
| 13   | 030277 | O-RING     |                                     | 1    |
| 14   | 036989 | LEVER      | GOVERNOR SPRING                     | 1    |
| 15   | 031786 | LOCKWASHER | M 8 DIN 127                         | 1    |
| 16   | 031802 | NUT        | M 8 JAM                             | 1    |
| 17   | 038680 | SCREW      | LOW SPEED SET                       | 1    |
| 18   | 015812 | NUT        | M 6 DIN 934                         | 1    |
| 19   | 043983 | COVER      | HIGH SPEED SET SCREW ANTI-TAMPER    | 1    |
| 20   | 043978 | SCREW      | HIGH SPEED SET INCL NUT             | 1    |
| 21   |        | NUT        | SEE REF 20                          | 1    |
| 22   | 043984 | C-RING     |                                     | 1    |
| 23   | 043977 | SCREW ASSY | RACK SET                            | 1    |
| 24-1 | 038458 | SPRING     | GOVERNOR 5.0 BCD, 5.0 BCDA          | 1    |
| 24-2 | 037109 | SPRING     | GOVERNOR 5.0 BCDB                   | 1    |
| 25   | 037079 | LEVER      | TENSION                             | 1    |
| 26   | 037092 | SPRING     | START                               | 1    |
| 27   | 037080 | SHAFT      | GOVERNOR                            | 1    |
| 28   | 037078 | LEVER      | GOVERNOR                            | 1    |
| 29-1 | 020628 | CAPSCREW   | M 6 X 25 DIN 933                    | 1    |
| 29-2 | 031783 | LOCKWASHER | M 6 DIN 127                         | 1    |
| 30   | 033200 | STOPPER    | GOVERNOR                            | 1    |
| 31-1 | 038455 | WEIGHT     | ASSEMBLY-GOVERNOR 5.0 BCD, 5.0 BCDA | 1    |
| 31-2 | 043979 | WEIGHT     | ASSEMBLY-GOVERNOR 5.0 BCDB          | 1    |
| 32-1 | 015816 | CAPSCREW   | M 6 X 10 DIN 933                    | 2    |
| 32-2 | 031783 | LOCKWASHER | M 6 DIN 127                         | 2    |
| 33-1 | 038457 | SHAFT      | GOVERNOR SLIDING 5.0 BCD, 5.0 BCDA  | 1    |
| 33-2 | 036941 | SHAFT      | GOVERNOR SLIDING 5.0 BCDB           | 1    |
| 34   | 037022 | CLIP       | TIE ROD                             | 1    |
| 35   | 037021 | ROD        | TIE                                 | 1    |
| 36   | 036939 | RING       | RETAINING                           | 1    |
| 37   | 043989 | SPRING     | TIE ROD                             | 1    |
| 38   | 043980 | C-RING     |                                     | 1    |
| 39   | 043981 | COVER      | TORQUE SET ANTI-TAMPER              | 1    |


# WESTERBEKE 5.0 BCD GENERATOR - FUEL SYSTEM



WESTERBEKE 5.0 BCD GENERATOR - FUEL SYSTEM

| REF   | PN     | NAME       | REMARKS                                 | QUAN |
|-------|--------|------------|---|------|
| 1-1   | 038459 | PUMP       | FUEL INJECTION 5.0 BCD, 5.0 BCDA        | 1    |
| 1-2   | 043555 | PUMP       | FUEL INJECTION 5.0 BCDB                 | 1    |
| 2     | 018804 | CAPSCREW   | M 6 X 20 DIN 933                        | 4    |
| 3     | 031783 | LOCKWASHER | M 6 DIN 127                             | 4    |
| 4-1   | 036964 | SHIM       | ADJUSTING 0.2 MM                        | AR   |
| 4-2   | 036965 | SHIM       | ADJUSTING 0.3 MM                        | AR   |
| 4-3   | 037009 | SHIM       | ADJUSTING 0.4 MM                        | AR   |
| 4-4   | 036966 | SHIM       | ADJUSTING 0.5 MM                        | AR   |
| 4-5   | 037010 | SHIM       | ADJUSTING 0.6 MM                        | AR   |
| 4-6   | 037011 | SHIM       | ADJUSTING 0.7 MM                        | AR   |
| 4-7   | 037012 | SHIM       | ADJUSTING 0.8 MM                        | AR   |
| 4-8   | 037013 | SHIM       | ADJUSTING 0.9 MM                        | AR   |
| 4-9   | 037014 | SHIM       | ADJUSTING 1.0 MM                        | AR   |
| 5     | 038401 | LINE       | LIFT PUMP TO INJECTION PUMP             | 1    |
| 6     | 037105 | WASHER     | BANJO                                   | 2    |
| 7     | 038399 | BOLT       | BANJO                                   | 1    |
| 8     | 030289 | WASHER     | BANJO M 8                               | 2    |
| 9     | 016988 | BOLT       | BANJO M 8                               | 1    |
| 10    | 034857 | HOSE       | FUEL RETURN                             | 1    |
| 11    | 038429 | LINE       | INJECTION RETURN TO PUMP                | 1    |
| 12-1  | 024600 | UNION      | COMPRESSION INCLUDING NUTS AND FERRULES | 1    |
| 12-2  | 013344 | NUT        | COMPRESSION                             | 2    |
| 12-3  | 013343 | FERRULE    | COMPRESSION                             | 2    |
| 13    | 036951 | LINE       | INJECTOR 1                              | 1    |
| 14    | 036952 | LINE       | INJECTOR 2                              | 1    |
| 15    | 036953 | LINE       | INJECTOR 3                              | 1    |
| 16    | 036921 | NUT        | INJECTOR                                | 3    |
| 17    | 037099 | LINE       | INJECTOR RETURN                         | 1    |
| 18    | 036922 | GASKET     | INJECTOR RETURN                         | 3    |
| 19    | 037091 | INJECTOR   | INCLUDING REF 20 THRU 27                | 3    |
| 20    | 037112 | HOLDER     | INJECTOR                                | 1    |
| 21- 1 | 036925 | SHIM       | INJECTOR 1.25                           | AR   |
| 21- 2 | 036926 | SHIM       | INJECTOR 1.30                           | AR   |
| 21- 3 | 036927 | SHIM       | INJECTOR 1.35                           | AR   |
| 21- 4 | 036928 | SHIM       | INJECTOR 1.40                           | AR   |
| 21- 5 | 036929 | SHIM       | INJECTOR 1.45                           | AR   |
| 21- 6 | 036930 | SHIM       | INJECTOR 1.50                           | AR   |
| 21- 7 | 036931 | SHIM       | INJECTOR 1.55                           | AR   |
| 21- 8 | 036932 | SHIM       | INJECTOR 1.60                           | AR   |
| 21- 9 | 036933 | SHIM       | INJECTOR 1.65                           | AR   |
| 21-10 | 036934 | SHIM       | INJECTOR 1.70                           | AR   |
| 22    | 037106 | SPRING     | INJECTOR                                | 1    |
| 23    | 037107 | PIN        | INJECTOR SPRING                         | 1    |
| 24    | 037108 | SPACER     | INJECTOR                                | 1    |
| 25    | 036935 | NOZZLE     | INJECTOR                                | 1    |
| 26    | 037113 | GASKET     | INJECTOR NOZZLE 5.0 BCD TO S/N 12009    | 1    |
| 27    | 037109 | NUT        | INJECTOR NOZZLE                         | 1    |
| 28    | 036923 | GASKET     | INJECTOR                                | 3    |


WESTERBEKE 5.0 BCD GENERATOR - FUEL SYSTEM



WESTERBEKE 5.0 BCD GENERATOR - FUEL SYSTEM

| REF  | PN     | NAME       | REMARKS                              | QUAN |
|------|--------|------------|--------------------------------------|------|
| 29   | 038084 | BRACKET    | FUEL FILTER                          | 1    |
| 30   | 031787 | WASHER     | M 8 DIN 125                          | 2    |
| 31   | 031786 | LOCKWASHER | M 8 DIN 127                          | 2    |
| 32   | 017196 | CAPSCREW   | M 8 X 20 DIN 933                     | 2    |
| 33   | 013741 | CLAMP      | SUPPORT HOSE                         | 1    |
| 34   | 024984 | BOLT       | BANJO                                | 2    |
| 35   | 024972 | WASHER     | ALUMINUM                             | 2    |
| 36   | 030291 | WASHER     | BANJO                                | 4    |
| 37-1 | 030210 | FILTER     | FUEL ASSEMBLY INCL REF 37 THRU 40    | 1    |
| 37-2 | 030211 | BODY       | FUEL FILTER                          | 1    |
| 38   | 030200 | ELEMENT    | FUEL FILTER INCLUDING O-RINGS        | 1    |
| 39   | 030199 | CUP        | FUEL FILTER                          | 1    |
| 40   | 030212 | RETAINER   | FUEL FILTER CUP                      | 1    |
| 41   | 038085 | BRACKET    | LIFT PUMP                            | 1    |
| 42   | 038118 | LINE       | LIFT PUMP TO FILTER                  | 1    |
| 43-1 | 019449 | CONNECTOR  | 1/8 NPT TO 1/4 COMPRESSION           | 1    |
| 43-2 | 016676 | NUT        | COMPRESSION                          | 1    |
| 43-3 | 011597 | FERRULE    | COMPRESSION                          | 1    |
| 44   | 039275 | PUMP       | FUEL LIFT 12 VDC                     | 1    |
| 45   | 031753 | WASHER     | FLAT 1/4                             | 2    |
| 46   | 031752 | LOCKWASHER | 1/4                                  | 2    |
| 47   | 031501 | CAPSCREW   | 1/4NC X 1/2                          | 2    |
| 48   | 030025 | HOSE       | FUEL SUPPLY                          | 1    |
| 49   | 013340 | ELBOW      | 1/8 NPT STREET                       | 1    |
| 50   | 034589 | CAPSCREW   | M10 X 30 DIN 933                     | 2    |
| 51   | 019262 | LOCKWASHER | M10 DIN 127                          | 2    |
| 52   | 030213 | SCREW      | BLEED                                | 1    |
| 53   | 030289 | WASHER     |                                      | 1    |
| 54   | 031560 | CAPSCREW   | 5/16NC X 2-1/4                       | 2    |
| 55   | 031758 | LOCKWASHER | 5/16                                 | 2    |
| 56   | 031759 | WASHER     | FLAT 5/16                            | 2    |
| 57   | 038122 | LINE       | PRIOR TO OCT 1989 REPL WITH REF 5-12 | 1    |
| 58   | 037187 | LINE       | FUEL RETURN TO OCT 1989              | 1    |
| 59   | 024906 | CLAMP      | HOSE                                 | 1    |
| 60   | 037110 | BOLT       | BLEED                                | 1    |
| 61   | 037104 | WASHER     | BANJO                                | 1    |
| 62   | 037111 | BOLT       | BANJO                                | 1    |
| 63   | 036868 | HOSE       | INJECTOR RETURN TO PUMP              | 1    |
| 64   | 037163 | CLAMP      | KEYSTONE                             | 2    |


# WESTERBEKE 5.0 BCD GENERATOR - ELECTRICAL SYSTEM



WESTERBEKE 5.0 BCD GENERATOR - ELECTRICAL SYSTEM

| REF | PN     | NAME       | REMARKS                    | QUAN |
|-----|--------|------------|----------------------------|------|
| 1   | 034552 | MOTOR      | STARTER 12VDC              | 1    |
| 2   | 036218 | SOLENOID   | STARTER MOTOR              | 1    |
| 3   | 018242 | NUT        | M 8 DIN 934                | 1    |
| 4   | 032923 | SWITCH     | EXHAUST TEMPERATURE        | 1    |
| 5   | 035711 | SCREW      | 6-20 X 1/4 TAPPING         | 2    |
| 6   | 031844 | LOCKWASHER | 8                          | 2    |
| 7   | 031911 | SCREW      | 8-32 X 1/4                 | 2    |
| 8   | 033381 | SPACER     |                            | 1    |
| 9   | 038087 | EYE        | LIFTING                    | 1    |
| 10  | 031786 | LOCKWASHER | M 8 DIN 127                | 1    |
| 11  | 013630 | CAPSCREW   | M 8 X 25 DIN 933           | 1    |
| 12  | 031861 | SCREW      | 8-32 X 1/4                 | 2    |
| 13  | 043422 | BREAKER    | CIRCUIT 25 AMP             | 1    |
| 14  | 038086 | BRACKET    | CIRCUIT BREAKER, SOLENOID  | 1    |
| 15  | 034589 | CAPSCREW   | M10 X 30 DIN 933           | 1    |
| 16  | 019262 | LOCKWASHER | M10 DIN 127                | 1    |
| 17  | 024639 | SOLENOID   | PRE-HEAT                   | 1    |
| 18  | 031866 | SCREW      | 8-32 X 7/8                 | 2    |
| 19  | 031844 | LOCKWASHER | 8                          | 2    |
| 20  | 031753 | WASHER     | FLAT 1/4                   | 2    |
| 21  | 031752 | LOCKWASHER | 1/4                        | 2    |
| 22  | 031501 | CAPSCREW   | 1/4NC X 1/2                | 2    |
| 23  | 031760 | NUT        | 5/16NF                     | 2    |
| 24  | 031847 | NUT        | 10-32                      | AR   |
| 25  | 036563 | BREAKER    | CIRCUIT ASSEMBLY 10 AMP    | 1    |
| 26  | 037100 | SOLENOID   | FUEL SHUT-OFF              | 1    |
| 27  | 034669 | NUT        | SOLENOID ADJUSTING/LOCKING | 1    |
| 28  | 037508 | ADAPTER    | 1/8 BSPT TO 1/8 NPT        | 1    |
| 29  | 013340 | ELBOW      | 1/8 NPT STREET 90          | 2    |
| 30  | 037323 | SWITCH     | OIL PRESSURE               | 1    |
| 31  | 024132 | SENDER     | OIL PRESSURE               | 1    |
| 32  | 024844 | ADAPTER    | 1/8 BSPT TO 1/8 NPT        | 1    |
| 33  | 038074 | CLAMP      | HARNESS                    | 2    |
| 34  | 039550 | SWITCH     | WATER TEMPERATURE          | 1    |
| 35  | 035109 | SENDER     | WATER TEMPERATURE          | 1    |
| 36  | 036961 | GLOWPLUG   |                            | 3    |
| 37  | 037028 | STRAP      | GLOWPLUG CONNECTING        | 1    |
| 38  | 038123 | HARNESS    | GENSET WIRING              | 1    |
| 39  | 043812 | ADAPTER    | 2 OIL PRESSURE SWITCHES    | 1    |
| 40  | 011552 | SWITCH     | OIL PRESSURE - SEA RAY     | 1    |


# WESTERBEKE 5.0 BCD GENERATOR - BACK END - GENERATOR



WESTERBEKE 5.0 BCD GENERATOR - BACK END - GENERATOR

| REF   | PN     | NAME       | REMARKS                                   | QUAN |
|-------|--------|------------|---|------|
| 1     | 034552 | MOTOR      | STARTER 12VDC                             | 1    |
| 2     | 031789 | WASHER     | M10 DIN 125                               | 2    |
| 3     | 019262 | LOCKWASHER | M10 DIN 127                               | 2    |
| 4     | 034589 | CAPSCREW   | M10 X 30 DIN 933                          | 2    |
| 5-1   | 038202 | FLYWHEEL   | BALANCED WITH RING GEAR                   | 1    |
| 5-2   | 032996 | GEAR       | RING                                      | 1    |
| 6     | 024952 | CAPSCREW   | M10 X 1.25 X 25 DIN 961                   | 6    |
| 7     | 019262 | LOCKWASHER | M10 DIN 127                               | 6    |
| 8     | 036050 | PLATE      | BACK                                      | 1    |
| 9     | 019262 | LOCKWASHER | M10 DIN 127                               | 1    |
| 10    | 034833 | CAPSCREW   | M10 X 60 DIN 912                          | 1    |
| 11    | 013629 | CAPSCREW   | M10 X 25 DIN 933                          | 2    |
| 12    | 019262 | LOCKWASHER | M10 DIN 127                               | 5    |
| 13    | 034589 | CAPSCREW   | M10 X 30 DIN 933                          | 3    |
| 14    | 036924 | BOLT       | FLYWHEEL                                  | 4    |
| 15    | 035928 | PLATE      | DRIVE DISC TO ARMATURE                    | 1    |
| 16    | 035927 | DISC       | DRIVE                                     | 2    |
| 17    | 031786 | LOCKWASHER | M 8 DIN 127                               | 8    |
| 18    | 017196 | CAPSCREW   | M 8 X 20 DIN 933                          | 8    |
| 19    |        | DIODE      | SEE REF 20                                | 2    |
| 20    | 035971 | BRIDGE     | DIODE SET                                 | 1    |
| 21    | 031933 | SCREW      | M 5 X 10 DIN 85A                          | 2    |
| 22    | 035974 | GUARD      | AIR                                       | 1    |
| 23    | 015812 | NUT        | M 6 DIN 934                               | 4    |
| 24    | 031783 | LOCKWASHER | M 6 DIN 127                               | 4    |
| 25    |        | PANEL      | CONTROL-REFER TO CONTROL PANEL PAGE       | 1    |
| 26    | 038236 | ISOLATOR   | PANEL MOUNTING                            | 4    |
| 27    | 031914 | LOCKWASHER | M 5 DIN 6797A                             | 4    |
| 28    | 031918 | SCREW      | M 5 X 10 DIN 84A                          | 4    |
| 29-1  | 035984 | COVER      | 5.0 BCD                                   | 1    |
| 29-2  | 035975 | COVER      | 5.0 BCDA, 5.0 BCDB                        | 1    |
| 30- 1 | 037429 | GENERATOR  | ASSEMBLY 5.0 BCD TO 31023 NLA             | 1    |
| 30- 2 | 043092 | GENERATOR  | ASSEMBLY 5.0 BCD FROM 31024               | 1    |
| 30- 3 | 037438 | GENERATOR  | ASSEMBLY 5.0 BCDA, 5.0 BCDB TO 31018 NLA  | 1    |
| 30- 4 | 043095 | GENERATOR  | ASSEMBLY 5.0 BCDA, 5.0 BCDB FROM 31019    | 1    |
| 30- 5 | 035983 | HOUSING    | INCL STATOR 5.0 BCD TO 20245 NLA          | 1    |
| 30- 6 | 041218 | HOUSING    | INCL STATOR 5.0 BCD 20246 TO 31023        | 1    |
| 30- 7 | 043101 | HOUSING    | INCL STATOR 5.0 BCD FROM 31024            | 1    |
| 30- 8 | 035973 | HOUSING    | INCL STATOR 5.0 BCDA, 5.0 BCDB TO 31018   | 1    |
| 30- 9 | 043102 | HOUSING    | INCL STATOR 5.0 BCDA, 5.0 BCDB FROM 31019 | 1    |
| 30-10 | 037721 | STATOR     | 5.0 BCD TO 20245 NLA                      | 1    |
| 30-11 | 041216 | STATOR     | 5.0 BCD FROM 20246 TO 31023               | 1    |
| 30-12 | 043098 | STATOR     | 5.0 BCD FROM 31024                        | 1    |
| 30-13 | 037722 | STATOR     | 5.0 BCDA, 5.0 BCDB TO 31018               | 1    |
| 30-14 | 043099 | STATOR     | 5.0 BCDA, 5.0 BCDB FROM 31019             | 1    |


# WESTERBEKE 5.0 BCD GENERATOR - BACK END - GENERATOR



WESTERBEKE 5.0 BCD GENERATOR - BACK END - GENERATOR

| REF  | PN     | NAME       | REMARKS                               | QUAN |
|------|--------|------------|---------------------------------------|------|
| 31   | 034182 | COVER      | PTO                                   | 1    |
| 32   | 038088 | DRIPTRAY   |                                       | 1    |
| 33   | 015887 | NUT        | M10 DIN 934                           | 2    |
| 34   | 019262 | LOCKWASHER | M10 DIN 127                           | 1    |
| 35   | 019039 | DOWEL      | HOUSING TO BACKPLATE                  | 2    |
| 36   | 035972 | BEARING    | BALL                                  | 1    |
| 37-1 | 035982 | ARMATURE   | ASSEMBLY 5.0 BCD                      | 1    |
| 37-2 | 035970 | ARMATURE   | ASSEMBLY 5.0 BCDA, 5.0 BCDB           | 1    |
| 38   | 035969 | FAN        |                                       | 1    |
| 39   | 031789 | WASHER     | M10 DIN 125                           | 6    |
| 40   | 031915 | LOCKWASHER | M10 DIN 6797A                         | 6    |
| 41   | 018813 | CAPSCREW   | M10 X 20 DIN 933                      | 6    |
| 42   | 031712 | CAPSCREW   | 1/2NC X 2-3/4                         | 4    |
| 43   | 031777 | WASHER     | FLAT 1/2                              | 4    |
| 44   | 019262 | LOCKWASHER | M10 DIN 127                           | 4    |
| 45   | 031228 | CAPSCREW   | M10 X 1.25 X 30 DIN 961               | 4    |
| 46   | 031556 | CAPSCREW   | 5/16NC X 1-1/4                        | 16   |
| 47-1 | 038112 | MOUNT      | FRONT RIGHT                           | 1    |
| 47-2 | 038113 | MOUNT      | FRONT LEFT                            | 1    |
| 48   | 033530 | SHIELD     | FRONT ISOLATOR                        | 2    |
| 49   | 024776 | ISOLATOR   |                                       | 4    |
| 50   | 035273 | SPACER     | ISOLATOR TO RAIL                      | 4    |
| 51   | 024674 | WASHER     | ISOLATOR SNUBBING                     | 8    |
| 52   | 031776 | LOCKWASHER | 1/2                                   | 4    |
| 53   | 031774 | NUT        | 1/2NC                                 | 4    |
| 54   | 031758 | LOCKWASHER | 5/16                                  | 16   |
| 55   | 031756 | NUT        | 5/16NC                                | 16   |
| 56-1 | 038148 | RAIL       | LEFT-ASSEMBLY                         | 1    |
| 56-2 | 038149 | RAIL       | RIGHT-ASSEMBLY INCLUDING GROUND STRAP | 1    |
| 57   | 034593 | STRAP      | GROUND                                | 1    |



# WESTERBEKE 5.0 BCD GENERATOR - AC OUTPUT



WESTERBEKE 5.0 BCD GENERATOR - AC OUTPUT

| REF  | PN     | NAME       | REMARKS                                 | QUAN |
|------|--------|------------|---|------|
| 1-1  | 035981 | CHARGER    | BATTERY 5.0 BCD TO 31023                | 1    |
| 1-2  | 043096 | CHARGER    | BATTERY 5.0 BCD FROM 31024              | 1    |
| 1-3  | 035981 | CHARGER    | BATTERY 5.0 BCDA, 5.0 BCDB TO 31018     | 1    |
| 1-4  | 043096 | CHARGER    | BATTERY 5.0 BCDA, 5.0 BCDB FROM 31019   | 1    |
| 2    | 031930 | SCREW      | M 5 X 10 DIN 963A                       | 2    |
| 3    | 043649 | RECTIFIER  | BRIDGE                                  | 1    |
| 4-1  | 035978 | CAPACITOR  | 5.0 BCD (31.5 MFD)                      | 1    |
| 4-2  | 041199 | CAPACITOR  | 5.0 BCD (35 MFD) S/N 20246C-20308C ONLY | 1    |
| 4-3  | 035978 | CAPACITOR  | 5.0 BCDA, 5.0 BCDB (31.5 MFD) TO 15506  | 2    |
| 4-4  | 039556 | CAPACITOR  | 5.0 BCDA, 5.0 BCDB (18 MFD) FROM 15507  | 2    |
| 5    | 031918 | SCREW      | M 5 X 10 DIN 84A                        | 4    |
| 6-1  | 035984 | COVER      | 5.0 BCD                                 | 1    |
| 6-2  | 035975 | COVER      | 5.0 BCDA, 5.0 BCDB                      | 1    |
| 7-1  | 035940 | BLOCK      | TERMINAL AC OUTPUT M 5 STUDS            | 1    |
| 7-2  | 038348 | NUT        | M 5 BRASS                               | AR   |
| 7-3  | 038349 | BAR        | BUSS                                    | AR   |
| 7-4  | 040138 | WASHER     | M 5 BRASS                               | AR   |
| 8-1  | 035979 | CLAMP      | CAPACITOR 5.0 BCD                       | 1    |
| 8-2  | 035979 | CLAMP      | CAPACITOR 5.0 BCDA, 5.0 BCDB            | 2    |
| 9-1  | 018241 | NUT        | M 5 DIN 934 5.0 BCD                     | 1    |
| 9-2  | 018241 | NUT        | M 5 DIN 934 5.0 BCDA, 5.0 BCDB          | 2    |
| 10-1 | 031914 | LOCKWASHER | M 5 DIN 6797A 5.0 BCD                   | 2    |
| 10-2 | 031914 | LOCKWASHER | M 5 DIN 6797A 5.0 BCDA, 5.0 BCDB        | 4    |
| 11-1 | 031781 | WASHER     | M 5 DIN 125 5.0 BCD                     | 1    |
| 11-2 | 031781 | WASHER     | M 5 DIN 127 5.0 BCDA, 5.0 BCDB          | 2    |
| 12-1 | 031920 | SCREW      | M 5 X 20 DIN 84A 5.0 BCD                | 1    |
| 12-2 | 031920 | SCREW      | M 5 X 20 DIN 84A 5.0 BCDA, 5.0 BCDB     | 2    |
| 13   | 031914 | LOCKWASHER | M 5 DIN 6797A                           | 1    |
| 14   | 031931 | SCREW      | M 5 X 16 DIN 84A                        | 1    |
| 15   | 031932 | CAPSCREW   | M 5 X 10 DIN 933 BRASS                  | 1    |
| 16   | 031914 | LOCKWASHER | M 5 DIN 6797A                           | 1    |
| 17   | 035980 | TERMINAL   | CHARGER OUTPUT-ISOLATED                 | 1    |
| 18   | 031930 | SCREW      | M 5 X 10 DIN 963A                       | 1    |
| 19   | 035944 | GROMMET    | WIRES THRU HOUSING                      | 1    |
| 20   | 035455 | LABEL      | AC OUTPUT CONNECTIONS                   | 1    |





WESTERBEKE 5.0 BCD GENERATOR - AC OUTPUT CIRCUIT BREAKER



WESTERBEKE 5.0 BCD GENERATOR - AC OUTPUT CIRCUIT BREAKER

| REF  | PN     | NAME       | REMARKS                            | QUAN |
|------|--------|------------|------------------------------------|------|
| 2    | 031891 | SCREW      | 8-32 X 3/8 TRUSS HEAD SS           | 6    |
| 3    | 038126 | COVER      | BOX                                | 1    |
| 4    | 039082 | GUARD      | CIRCUIT BREAKER HANDLE             | 1    |
| 5    | 031852 | SCREW      | 6-32 X 1/4 BINDING HEAD SS         | 4    |
| 6    | 042330 | NIPPLE     | 1"                                 | 1    |
| 7    | 042329 | NUT        | 1"                                 | 3    |
| 8    | 038523 | SPACER     |                                    | 1    |
| 9-1  | 042705 | BREAKER    | CIRCUIT 25 AMP 60HZ 2 POLE         | 1    |
| 9-2  | 042704 | BREAKER    | CIRCUIT 20 AMP 50HZ 2 POLE         | 1    |
| 10   | 032493 | LOCKWASHER | 1/4 INTERNAL TOOTH BRONZE          | 2    |
| 11   | 032498 | NUT        | 1/4NC HEX BRASS                    | 2    |
| 12   | 032499 | WASHER     | FLAT 1/4 BRASS                     | 2    |
| 13   | 038645 | WIRE       | WHITE 60HZ                         | 1    |
| 14   | 038125 | BOX        | CIRCUIT BREAKER                    | 1    |
| 15   | 038640 | WIRE       | BLACK 60/50HZ                      | 1    |
| 16-1 | 038640 | WIRE       | BLACK 60HZ                         | 1    |
| 16-2 | 042333 | WIRE       | WHITE 50HZ                         | 1    |
| 17   | 031847 | NUT        | 10-32 HEX SS                       | 4    |
| 18   | 031848 | WASHER     | FLAT 10 SS                         | 8    |
| 19   | 038622 | CAPSCREW   | 1/4NC X 1 BRONZE FULLY THREADED    | 1    |
| 20   | 038621 | PLUG       | NYLON                              | 1    |
| 21   | 042719 | DIAGRAM    | AC OUTPUT & CIRCUIT BREAKER WIRING | 1    |





WESTERBEKE 5.0 BCD GENERATOR - CONTROL PANEL



WESTERBEKE 5.0 BCD GENERATOR - CONTROL PANEL

| REF  | PN     | NAME       | REMARKS                           | QUAN |
|------|--------|------------|-----------------------------------|------|
| 1    | 036539 | PANEL      | GENERATOR CONTROL REF 2 THRU 13   | 1    |
| 2    | 036192 | HOURMETER  |                                   | 1    |
| 3    | 037605 | VOLTMETER  | 12 VDC                            | 1    |
| 4    | 037603 | METER      | OIL PRESSURE 0-100 PSI            | 1    |
| 5    | 037601 | METER      | WATER TEMPERATURE                 | 1    |
| 6-1  | 034485 | PLATE      | PANEL                             | 1    |
| 6-2  | 034999 | COVER      | BOX, WHEN PANEL REMOTE MOUNTED    | 1    |
| 7    | 024731 | SWITCH     | STOP                              | 1    |
| 8    | 024732 | SWITCH     | PREHEAT-START                     | 2    |
| 9-1  | 042893 | LAMP       | INSTRUMENT WEDGE BASE INCL HOLDER | 3    |
| 9-2  | 035825 | WIRE       | LAMP POWER CONNECTION             | 3    |
| 10-1 | 031900 | NUT        | 10-32                             | AR   |
| 10-2 | 031902 | LOCKWASHER | 10                                | AR   |
| 11   | 031904 | NUT        | 10-24 KEPS                        | 1    |
| 12   | 036538 | HARNESS    | PANEL                             | 1    |
| 13   | 031999 | RING       | LOCK-TOGGLE SWITCH MOUNT          | 3    |
| 14   | 034421 | SCREW      | 8-32 X 3/8 TRUSS HEAD BLACK SS    | 4    |
| 15-1 | 038123 | HARNESS    | ENGINE                            | 1    |
| 15-2 | 036232 | HARNESS    | PANEL BOX                         | 1    |
| 16   | 023939 | BUSHING    | SNAP-IN 1-3/4 IN HOLE             | 2    |
| 17-1 | 038178 | ASSEMBLY   | BOX AND HARNESS                   | 1    |
| 17-2 | 034243 | BOX        | GENERATOR CONTROL PANEL           | 1    |
| 18   | 013856 | PLATE      | SCREW-TERMINAL BLOCK              | 2    |
| 19-1 | 031866 | SCREW      | 8-32 X 7/8 BINDING HEAD SS        | 4    |
| 19-2 | 031842 | NUT        | 8-32 HEX SS                       | 4    |
| 19-3 | 031843 | WASHER     | FLAT 8                            | 4    |
| 19-4 | 031844 | LOCKWASHER | 8                                 | 4    |
| 20   | 013320 | BLOCK      | TERMINAL 4 POS TO SEPT 93         | 1    |
| 21   | 013363 | MARKER     | TERMINAL BLOCK                    | 1    |
| 22   | 013938 | JUMPER     | TERMINAL BLOCK                    | 1    |
| 23-1 | 031855 | SCREW      | 6-32 X 5/8 BINDING HEAD SS        | 4    |
| 23-2 | 050234 | NUT        | 6-32 KEPS                         | 4    |
| 23-3 | 031838 | WASHER     | FLAT 6                            | 4    |
| 24   | 015222 | PLATE      | SCREW-TERMINAL BLOCK              | 2    |
| 24-4 | 038042 | NUT        | SWITCH                            | 1    |
| 25   | 019122 | MARKER     | TERMINAL BLOCK                    | 1    |
| 26   | 019121 | BLOCK      | TERMINAL 5 POS TO SEPT 93         | 1    |
| 27-1 | 033259 | SWITCH     | EMERGENCY STOP                    | 1    |
| 27-2 | 033258 | BOOT       | EMERGENCY STOP SWITCH             | 1    |
| 27-3 | 033251 | LABEL      | EMERGENCY STOP SWITCH             | 1    |


WESTERBEKE 5.0 BCD GENERATOR - CONTROL PANEL



WESTERBEKE 5.0 BCD GENERATOR - CONTROL PANEL

| REF  | PN     | NAME   | REMARKS                                | QUAN |
|------|--------|--------|--|------|
| 28   | 039928 | BLOCK  | TERMINAL 10 POS FROM SEPT 93           | 2    |
| 29   | 039929 | MARKER | TERMINAL BLOCK                         | 2    |
| 30   | 015222 | PLATE  | SCREW-TERMINAL BLOCK                   | 4    |
| 31-1 | 031855 | SCREW  | 6-32 X 5/8 BINDING HEAD SS             | 7    |
| 31-2 | 031857 | SCREW  | 6-32 X 7/8 BINDING HEAD SS             | 1    |
| 31-3 | 050234 | NUT    | 6-32 KEPS                              | 8    |
| 31-4 | 015223 | JUMPER | TERMINAL BLOCK                         | AR   |
| 32-1 | 031872 | SCREW  | 10-32 X 1/2 BINDING HEAD SS - 1 RELAY  | 1    |
| 32-2 | 031872 | SCREW  | 10-32 X 1/2 BINDING HEAD SS - 2 RELAYS | 2    |
| 33-1 | 037833 | RELAY  | 40 AMP FROM JUNE 97                    | 1    |
| 33-2 | 037833 | RELAY  | 40 AMP FROM JAN 99                     | 2    |
| 34-1 | 200125 | NUT    | 10-32 KEPS - 1 RELAY                   | 1    |
| 34-2 | 200125 | NUT    | 10-32 KEPS - 2 RELAYS                  | 2    |
| 35   | 041081 | DIODE  | FROM JUNE 97                           | 1    |
| 36   | 024968 | LABEL  | GENSET OPERATING INSTRUCTIONS          | 1    |


WESTERBEKE 5.0 BCDB GENERATOR - SEA RAY CONTROL PANEL



WESTERBEKE 5.0 BCDB GENERATOR - SEA RAY CONTROL PANEL

| REF  | PN     | NAME       | REMARKS                                 | QUAN |
|------|--------|------------|---|------|
| 1    | 036539 | PANEL      | GENERATOR CONTROL REF 2 THRU 13         | 1    |
| 2    | 036192 | HOURLMETER |   | 1    |
| 3    | 037605 | VOLTMETER  | 12 VDC                                  | 1    |
| 4    | 037603 | METER      | OIL PRESSURE 0-100 PSI                  | 1    |
| 5    | 037601 | METER      | WATER TEMPERATURE                       | 1    |
| 6    | 034485 | PLATE      | PANEL                                   | 1    |
| 7    | 024731 | SWITCH     | STOP                                    | 1    |
| 8    | 024732 | SWITCH     | PREHEAT-START                           | 2    |
| 9-1  | 042893 | LAMP       | INSTRUMENT WEDGE BASE INCL HOLDER       | 3    |
| 9-2  | 035825 | WIRE       | LAMP POWER CONNECTION                   | 3    |
| 10-1 | 031900 | NUT        | 10-32                                   | AR   |
| 10-2 | 031902 | LOCKWASHER | 10                                      | AR   |
| 11   | 031904 | NUT        | 10-24 KEPS                              | 1    |
| 12   | 036538 | HARNESS    | PANEL                                   | 1    |
| 13   | 031999 | RING       | LOCK-TOGGLE SWITCH MOUNT                | 3    |
| 14   | 034421 | SCREW      | 8-32 X 3/8 TRUSS HEAD BLACK SS          | 4    |
| 15-1 | 043841 | HARNESS    | ENGINE                                  | 1    |
| 15-2 | 043747 | HARNESS    | PANEL BOX                               | 1    |
| 16-1 | 043795 | ASSEMBLY   | BOX AND HARNESS                         | 1    |
| 16-2 | 043840 | BOX        | GENERATOR CONTROL PANEL                 | 1    |
| 16-3 | 040195 | COVER      | CONTROL PANEL TOP                       | 1    |
| 17   |        | CAP        | FUSE HOLDER SEE REF 19                  | 1    |
| 18   | 033769 | FUSE       | 8 AMP                                   | 1    |
| 19   | 043747 | HOLDER     | FUSE INCL CAP AND NUT                   | 1    |
| 20   |        | NUT        | SEE REF 19                              | 1    |
| 21-1 | 038042 | NUT        | SWITCH MOUNT                            | 1    |
| 21-2 | 031999 | RING       | LOCK-TOGGLE SWITCH MOUNT                | 1    |
| 22-1 | 033259 | SWITCH     | EMERGENCY STOP                          | 1    |
| 22-2 | 033251 | LABEL      | EMERGENCY STOP SWITCH                   | 1    |
| 23   | 037833 | RELAY      | 40 AMP                                  | 2    |
| 24   | 200125 | NUT        | 10-32 KEPS                              | 2    |
| 25   | 031872 | SCREW      | 10-32 X 1/2 BINDING HEAD SS             | 2    |
| 26-1 | 039928 | BLOCK      | TERMINAL 10 POSITION                    | 2    |
| 26-2 | 039929 | MARKER     | TERMINAL BLOCK                          | 2    |
| 26-3 | 015222 | PLATE      | SCREW-TERMINAL BLOCK                    | 4    |
| 26-4 | 031855 | SCREW      | 6-32 X 5/8 BINDING HEAD SS              | 7    |
| 26-5 | 031857 | SCREW      | 6-32 X 7/8 BINDING HEAD SS              | 1    |
| 26-6 | 050234 | NUT        | 6-32 KEPS                               | 8    |
| 27   | 043746 | CONNECTOR  | ASSEMBLY FEMALE FOR REMOTE PANEL        | 1    |
| 28   | 043818 | CONNECTOR  | MALE JUMPER-IF REMOTE PNL NOT INSTALLED | 1    |
| 29   | 041081 | DIODE      |   | 1    |


WESTERBEKE 5.0 BCD GENERATOR - BELT - IDLER PULLEY - BELT GUARD



WESTERBEKE 5.0 BCD GENERATOR - BELT - IDLER PULLEY - BELT GUARD

| REF | PN     | NAME       | REMARKS          | QUAN |
|-----|--------|------------|------------------|------|
| 1   | 018242 | NUT        | M 8 DIN 934      | 2    |
| 2   | 031786 | LOCKWASHER | M 8 DIN 127      | 2    |
| 3   | 031765 | WASHER     |                  | 1    |
| 4   | 038070 | BRACKET    | IDLER PULLEY     | 1    |
| 5   | 031786 | LOCKWASHER | M 8 DIN 127      | 1    |
| 6   | 031225 | CAPSCREW   | M 8 X 60 DIN 931 | 1    |
| 7   | 021558 | CAPSCREW   | M 8 X 35 DIN 933 | 1    |
| 8   | 037780 | PULLEY     | IDLER            | 1    |
| 9   | 037779 | SCREW      | IDLER PULLEY     | 1    |
| 10  | 038128 | BRACKET    | BELT GUARD       | 1    |
| 11  | 031783 | LOCKWASHER | M 6 DIN 127      | 1    |
| 12  | 033351 | CAPSCREW   | M 6 X 60 DIN 931 | 1    |
| 13  | 033228 | WINGSCREW  | BELT GUARD       | 3    |
| 14  | 031849 | LOCKWASHER | 10               | 3    |
| 15  | 033372 | WASHER     | BELT GUARD       | 3    |
| 16  | 038073 | GUARD      | BELT             | 1    |
| 17  | 034213 | CAPSCREW   | M 6 X 40 DIN 931 | 1    |
| 18  | 031783 | LOCKWASHER | M 6 DIN 127      | 1    |
| 19  | 038130 | BRACKET    | BELT GUARD       | 1    |
| 20  | 038129 | BRACKET    | BELT GUARD       | 1    |
| 21  | 031783 | LOCKWASHER | M 6 DIN 127      | 1    |
| 22  | 018804 | CAPSCREW   | M 6 X 20 DIN 933 | 1    |
| 23  | 030376 | BELT       |                  | 1    |

# WESTERBEKE 5.0 BCD GENERATOR - SOUND GUARD



WESTERBEKE 5.0 BCD GENERATOR - SOUND GUARD

| REF  | PN     | NAME       | REMARKS                        | QUAN |
|------|--------|------------|--------------------------------|------|
| 1    |        | PANEL      | TOP                            | 1    |
| 2    | 038263 | RAIL       | SIDE                           | 2    |
| 3    | 024057 | CORNER     |                                | 4    |
| 4    | 030896 | RETAINER   | QUICK OPENING SCREW            | AR   |
| 5    | 030895 | SCREW      | QUICK OPENING                  | AR   |
| 6    | 031940 | SCREW      | 6-32 X 3/8 SEMS PHIL HD        | AR   |
| 7    | 030775 | GUIDE      | PANEL ALIGNMENT                | AR   |
| 8    |        | PANEL      | REAR                           | 1    |
| 9    | 038383 | RAIL       | END                            | 2    |
| 10   |        | PANEL      | SIDE                           | 1    |
| 11   |        | PANEL      | FRONT                          | 1    |
| 12   |        | PANEL      | SIDE WITH WINDOW               | 1    |
| 13   | 037417 | WINDOW     | ASSEMBLY                       | 1    |
| 14-1 | 035720 | HANDLE     |                                | AR   |
| 14-2 | 031937 | SCREW      | 8-32 X 3/8 SEMS PHIL HD        | AR   |
| 15   | 040477 | POST       | CORNER                         | 4    |
| 16   | 036624 | ELBOW      | SEA WATER INLET                | 1    |
| 17   | 031752 | LOCKWASHER | 1/4                            | 4    |
| 18   | 031501 | CAPSCREW   | 1/4NC X 1/2                    | 4    |
| 19   | 038328 | SKIRT      | FRONT                          | 1    |
| 20   | 024058 | CORNER     |                                | 4    |
| 21   | 030880 | CLOSURE    | SKIRT CORNER                   | 4    |
| 22   | 038258 | SKIRT      | SIDE                           | 2    |
| 23   | 031503 | CAPSCREW   | 1/4NC X 3/4                    | 8    |
| 24   | 041744 | SKIRT      | REAR                           | 1    |
| 25-1 | 041700 | ELBOW      | EXHAUST 90 DEG 1-7/8IN         | 1    |
| 25-2 | 037816 | BUSHING    | 1-7/8" TO 2" HOSE              | 1    |
| 26   | 041745 | PLENUM     | AIR INTAKE                     | 1    |
| 28   | 023991 | ADAPTER    | FUEL LINES THRU SKIRT-OPTIONAL | 2    |
| 29   | 036069 | BOLT       | ASSEMBLY - PLENUM              | 2    |
| 30   | 038289 | HOSE       | SKIRT TO SEA WATER PUMP        | 1    |

WESTERBEKE 5.0 BCD GENERATOR - MISCELLANEOUS

| REF  | PN     | NAME       | REMARKS                                | QUAN |
|------|--------|------------|--|------|
| 1    | 038350 | KIT A      | SPARE PARTS                            | 1    |
| 2-1  | 038351 | KIT B      | SPARE PARTS-EXTENDED CRUISING 5.0 BCD  | 1    |
| 2-2  | 038351 | KIT B      | SPARE PARTS-EXTENDED CRUISING 5.0 BCDA | 1    |
| 2-3  | 043562 | KIT B      | SPARE PARTS-EXTENDED CRUISING 5.0 BCDB | 1    |
| 3-1  | 038352 | GASKET SET | UPPER 5.0 BCD, 5.0 BCDA                | 1    |
| 3-2  | 043560 | GASKET SET | UPPER 5.0 BCDB                         | 1    |
| 4-1  | 038353 | GASKET SET | COMPLETE 5.0 BCD, 5.0 BCDA             | 1    |
| 4-2  | 043561 | GASKET SET | COMPLETE 5.0 BCDB                      | 1    |
| 5    | 037121 | KIT        | FUEL HARDWARE                          | 1    |
| 6    | 024177 | KIT        | REMOTE FRESH WATER SURGE TANK          | 1    |
| 7-1  | 013758 | PAINT      | RED AEROSOL SPRAY CAN                  | 1    |
| 7-2  | 042307 | PAINT      | WHITE AEROSOL SPRAY CAN                | 1    |
| 8    | 030760 | HARNES     | 15 FOOT PANEL EXTENSION                | 1    |
| 9    | 038677 | PARTSLIST  |  | 1    |
| 10   | 038673 | MANUAL     | SERVICE                                | 1    |
| 11   | 042871 | MANUAL     | OPERATOR                               | 1    |
| 12   | 032974 | FILTER     | SEDIMENTER/WATER TRAP                  | 1    |
| 13-1 | 038124 | DIAGRAM    | GENSET WIRING                          | 1    |
| 13-2 | 043783 | DIAGRAM    | GENSET WIRING - SEA RAY                | 1    |
| 14   | 033327 | VALVE      | ANTI-SIPHON VENT                       | 1    |
| 15   | 015010 | STRAINER   | SEA WATER                              | 1    |
| 16   | 034936 | MUFFLER    | HYDRO-HUSH C                           | 1    |
| 17-1 | 033340 | ADAPTER    | HOSE TO MUFFLER-STRAIGHT               | AR   |
| 17-2 | 033341 | ADAPTER    | HOSE TO MUFFLER-45 DEGREE              | AR   |
| 17-3 | 033342 | ADAPTER    | HOSE TO MUFFLER-90 DEGREE              | AR   |
| 17-4 | 033943 | COUPLING   | RUBBER INCLUDING CLAMPS                | AR   |

| PART NO | PAGE | REF  | PART NO | PAGE | REF  | PART NO | PAGE | REF |
|---------|------|------|---------|------|------|---------|------|-----|
| 011386  | 115  | 56   | 019262  | 123  | 51   | 030212  | 123  | 40  |
| 011405  | 113  | 15   | 019262  | 125  | 16   | 030213  | 123  | 52  |
| 011405  | 113  | 17   | 019262  | 127  | 3    | 030214  | 101  | 23  |
| 011405  | 115  | 68   | 019262  | 127  | 7    | 030219  | 105  | 18  |
| 011597  | 123  | 43-3 | 019262  | 127  | 9    | 030225  | 111  | 39  |
| 011885  | 115  | 55   | 019262  | 127  | 12   | 030231  | 107  | 6   |
| 012292  | 115  | 69   | 019262  | 129  | 34   | 030239  | 101  | 22  |
| 013320  | 135  | 20   | 019262  | 129  | 44   | 030241  | 105  | 31  |
| 013337  | 115  | 59   | 019321  | 113  | 44   | 030242  | 105  | 28  |
| 013340  | 109  | 33   | 019369  | 115  | 54   | 030244  | 111  | 37  |
| 013340  | 123  | 49   | 019449  | 123  | 43-1 | 030272  | 101  | 12  |
| 013340  | 125  | 29   | 020628  | 119  | 29-1 | 030273  | 109  | 3   |
| 013343  | 121  | 12-3 | 021558  | 141  | 7    | 030274  | 107  | 7   |
| 013344  | 121  | 12-2 | 022850  | 113  | 45   | 030274  | 109  | 16  |
| 013363  | 135  | 21   | 022851  | 113  | 43   | 030277  | 119  | 7   |
| 013590  | 111  | 51-1 | 022852  | 113  | 46   | 030277  | 119  | 13  |
| 013629  | 127  | 11   | 023939  | 135  | 16   | 030280  | 109  | 11  |
| 013630  | 109  | 25-1 | 023991  | 143  | 28   | 030289  | 121  | 8   |
| 013630  | 125  | 11   | 024057  | 143  | 3    | 030289  | 123  | 53  |
| 013741  | 123  | 33   | 024058  | 143  | 20   | 030291  | 123  | 36  |
| 013758  | 144  | 7-1  | 024132  | 111  | 41   | 030326  | 109  | 24  |
| 013856  | 135  | 18   | 024132  | 125  | 31   | 030326  | 117  | 15  |
| 013938  | 135  | 22   | 024177  | 144  | 6    | 030376  | 141  | 23  |
| 015010  | 144  | 15   | 024306  | 113  | 14   | 030386  | 113  | 39  |
| 015222  | 135  | 24   | 024369  | 105  | 8    | 030461  | 111  | 40  |
| 015222  | 137  | 30   | 024373  | 101  | 2    | 030707  | 101  | 31  |
| 015222  | 139  | 26-3 | 024600  | 121  | 12-1 | 030708  | 101  | 4   |
| 015223  | 137  | 31-4 | 024602  | 113  | 27   | 030711  | 105  | 6   |
| 015812  | 119  | 18   | 024637  | 115  | 67   | 030712  | 101  | 10  |
| 015812  | 127  | 23   | 024639  | 125  | 17   | 030712  | 101  | 18  |
| 015816  | 119  | 32-1 | 024674  | 129  | 51   | 030712  | 111  | 45  |
| 015828  | 109  | 22   | 024704  | 115  | 65   | 030760  | 144  | 8   |
| 015830  | 113  | 12   | 024731  | 135  | 7    | 030775  | 143  | 7   |
| 015887  | 129  | 33   | 024731  | 139  | 7    | 030846  | 103  | 45  |
| 016676  | 123  | 43-2 | 024732  | 135  | 8    | 030880  | 143  | 21  |
| 016789  | 101  | 13   | 024732  | 139  | 8    | 030895  | 143  | 5   |
| 016988  | 121  | 9    | 024776  | 129  | 49   | 030896  | 143  | 4   |
| 017012  | 105  | 22-1 | 024786  | 115  | 66   | 031225  | 105  | 43  |
| 017196  | 123  | 32   | 024844  | 111  | 52   | 031225  | 141  | 6   |
| 017196  | 127  | 18   | 024844  | 125  | 32   | 031228  | 129  | 45  |
| 018241  | 131  | 9-1  | 024858  | 115  | 64   | 031281  | 109  | 21  |
| 018241  | 131  | 9-2  | 024905  | 103  | 47   | 031501  | 123  | 47  |
| 018242  | 109  | 18   | 024906  | 115  | 63   | 031501  | 125  | 22  |
| 018242  | 113  | 8    | 024906  | 123  | 59   | 031501  | 143  | 18  |
| 018242  | 125  | 3    | 024907  | 113  | 13   | 031503  | 143  | 23  |
| 018242  | 141  | 1    | 024922  | 103  | 46   | 031506  | 115  | 50  |
| 018804  | 101  | 8    | 024952  | 127  | 6    | 031556  | 129  | 46  |
| 018804  | 105  | 25   | 024968  | 137  | 36   | 031560  | 123  | 54  |
| 018804  | 113  | 21   | 024972  | 123  | 35   | 031712  | 129  | 42  |
| 018804  | 113  | 31   | 024977  | 115  | 62   | 031752  | 115  | 49  |
| 018804  | 113  | 35   | 024984  | 123  | 34   | 031752  | 123  | 46  |
| 018804  | 121  | 2    | 030025  | 123  | 48   | 031752  | 125  | 21  |
| 018804  | 141  | 22   | 030146  | 111  | 43   | 031752  | 143  | 17  |
| 018813  | 129  | 41   | 030146  | 113  | 36   | 031753  | 115  | 48  |
| 019039  | 129  | 35   | 030199  | 123  | 39   | 031753  | 123  | 45  |
| 019121  | 135  | 26   | 030200  | 123  | 38   | 031753  | 125  | 20  |
| 019122  | 135  | 25   | 030210  | 123  | 37-1 | 031756  | 129  | 55  |
| 019262  | 115  | 52   | 030211  | 123  | 37-2 | 031758  | 123  | 55  |

| PART NO | PAGE | REF  | PART NO | PAGE | REF  | PART NO | PAGE | REF  |
|---------|------|------|---------|------|------|---------|------|------|
| 031758  | 129  | 54   | 031825  | 109  | 7-1  | 032923  | 125  | 4    |
| 031759  | 123  | 56   | 031825  | 113  | 37-1 | 032947  | 115  | 58   |
| 031760  | 125  | 23   | 031825  | 115  | 72   | 032974  | 144  | 12   |
| 031765  | 141  | 3    | 031825  | 119  | 11   | 032996  | 127  | 5-2  |
| 031774  | 129  | 53   | 031838  | 135  | 23-3 | 033037  | 117  | 5    |
| 031776  | 129  | 52   | 031842  | 135  | 19-2 | 033043  | 117  | 7    |
| 031777  | 129  | 43   | 031843  | 135  | 19-3 | 033044  | 117  | 3    |
| 031781  | 131  | 11-1 | 031844  | 125  | 6    | 033123  | 105  | 17   |
| 031781  | 131  | 11-2 | 031844  | 125  | 19   | 033123  | 109  | 31   |
| 031783  | 101  | 25-2 | 031844  | 135  | 19-4 | 033124  | 105  | 35   |
| 031783  | 101  | 28-2 | 031847  | 125  | 24   | 033126  | 105  | 16-1 |
| 031783  | 103  | 41-2 | 031847  | 133  | 17   | 033126  | 109  | 30   |
| 031783  | 105  | 22-2 | 031848  | 133  | 18   | 033134  | 105  | 9    |
| 031783  | 109  | 7-2  | 031849  | 141  | 14   | 033149  | 105  | 30   |
| 031783  | 111  | 46-2 | 031852  | 133  | 5    | 033151  | 105  | 41   |
| 031783  | 111  | 51-2 | 031855  | 135  | 23-1 | 033152  | 105  | 40   |
| 031783  | 113  | 20   | 031855  | 137  | 31-1 | 033200  | 119  | 30   |
| 031783  | 113  | 37-2 | 031855  | 139  | 26-4 | 033212  | 101  | 3    |
| 031783  | 115  | 71-1 | 031857  | 137  | 31-2 | 033228  | 141  | 13   |
| 031783  | 119  | 29-2 | 031857  | 139  | 26-5 | 033251  | 135  | 27-3 |
| 031783  | 119  | 32-2 | 031861  | 125  | 12   | 033251  | 139  | 22-2 |
| 031783  | 121  | 3    | 031866  | 125  | 18   | 033258  | 135  | 27-2 |
| 031783  | 127  | 24   | 031866  | 135  | 19-1 | 033259  | 135  | 27-1 |
| 031783  | 141  | 11   | 031872  | 137  | 32-1 | 033259  | 139  | 22-1 |
| 031783  | 141  | 18   | 031872  | 137  | 32-2 | 033327  | 144  | 14   |
| 031783  | 141  | 21   | 031872  | 139  | 25   | 033340  | 144  | 17-1 |
| 031784  | 105  | 14   | 031891  | 133  | 2    | 033341  | 144  | 17-2 |
| 031784  | 105  | 22-3 | 031900  | 135  | 10-1 | 033342  | 144  | 17-3 |
| 031784  | 113  | 19   | 031900  | 139  | 10-1 | 033351  | 113  | 32   |
| 031784  | 115  | 71-2 | 031902  | 135  | 10-2 | 033351  | 141  | 12   |
| 031786  | 105  | 38   | 031902  | 139  | 10-2 | 033372  | 141  | 15   |
| 031786  | 109  | 19   | 031904  | 135  | 11   | 033381  | 125  | 8    |
| 031786  | 109  | 25-2 | 031904  | 139  | 11   | 033530  | 129  | 48   |
| 031786  | 113  | 9    | 031911  | 125  | 7    | 033538  | 107  | 13   |
| 031786  | 119  | 2    | 031914  | 127  | 27   | 033636  | 109  | 23   |
| 031786  | 119  | 15   | 031914  | 131  | 10-1 | 033636  | 115  | 60   |
| 031786  | 123  | 31   | 031914  | 131  | 10-2 | 033636  | 117  | 1-1  |
| 031786  | 125  | 10   | 031914  | 131  | 13   | 033657  | 101  | 11   |
| 031786  | 127  | 17   | 031914  | 131  | 16   | 033657  | 105  | 7    |
| 031786  | 141  | 2    | 031915  | 129  | 40   | 033769  | 139  | 18   |
| 031786  | 141  | 5    | 031918  | 127  | 28   | 033943  | 144  | 17-4 |
| 031787  | 105  | 39   | 031918  | 131  | 5    | 034182  | 129  | 31   |
| 031787  | 109  | 20   | 031920  | 131  | 12-1 | 034213  | 141  | 17   |
| 031787  | 113  | 10   | 031920  | 131  | 12-2 | 034243  | 135  | 17-2 |
| 031787  | 123  | 30   | 031930  | 131  | 2    | 034397  | 109  | 36   |
| 031789  | 115  | 51   | 031930  | 131  | 18   | 034421  | 135  | 14   |
| 031789  | 127  | 2    | 031931  | 131  | 14   | 034421  | 139  | 14   |
| 031789  | 129  | 39   | 031932  | 131  | 15   | 034440  | 117  | 9    |
| 031801  | 105  | 36   | 031933  | 127  | 21   | 034457  | 117  | 1-2  |
| 031802  | 119  | 1    | 031935  | 113  | 6    | 034458  | 117  | 6    |
| 031802  | 119  | 16   | 031937  | 143  | 14-2 | 034459  | 117  | 11   |
| 031809  | 103  | 37   | 031940  | 143  | 6    | 034460  | 117  | 8    |
| 031810  | 101  | 25-1 | 031999  | 135  | 13   | 034461  | 117  | 12   |
| 031810  | 101  | 28-1 | 031999  | 139  | 13   | 034462  | 117  | 4    |
| 031810  | 111  | 46-1 | 031999  | 139  | 21-2 | 034463  | 117  | 13   |
| 031824  | 111  | 44   | 032493  | 133  | 10   | 034464  | 117  | 2    |
| 031824  | 113  | 40   | 032498  | 133  | 11   | 034466  | 117  | 1-3  |
| 031825  | 103  | 41-1 | 032499  | 133  | 12   | 034485  | 135  | 6-1  |

| PART NO | PAGE | REF   | PART NO | PAGE | REF   | PART NO | PAGE | REF  |
|---------|------|-------|---------|------|-------|---------|------|------|
| 034485  | 139  | 6     | 036538  | 135  | 12    | 036961  | 125  | 36   |
| 034497  | 113  | 41    | 036538  | 139  | 12    | 036962  | 101  | 35   |
| 034552  | 125  | 1     | 036539  | 135  | 1     | 036963  | 101  | 5    |
| 034552  | 127  | 1     | 036539  | 139  | 1     | 036964  | 121  | 4-1  |
| 034589  | 123  | 50    | 036541  | 113  | 3     | 036965  | 121  | 4-2  |
| 034589  | 125  | 15    | 036563  | 125  | 25    | 036966  | 121  | 4-4  |
| 034589  | 127  | 4     | 036616  | 113  | 1     | 036967  | 105  | 42   |
| 034589  | 127  | 13    | 036622  | 113  | 42    | 036968  | 109  | 32   |
| 034593  | 129  | 57    | 036624  | 143  | 16    | 036970  | 109  | 6    |
| 034620  | 105  | 21    | 036819  | 103  | 44    | 036978  | 109  | 12   |
| 034642  | 105  | 26    | 036868  | 123  | 63    | 036979  | 105  | 32   |
| 034642  | 113  | 38    | 036914  | 107  | 4     | 036980  | 105  | 24   |
| 034669  | 125  | 27    | 036915  | 111  | 42    | 036981  | 101  | 27   |
| 034833  | 127  | 10    | 036916  | 103  | 38    | 036982  | 109  | 27   |
| 034857  | 121  | 10    | 036917  | 101  | 6     | 036986  | 105  | 29   |
| 034936  | 144  | 16    | 036918  | 101  | 24    | 036987  | 101  | 17   |
| 034999  | 135  | 6-2   | 036919  | 105  | 11    | 036988  | 103  | 39   |
| 035109  | 113  | 28    | 036921  | 121  | 16    | 036989  | 119  | 14   |
| 035109  | 125  | 35    | 036922  | 121  | 18    | 036993  | 107  | 10   |
| 035273  | 129  | 50    | 036923  | 121  | 28    | 036994  | 107  | 9    |
| 035411  | 113  | 5     | 036924  | 127  | 14    | 036995  | 109  | 14   |
| 035455  | 131  | 20    | 036925  | 121  | 21- 1 | 036996  | 109  | 9    |
| 035711  | 125  | 5     | 036926  | 121  | 21- 2 | 036997  | 101  | 29   |
| 035720  | 143  | 14-1  | 036927  | 121  | 21- 3 | 037004  | 101  | 30   |
| 035825  | 135  | 9-2   | 036928  | 121  | 21- 4 | 037005  | 101  | 32   |
| 035825  | 139  | 9-2   | 036929  | 121  | 21- 5 | 037006  | 109  | 8    |
| 035927  | 127  | 16    | 036930  | 121  | 21- 6 | 037007  | 105  | 12   |
| 035928  | 127  | 15    | 036931  | 121  | 21- 7 | 037008  | 105  | 23   |
| 035940  | 131  | 7-1   | 036932  | 121  | 21- 8 | 037009  | 121  | 4-3  |
| 035944  | 131  | 19    | 036933  | 121  | 21- 9 | 037010  | 121  | 4-5  |
| 035969  | 129  | 38    | 036934  | 121  | 21-10 | 037011  | 121  | 4-6  |
| 035970  | 129  | 37-2  | 036935  | 121  | 25    | 037012  | 121  | 4-7  |
| 035971  | 127  | 20    | 036936  | 105  | 15    | 037013  | 121  | 4-8  |
| 035972  | 129  | 36    | 036937  | 115  | 74    | 037014  | 121  | 4-9  |
| 035973  | 127  | 30- 8 | 036938  | 111  | 47    | 037015  | 113  | 34   |
| 035974  | 127  | 22    | 036939  | 119  | 36    | 037016  | 113  | 29   |
| 035975  | 127  | 29-2  | 036940  | 101  | 9     | 037017  | 109  | 17   |
| 035975  | 131  | 6-2   | 036941  | 119  | 33-2  | 037018  | 101  | 34-1 |
| 035978  | 131  | 4-1   | 036942  | 119  | 10    | 037019  | 109  | 28   |
| 035978  | 131  | 4-3   | 036943  | 101  | 21    | 037021  | 119  | 35   |
| 035979  | 131  | 8-1   | 036945  | 101  | 7     | 037022  | 119  | 34   |
| 035979  | 131  | 8-2   | 036946  | 109  | 26    | 037024  | 119  | 12   |
| 035980  | 131  | 17    | 036947  | 115  | 73    | 037025  | 109  | 13   |
| 035981  | 131  | 1-1   | 036948  | 109  | 4     | 037026  | 105  | 27   |
| 035981  | 131  | 1-3   | 036948  | 109  | 10    | 037027  | 105  | 34   |
| 035982  | 129  | 37-1  | 036948  | 109  | 15    | 037028  | 125  | 37   |
| 035983  | 127  | 30- 5 | 036949  | 109  | 1     | 037029  | 105  | 33   |
| 035984  | 127  | 29-1  | 036950  | 109  | 5     | 037030  | 111  | 38   |
| 035984  | 131  | 6-1   | 036951  | 121  | 13    | 037043  | 113  | 25   |
| 036050  | 127  | 8     | 036952  | 121  | 14    | 037045  | 101  | 26   |
| 036069  | 143  | 29    | 036953  | 121  | 15    | 037046  | 105  | 19   |
| 036192  | 135  | 2     | 036954  | 105  | 10    | 037050  | 111  | 48   |
| 036192  | 139  | 2     | 036955  | 113  | 11    | 037051  | 111  | 49   |
| 036218  | 125  | 2     | 036956  | 113  | 24    | 037053  | 105  | 37   |
| 036228  | 113  | 23    | 036957  | 113  | 33    | 037056  | 105  | 1    |
| 036232  | 135  | 15-2  | 036958  | 105  | 3     | 037057  | 113  | 30   |
| 036425  | 113  | 2     | 036959  | 105  | 4     | 037062  | 101  | 34-2 |
| 036493  | 103  | 42    | 036960  | 105  | 44    | 037063  | 101  | 34-3 |

| PART NO | PAGE | REF   | PART NO | PAGE | REF  | PART NO | PAGE | REF   |
|---------|------|-------|---------|------|------|---------|------|-------|
| 037066  | 107  | 5-2   | 037780  | 141  | 8    | 038454  | 105  | 5-1   |
| 037067  | 107  | 5-3   | 037816  | 143  | 25-2 | 038455  | 119  | 31-1  |
| 037068  | 103  | 36    | 037833  | 137  | 33-1 | 038456  | 107  | 2-1   |
| 037069  | 107  | 5-1   | 037833  | 137  | 33-2 | 038457  | 119  | 33-1  |
| 037070  | 111  | 50    | 037833  | 139  | 23   | 038458  | 119  | 24-1  |
| 037072  | 101  | 20    | 038042  | 135  | 24-4 | 038459  | 121  | 1-1   |
| 037073  | 101  | 19    | 038042  | 139  | 21-1 | 038499  | 101  | 1-1   |
| 037075  | 109  | 2     | 038064  | 115  | 70   | 038499  | 101  | 1-2   |
| 037078  | 119  | 28    | 038070  | 141  | 4    | 038523  | 133  | 8     |
| 037079  | 119  | 25    | 038073  | 141  | 16   | 038621  | 133  | 20    |
| 037080  | 119  | 27    | 038074  | 125  | 33   | 038622  | 133  | 19    |
| 037086  | 109  | 29    | 038076  | 115  | 61   | 038640  | 133  | 15    |
| 037087  | 105  | 13    | 038079  | 113  | 16   | 038640  | 133  | 16-1  |
| 037090  | 119  | 9     | 038080  | 115  | 57   | 038645  | 133  | 13    |
| 037091  | 121  | 19    | 038084  | 123  | 29   | 038673  | 144  | 10    |
| 037092  | 119  | 26    | 038085  | 123  | 41   | 038677  | 144  | 9     |
| 037095  | 103  | 40    | 038086  | 125  | 14   | 038678  | 117  | 14    |
| 037099  | 121  | 17    | 038087  | 125  | 9    | 038679  | 101  | 15    |
| 037100  | 125  | 26    | 038088  | 129  | 32   | 038680  | 119  | 17    |
| 037104  | 123  | 61    | 038112  | 129  | 47-1 | 039082  | 133  | 4     |
| 037105  | 121  | 6     | 038113  | 129  | 47-2 | 039275  | 123  | 44    |
| 037106  | 121  | 22    | 038114  | 113  | 4    | 039550  | 113  | 22    |
| 037107  | 121  | 23    | 038118  | 123  | 42   | 039550  | 125  | 34    |
| 037108  | 121  | 24    | 038122  | 123  | 57   | 039556  | 131  | 4-4   |
| 037109  | 119  | 24-2  | 038123  | 125  | 38   | 039928  | 137  | 28    |
| 037109  | 121  | 27    | 038123  | 135  | 15-1 | 039928  | 139  | 26-1  |
| 037110  | 123  | 60    | 038124  | 144  | 13-1 | 039929  | 137  | 29    |
| 037111  | 123  | 62    | 038125  | 133  | 14   | 039929  | 139  | 26-2  |
| 037112  | 121  | 20    | 038126  | 133  | 3    | 040138  | 131  | 7-4   |
| 037113  | 121  | 26    | 038128  | 141  | 10   | 040195  | 139  | 16-3  |
| 037114  | 101  | 33    | 038129  | 141  | 20   | 040477  | 143  | 15    |
| 037121  | 144  | 5     | 038130  | 141  | 19   | 040892  | 107  | 2-2   |
| 037162  | 113  | 26    | 038147  | 113  | 47   | 040893  | 107  | 2-3   |
| 037163  | 123  | 64    | 038148  | 129  | 56-1 | 040926  | 107  | 8     |
| 037167  | 107  | 11    | 038149  | 129  | 56-2 | 041081  | 137  | 35    |
| 037168  | 107  | 12    | 038178  | 135  | 17-1 | 041081  | 139  | 29    |
| 037187  | 123  | 58    | 038202  | 127  | 5-1  | 041130  | 115  | 53    |
| 037191  | 105  | 20    | 038236  | 127  | 26   | 041199  | 131  | 4-2   |
| 037312  | 113  | 7     | 038258  | 143  | 22   | 041216  | 127  | 30-11 |
| 037323  | 109  | 34    | 038263  | 143  | 2    | 041218  | 127  | 30-6  |
| 037323  | 125  | 30-1  | 038289  | 143  | 30   | 041250  | 105  | 45    |
| 037323  | 125  | 30-2  | 038328  | 143  | 19   | 041487  | 105  | 16-2  |
| 037383  | 113  | 18    | 038348  | 131  | 7-2  | 041700  | 143  | 25-1  |
| 037393  | 103  | 43    | 038349  | 131  | 7-3  | 041744  | 143  | 24    |
| 037417  | 143  | 13    | 038350  | 144  | 1    | 041745  | 143  | 26    |
| 037429  | 127  | 30-1  | 038351  | 144  | 2-1  | 042307  | 144  | 7-2   |
| 037438  | 127  | 30-3  | 038351  | 144  | 2-2  | 042329  | 133  | 7     |
| 037508  | 109  | 35    | 038352  | 144  | 3-1  | 042330  | 133  | 6     |
| 037508  | 125  | 28    | 038353  | 144  | 4-1  | 042333  | 133  | 16-2  |
| 037601  | 135  | 5     | 038383  | 143  | 9    | 042400  | 101  | 1-3   |
| 037601  | 139  | 5     | 038399  | 121  | 7    | 042704  | 133  | 9-2   |
| 037603  | 135  | 4     | 038401  | 121  | 5    | 042705  | 133  | 9-1   |
| 037603  | 139  | 4     | 038429  | 121  | 11   | 042719  | 133  | 21    |
| 037605  | 135  | 3     | 038447  | 107  | 3-1  | 042871  | 144  | 11    |
| 037605  | 139  | 3     | 038448  | 105  | 2-1  | 042893  | 135  | 9-1   |
| 037721  | 127  | 30-10 | 038449  | 107  | 1-1  | 042893  | 139  | 9-1   |
| 037722  | 127  | 30-13 | 038451  | 107  | 1-2  | 043092  | 127  | 30-2  |
| 037779  | 141  | 9     | 038452  | 107  | 1-3  | 043095  | 127  | 30-4  |

| PART NO | PAGE | REF   |
|---------|------|-------|
| 043096  | 131  | 1-2   |
| 043096  | 131  | 1-4   |
| 043098  | 127  | 30-12 |
| 043099  | 127  | 30-14 |
| 043101  | 127  | 30- 7 |
| 043102  | 127  | 30- 9 |
| 043422  | 125  | 13    |
| 043550  | 105  | 2-2   |
| 043551  | 107  | 1-4   |
| 043553  | 107  | 1-5   |
| 043554  | 107  | 1-6   |
| 043555  | 121  | 1-2   |
| 043556  | 107  | 2-4   |
| 043557  | 107  | 2-5   |
| 043558  | 107  | 2-6   |
| 043559  | 105  | 5-2   |
| 043560  | 144  | 3-2   |
| 043561  | 144  | 4-2   |
| 043562  | 144  | 2-3   |
| 043649  | 131  | 3     |
| 043746  | 139  | 27    |
| 043747  | 139  | 15-2  |
| 043747  | 139  | 19    |
| 043783  | 144  | 13-2  |
| 043795  | 139  | 16-1  |
| 043818  | 139  | 28    |
| 043840  | 139  | 16-2  |
| 043841  | 139  | 15-1  |
| 043976  | 107  | 3-2   |
| 043977  | 119  | 23    |
| 043978  | 119  | 20    |
| 043979  | 119  | 31-2  |
| 043980  | 119  | 38    |
| 043981  | 119  | 39    |
| 043982  | 119  | 5     |
| 043983  | 119  | 19    |
| 043984  | 119  | 22    |
| 043985  | 119  | 6     |
| 043986  | 119  | 4     |
| 043987  | 119  | 8     |
| 043988  | 119  | 3     |
| 043989  | 119  | 37    |
| 050234  | 135  | 23-2  |
| 050234  | 137  | 31-3  |
| 050234  | 139  | 26-6  |
| 200125  | 137  | 34-1  |
| 200125  | 137  | 34-2  |
| 200125  | 139  | 24    |

)

)

)