

WESTERBEKE SUPERSESSION LISTING

1

Old Number	Description	New Number
11002	SPACER,CRANKSHAFT PULLEY	11857
11009	BASE,AIR FILTER 4-107	NLA
11020	PUMP,SEA WATER	16423
11058	NAMEPLATE,GEN CTL ON-OFF-REMOT	NLA
11059	NAMEPLATE,CRANKING LIMITER RES	NLA
11060	NAMEPLATE,PREHEAT	NLA
11069	NAMEPLATE,DYNAMONITOR	NLA
11086	WASHER,FAN JC GENERATOR	NLA
11095	PANEL,PLATE	NLA
11100	COVER,STARTER PINION	NLA
11115	BRACKET,EXCHANGER TO BLOCK	NLA
11120	PUMP,SEA WATER	16685
11121	STUD,OIL FILTER MOUNT-WB	NLA
11125	SPACER	33064
11127	ADAPTER,ADJUSTING STRAP TO GEN	NLA
11131	ADAPTER	NLA
11135	CAP,EXCHANGER	13969 & 13955
11137	STUD 3/8NCx3-5/8	NLA
11157	STUD 3/8NCx2-1/2	NLA
11166	NAMEPLATE	NLA
11167	NAMEPLATE	NLA
11192	TRANSMISSION 1.3:1 SSL	NLA
11198	BRACKET,SUPPORT	NLA
11201	PULLEY,FRESH PUMP W40LS	NLA
11205	SUPPORT,ALTERNATOR 4-107	NLA
11208	SEAL SS1A	NLA
11209	CELL,SALINITY SS1A	NLA
11245	NAMEPLATE,SS1 SALINITY ALARM	NLA
11267	BRACKET,REGULATOR W40LS	NLA
11285	NIPPLE,HOSE 1 NPT	NLA
11286	HARNESS,PANEL 15746	NLA
11287	HARNESS,MARINE 4-107LS	NLA
11297	TEE	11651
11298	LINE,FUEL	12150
11300	LINE,OIL	13127
11301	LINE.OIL	14078
11302	LINE.OIL	14079
11303	LINE.OIL	14080
11304	COOLER,OIL	12985
11315	GEAR,RING 4-60	NLA
11317	SWITCH,MICRO 5A,250VAC	NLA
11318	VANE,AIR SWITCH	NLA
11319	PUMP SS1A	NLA
11321	CONNECTOR	NLA
11328	SEAL SS1A	NLA
11330	NUT	NLA
11339	TUBING,POLYETHYLENE 3/8OD,1/4I	NLA
11340	HOSE SS1A	NLA
11344	SCREW	NLA
11345	LOCKWASHER	NLA
11346	SCREW	NLA
11347	SCREW	NLA
11348	SCREW	NLA
11349	FAN SS1A	NLA
11350	FAN SS1A	NLA
11351	FAN SS1A	NLA
11352	FAN SS1A	NLA
11353	PUMP,SEA WATER	38445

WESTERBEKE SUPERSESSION LISTING

2

Old Number	Description	New Number
11356	PULLEY,AK 3.75"OD 5/8" BORE	NLA
11370	PULLEY,AK 2.70"OD 1/2" BORE	NLA
11373	PULLEY,AK 4.25"OD 5/8" BORE	NLA
11378	EXCHANGER SS1A	NLA
11383	SWITCH,PRESSURE	37323
11396	SWITCH,WATER TEMP	13382
11418	IMPELLER	use impeller kit
11420	SEAL	NLA
11423	SLINGER	NLA
11424	GASKET,SS1 HOT SEA PUMP	NLA
11426	SWITCH,TOGGLE	NLA
11427	SWITCH,TOGGLE,SPST,ON-ON	NLA
11429	HOLDER,LAMP RED T3-1/4MBB	NLA
11430	HOLDER,LAMP WHITE T3-1/4MBB	NLA
11433	BLOCK,TERMINAL 14 POS 30A 2ROW	NLA
11434	MARKER,TERMINAL BLOCK 11433	NLA
11454	HOLDER,FUSE .25x1.25 30A 250V	NLA
11456	LAMP	NLA
11457	FUSE 5A SLO-BLO	NLA
11460	DIODE 1N4721	NLA
11465	RESISTOR 10 OHM	NLA
11466	RESISTOR 3 OHM	NLA
11478	BLOCK,TERMINAL 5 POS 30A 2ROW	NLA
11479	MARKER,TERMINAL BLOCK 11478	NLA
11485	MOTOR,SS1A PUMPS	NLA
11487	ENGINE 108	30870
11488	MOTOR,STARTER 12VDC	17950
11490	SPRING,GOVERNOR	NLA
11491	NAMEPLATE,CAV INJECTION PUMP	NLA
11500	HOSE	11501
11502	ELBOW 1" CxC 90 COPPER WROT	NLA
11506	HOSE	11501
11507	HOSE	11501
11508	RADIATOR	NLA
11509	FAN	NLA
11510	SPACER,FAN	NLA
11511	ELEMENT,AIR RAD COOL 107	NLA
11512	MANIFOLD,EXHAUST DRY W40	NLA
11513	FLANGE,MANIFOLD	NLA
11514	GASKET,EXH MANIFOLD OUTLET 107	NLA
11518	COOLER,OIL	24581
11520	GENERATOR JC 10KW 1PH	NLA
11521	GENERATOR JC 12.5KW 1PH	NLA
11522	GENERATOR JC 15KW 1PH	34761
11523	ISOLATOR	21529
11524	ISOLATOR	NLA
11526	SWITCH,ROTARY	32009
11527	SWITCH,ROTARY	32010
11528	ENCLOSURE,SHORE SWITCH	NLA
11529	SWITCH	32133
11531	SWITCH,TOGGLE	NLA
11533	METER,HOUR	12892
11534	ALTERNATOR 12VDC, 55A UNGND	NLA
11545	METER,WATER TEMPERATURE	37601
11546	ALTERNATOR 12VDC,55A	24684
11553	GUARD,AIR DUCT YD HOUSING	NLA
11554	NUT	NLA
11555	SEAL,DIPSTICK	NLA

Old Number	Description	New Number
11556	MOTOR,STARTER	16762
11560	HOLDER,BRUSH	NLA
11561	COVER,ALTERNATOR	NLA
11562	INSULATOR,ALTERNATOR UNGND	NLA
11563	BOLT	NLA
11564	INSULATOR,ALTERNATOR UNGND	NLA
11565	SLEEVE	NLA
11566	SLEEVE,INSULATING 55A ALTNR	NLA
11567	WASHER,FLAT 1/4 NYLON 1/2OD	NLA
11568	BUSHING,INSUL FEMALE 0.500 DIA	NLA
11569	BUSHING,INSUL MALE 0.500 DIA	NLA
11570	BUSHING,INSUL FEMALE 1.000 DIA	NLA
11571	BUSHING,INSUL MALE 1.000 DIA	NLA
11574	BLOCK,TERMINAL 3 POS 30A 2ROW	NLA
11575	MARKER,TERMINAL BLOCK 11574	NLA
11577	RELAY,CRANKING LIMITER	NLA
11578	BLOCK,TERMINAL 2 POS 30A 2ROW	NLA
11579	RELAY	NLA
11580	MARKER,TERMINAL BLOCK 11586	NLA
11584	BUSHING,INSUL FEMALE 0.750 DIA	NLA
11585	BUSHING,INSUL MALE 0.750 DIA	NLA
11586	BLOCK,TERMINAL 12 POS 30A 2ROW	NLA
11588	RESISTOR 25 OHM,25W	NLA
11598	FILTER,FUEL	32974
11604	SOCKET,OCTAL	NLA
11610	REACTOR	NLA
11613	FILTER,OIL NAVY WB	14090
11617	MOTOR	38237
11619	DAMPER RB GEAR	NLA
11622	TRANSMISSION 1:1 SA1	NLA
11624	TRANSMISSION 1.5:1 SA1	NLA
11625	TRANSMISSION 2:1 SA1	NLA
11626	TRANSMISSION 2.5:1 SA1	NLA
11632	TRANSMISSION 2:1 HYD 71	NLA
11633	TRANSMISSION 2.5:1 HYD 71	NLA
11634	TRANSMISSION 3:1 HYD 71	NLA
11635	TRANSMISSION	37297
11636	TRANSMISSION 3:1 HYD P25L	24717
11637	TRANSMISSION 1.5:1 HYD P22L	24714
11638	TRANSMISSION 2:1 SA1-120	NLA
11639	TRANSMISSION 1:1 HYD P21L	24713
11640	TRANSMISSION 2:1 HYD P23L	24715
11641	TRANSMISSION 2.5:1 HYD P24L	24716
11646	V DRIVE RV10S 1.7:1	NLA
11647	V DRIVE RV10S 2:1	NLA
11657	COOLER,OIL	36650
11658	PUMP,SEA WATER BRONZE GEAR	NLA
11661	ALTERNATOR 12VDC, 60A	NLA
11662	FAN	NLA
11663	PULLEY	NLA
11664	REGULATOR	NLA
11666	MOTOR,STARTER 24VDC WB	NLA
11667	GENERATOR 24VDC	NLA
11669	REGULATOR 24VDC	21611
11671	ALTERNATOR 12VDC, 85A	NLA
11673	REGULATOR	11682
11674	PULLEY,ALTNR 3.25 NOM 2GR 1/2B	NLA
11676	RESISTOR 75 OHM	NLA

WESTERBEKE SUPERSESSION LISTING

4

Old Number	Description	New Number
11677	ALTERNATOR 12VDC,120A - NLA	NLA
11678	REGULATOR	11682
11680	BELT,COG	NLA
11682	REGULATOR	NLA
11683	ALTERNATOR 12VDC,100A - NLA	NLA
11684	REGULATOR	NLA
11685	PULLEY	NLA
11688	STARTING AID 107SPRA	NLA
11692	KIT,LAMP/HOLDERS 11693 PANEL	NLA
11693	PANEL,INSTRUMENT*SKIPPER NOT W	NLA
11697	GASKET	12688
11698	THERMOSTAT	24688
11701	INJECTOR	35374
11707	FILTER,FUEL	11614
11714	SWITCH	NLA
11721	TRANSMISSION 2:1 DROPBOX	34407
11725	COUPLING .875IN BORE SA1	23661
11726	COUPLING 1IN BORE SA1	23662
11727	COUPLING 1.125IN BORE SA1	23663
11728	COUPLING 1.250IN BORE SA1	23664
11729	COUPLING 1.375IN BORE SAOD	23665
11735	COUPLING .875IN BORE P21-P33	23668
11736	COUPLING 1IN BORE P21-P33	23669
11737	COUPLING 1.125IN BORE P21-33	23670
11738	COUPLING 1.250IN BORE P21-P33	23671
11739	COUPLING 1.375IN BORE P21-33	23672
11744	RELAY	NLA
11757	TAPE	NLA
11758	TAPE	NLA
11759	TAPE	NLA
11760	TAPE	NLA
11761	TAPE	NLA
11766	ENGINE 4-236	NLA
11780	NIPPLE	11516
11784	FILTER,FUEL	32974
11790	SWITCH,OVERSPEED	NLA
11803	FAN	NLA
11804	PULLEY,ALTNR	NLA
11805	SPACER,ALTERNATOR L-N	NLA
11806	SPACER,ALTERNATOR L-N	NLA
11808	LEVER,SHIFT	NLA
11814	CLAMP,HOSE	11386
11815	ALTERNATOR 12VDC, 65A	NLA
11816	BLOCK	NLA
11817	NAMEPLATE,GEN CTL ON-OFF	NLA
11820	VANE,AIR SWITCH	13845
11822	TACH CABLE 4 FOOT W40	NLA
11824	TACH CABLE 6 FOOT W40	NLA
11826	TACH CABLE 8 FOOT W40	NLA
11828	TACH CABLE 10 FOOT W40	NLA
11829	PLATE,FUEL SOLENOID END	NLA
11836	ALTERNATOR 32VDC, 70A	NLA
11837	REGULATOR	NLA
11838	RESISTOR	NLA
11845	EXCHANGER,HEAT 4-91	NLA
11847	PUMP	NLA
11848	BUSHING,INSUL FEMALE 1.500 DIA	NLA
11849	BUSHING,INSUL MALE 1.500 DIA	NLA

Old Number	Description	New Number
11853	TRANSMISSION 2:1 SSL	NLA
11856	ENGINE 1.5L BMC	NLA
11858	GASKET,BACKPLATE 4-91	30130
11860	GASKET,THERMOSTAT	14501
11863	STUD	11263
11865	PLUG	NLA
11866	SKID	32060
11867	COMPRESSOR KIT W40 SIDE FIELD	NLA
11868	KEY	NLA
11870	BRACKET,COMPRESSOR SUPPORT W40	NLA
11871	SEAL	NLA
11886	SUMP,OIL W30	NLA
11891	COIL,FUEL SOLENOID	NLA
11898	V DRIVE RV10S 1:1	NLA
11899	V DRIVE RV10S 1.3:1	NLA
11900	V DRIVE RV20D-W 1:1	NLA
11901	V DRIVE RV20D-W 1.5:1	NLA
11902	V DRIVE RV20D-W 2:1	NLA
11903	V DRIVE RV20D-W 3:1	NLA
11905	PLUNGER,FUEL SOLENOID	NLA
11920	HOSE,FUEL	23909
11930	STUD 5/16NCx1-9/16 BRONZE	NLA
11931	METER,AMMETER VDO	NLA
11936	BANJO,FUEL FILTER	NLA
11941	BANJO	NLA
11943	WASHER,BANJO M 8	30289
11946	WASHER	12522
11950	BUSHING,SAO SHAFT SUPPORT W30	NLA
11952	SOLENOID	21824
11956	SWITCH,KEY	24777
11961	COUPLING 1IN BORE 5" WAR	23686
11962	COUPLING 1.125IN BORE 5" WAR	23687
11963	COUPLING 1.25IN BORE 5" WAR	23688
11964	COUPLING 1.375IN BORE 5" WAR	23689
11970	METER,AMMETER S-W SKIPPER PNL	NLA
11971	SWITCH,WATER TEMP	39550 & 13443
11974	TUBE,FUEL SOLENOID PLUNGER	NLA
11976	SCREW,FUEL SOLENOID PLUNGER	NLA
11980	BRACKET,DIPSTICK SUPPORT	24117
11987	COOLER,OIL	NLA
11989	DAMPER	11618
11994	COUPLING .75IN BORE P21-P33	NLA
11998	WASHER	12522
11999	BOLT,BANJO	12350
12001	FAN,GENERATOR	NLA
12004	PLATE,DRIVE DISC YD-JC GENSET	NLA
12006	MOUNT,REAR RIGHT	13132
12014	MOUNT,REAR RIGHT HIGH 4-107	NLA
12016	BRACKET,ALTERNATOR	12147
12025	COVER,AIR CLEANER	NLA
12028	GUARD,FAN-RADIATOR COOL	NLA
12038	PULLEY 7x2xA W40	NLA
12060	BRACKET,ALTNR 51A W40	NLA
12061	MOUNT,REAR LEFT W40 RAWSON	NLA
12068	EYE,LIFTING REAR 10-15KW	NLA
12070	HUB,GENERATOR DRIVE	NLA
12089	PULLEY	NLA
12095	PULLEY	11709

WESTERBEKE SUPERSESSION LISTING

6

Old Number	Description	New Number
12096	PULLEY 6x3xB W40	NLA
12115	STRAP,GENERATOR	NLA
12120	ADAPTER,LUBE OIL	13955
12147	BRACKET,ALTRN 40A L-N 4-107	NLA
12162	GASKET SS1A	NLA
12167	BASE,GENSET 20KW JC	NLA
12175	CHASSIS,PANEL SS1A	NLA
12202	FLANGE,AIR	NLA
12215	ELBOW	NLA
12229	STRAP,ALTRN ADJUST 7.875 CC	NLA
12230	PULLEY 6x9xA W40	NLA
12236	PLATE	NLA
12238	COVER	NLA
12240	ELBOW	NLA
12241	FLANGE,MANIFOLD REAR	NLA
12244	FRAME,FUEL SOLENOID	NLA
12247	MOUNT,LEFT REAR	13124
12251	PULLEY 5.75x2xA W40	NLA
12254	ADAPTER,LUBE OIL LINES 4-154	NLA
12256	GASKET	NLA
12257	GASKET	NLA
12258	GASKET	NLA
12260	GASKET	NLA
12261	BRACKET,REGULATOR	12976
12268	NUT	31760
12269	NUT	37156
12271	EXCHANGER,HEAT 4-236	NLA
12273	BRACKET,SOLENOID MOUNT	21824
12275	MOUNT,REAR 4-60	NLA
12281	TUBE,DIPSTICK	13418 & 12274
12287	ELEMENT,AIR	NLA
12288	TUBING	NLA
12293	TRANSMISSION 1:1 SA0	NLA
12294	TRANSMISSION 2:1 SA0	NLA
12295	COUPLING .75IN BORE SAOD	23654
12296	COUPLING .875IN BORE SAOD	23655
12297	COUPLING 1IN BORE SAOD	23656
12298	COUPLING 1.125IN BORE SAOD	23657
12299	COUPLING .75IN BORE SA1	23660
12306	NUT	NLA
12307	COVER,ROCKER 4-91	NLA
12317	PANEL,INSTRUMENT 4-60 NOT WIRE	33866
12321	PANEL,GENSET CONTROL,TILTING	NLA
12322	SPACER	NLA
12325	BOX,GENSET CTL PNL TILTING	NLA
12327	PETCOCK	13970
12330	FILTER,OIL	32057
12332	BEARING,HUB 12632	NLA
12333	ROCKER	NLA
12339	BLOCK,BARE 107	NLA
12340	HEAD,CYLINDER 107 KIT	NLA
12344	ROD,CONNECTING 107	NLA
12356	CAPSCREW 5/16NFx2-1/2	NLA
12372	CONNECTOR,ROCKER OIL FEED	NLA
12373	BEARING SET,MAIN .030 W40	NLA
12374	CONNECTOR	11938
12399	GASKET	20021
12400	GASKET,HEAD 107U	NLA

WESTERBEKE SUPERSESSION LISTING

7

Old Number	Description	New Number
12401	GASKET	11653
12428	NUT	31766
12433	LOCKNUT	31761
12444	PIPE	NLA
12449	PLUG 3/4 NPT	207782
12453	CAPSCREW 5/16NCx1/2	31551
12455	PLUG,EXPANSION CUP 1.010 STEEL	NLA
12469	BOLT,MAIN BEARING CAP W40	NLA
12471	CAPSCREW	31527
12474	CAPSCREW 5/16NFx7/8	31579
12481	CAPSCREW 3/8NFx2 FULL THREAD	NLA
12509	VALVE,INTAKE FR 107U7101102	12511
12523	WASHER,FELT	NLA
12525	WASHER	NLA
12533	WASHER	NLA
12534	WASHER	19261
12539	WASHER,ROCKER SHAFT W40	NLA
12540	WASHER	NLA
12543	BOLT	31579
12544	TABWASHER	14720
12559	FLYWHEEL	24064
12569	BODY	11700
12571	FILTER,FUEL	19509
12577	IMPELLER,FRESH WATER PUMP	NLA
12593	SEAL	NLA
12594	BUSHING,CONNECTING ROD 107	NLA
12596	GEAR,RING	13832
12618	COVER,STARTER PINION	NLA
12619	WASHER,TACH DRIVE CAP W40	NLA
12625	PLATE,CAMSHAFT GEAR W40	NLA
12654	PLATE,CAMSHAFT THRUST	NLA
12656	PLATE,FRONT W40	NLA
12660	GASKET	12659
12680	SUMP,OIL	NLA
12681	COVER,ROCKER	39289 & 14709
12682	INSERT,COMBUSTION	NLA
12687	BRACKET,OIL FILTER	14090
12695	COVER	NLA
12700	COVER	NLA
12702	NAMEPLATE,GEN CTL ON-OFF-REMOT	NLA
12704	MOTOR SS1A	NLA
12732	KIT W40LB	NLA
12737	PANEL,INSTRUMENT 4-107	NLA
12738	RING SET STD 1 CYL 4-99	NLA
12794	PANEL,GENSET JC-ALT OUT OR AIR	NLA
12795	PANEL,REMOTE CTL JC GENSET	NLA
12799	DYNAMONITOR	NLA
12800	DYNAMONITOR	NLA
12801	DYNAMONITOR	NLA
12802	DYNAMONITOR	NLA
12803	SWITCH,SHORE	32009
12804	SWITCH,SHORE	32133
12805	SWITCH,SHORE	32010
12810	PANEL,REMOTE-AUTO WPDS10-15	NLA
12813	PANEL,CONTROL SS1A	NLA
12856	TRANSMISSION 2:1 VOLVO RB	NLA
12857	DISTILLER SS1A	NLA
12860	DISTILLER SS1A	NLA

WESTERBEKE SUPERSESSION LISTING

8

Old Number	Description	New Number
12871	ALTERNATOR 12VDC,105A	NLA
12883	METER,TACHOMETER,SKIPPER PANEL	NLA
12884	SWITCH,WATER TEMP	39550 & 13443
12885	PANEL,PLATE-MARINE INST NO KEY	NLA
12891	RESISTOR 4 OHM,25W	NLA
12893	RELAY,TIME DELAY 12VDC 5A,NO	NLA
12894	RELAY,TIME DELAY 12DVC 5A,NC	NLA
12901	PIN,PISTON 4-99 TO 7034969 7/8	NLA
12902	PIN	NLA
12904	LINER,CYLINDER 4-99	NLA
12906	RING SET OS 1 CYL 4-107	NLA
12907	RING	12905
12909	PUMP,WATER	NLA
12911	SEAL	18167
12912	SEAL	14774
12913	SHAFT	NLA
12914	IMPELLER	11764
12916	CAM,WATER PUMP	NLA
12917	SCREW	299895
12922	SEAT	14774
12923	SEAL	14774
12925	BAND,MOUNT UPPER JC SERIES	NLA
12932	KIT,WATER PUMP 12935 REBUILD	NLA
12934	CONNECTOR,BOX 3/4 DIA	NLA
12937	PANEL,GENSET CONTROL	NLA
12938	BRACKER,OIL FILTER	NLA
12940	BOX,JUNCTION WPDS	NLA
12941	COVER,JUNCTION BOX 12940	NLA
12945	O-RING	NLA
12948	FLEXIBLE COUPLING ASSY .75IN	NLA
12949	FLEXIBLE COUPLING ASSY .87IN	NLA
12950	FLEXIBLE COUPLING ASSY 1.0IN	NLA
12951	FLEXIBLE COUPLING ASSY 1.125IN	NLA
12952	FLEXIBLE COUPLING ASSY 1.25IN	NLA
12960	HARNESS,GENSET WPDS-10-15KW	NLA
12961	HOLDER,LAMP VDO GAUGES	NLA
12967	NUT,TILTING CONTROL PANEL	NLA
12968	KNOB,TILTING CONTROL PANEL	NLA
12969	GROMMET	38434
12973	GROMMET	NLA
12974	CLAMP	NLA
12976	BRACKET,REGULATOR,BREAKER	NLA
12988	BAND,MOUNT UPPER JC SERIES	NLA
12991	ENGINE 4-60 BMC	NLA
12992	HARNESS,MARINE 4-107	NLA
13003	MOUNT	13143
13014	HOUSING,PINION HYD STARTER	NLA
13021	MOUNT,REAR LEFT MORGAN	NLA
13051	BRACKET,REMOTE LUBE OIL FILTER	NLA
13052	EXCHANGER,HEAT 4-107 ORIGINAL	NLA
13053	EXCHANGER,HEAT WPDS DRIP PAN	NLA
13055	MOUNT,REAR W80-120 HYD	NLA
13062	SPACER,STARTER MOTOR WPDS10-15	NLA
13064	BRACKET,SOLENOID	NLA
13065	LINK,FUEL SOLENOID	NLA
13076	BRACKET,STARTING AID	NLA
13082	COVER	NLA
13085	BOX,GENSET REMOTE CTL	NLA

WESTERBEKE SUPERSESSION LISTING

9

Old Number	Description	New Number
13100	MOUNT,FRONT LEFT WB	NLA
13109	HOUSING	12985
13124	MOUNT,REAR LEFT 4-107	NLA
13136	MOUNT,FRONT RIGHT 22.5 IN 40LB	NLA
13138	MOUNT,REAR LEFT 22.5 IN 40LB	NLA
13140	MOUNT,FRONT LEFT SOLID 40H	NLA
13142	MOUNT,FRONT RIGHT WPDS 10-15	NLA
13146	HOUSING,THERMOSTAT	NLA
13159	SEPERATOR SS1A	NLA
13160	SEPERATOR SS1A	NLA
13162	EYE,LIFTING WPDS20	NLA
13167	PANEL SS1A	NLA
13168	COVER SS1A	NLA
13174	MUFFLER	34936
13183	COOLER,OIL	13846 & 22032
13209	BRACKET,ALTNR 60A L-N	NLA
13221	MOUNT,REAR RB	NLA
13233	ADAPTER	NLA
13237	BRACKET,ALTNR 51A EXTRA W40	NLA
13241	GASKET,BACKPLATE	NLA
13243	PLATE,BACK	23932
13276	CAP	NLA
13279	MOUNT	13864
13283	MOUNT,REAR RIGHT MORGAN	NLA
13284	MOUNT,REAR RIGHT 22.5 IN 40LB	NLA
13310	BRACKET,ALTNR 51A W30	NLA
13314	COOLER,OIL	NLA
13323	ALARM	NLA
13324	CABLE	19208
13349	NIPPLE 1/8 NPT x 2 BRASS	NLA
13353	PANEL,INSTRUMENT,4-60 WIRED	NLA
13366	BRACKET,TERMINAL JUNCTION	NLA
13369	COOLER,OIL	11199
13371	CABLE	19208
13372	CABLE	NLA
13379	AQUALARM	NLA
13380	ALARM	NLA
13381	SWITCH,OIL PRESS,NC,UNGND	NLA
13383	FLYWHEEL ASSEMBLY W30	NLA
13396	SUPPORT,REAR MOUNT WPD3	NLA
13410	HOUSING,FLYWHEEL SA0 4-91	NLA
13416	COUPLING	20680
13422	HOUSING,FLYWHEEL RB 4-91	NLA
13427	BRACKET,COOLER	21467 & 11411
13430	ADAPTER,GENERATOR TO HSG WPD3	NLA
13431	REGULATOR SS1A	NLA
13436	BASE,GENSET WPD3	NLA
13439	BOX,GENSET CTL PNL WPD3	NLA
13447	BLOCK,TERMINAL 4 POS 1 ROW	NLA
13451	METER,AMP	NLA
13461	EYE,LIFTING FRONT	NLA
13464	BRACKET,OIL COOLER 4-154	NLA
13467	POINTER,TIMING W120	NLA
13468	MOUNT,REAR RIGHT HIGH 4-91	NLA
13470	MOUNT,REAR LEFT HIGH 4-91 W50	NLA
13472	STRAINER SS3	NLA
13474	ELBOW	NLA
13478	EXCHANGER SS3	NLA

WESTERBEKE SUPERSESSION LISTING

10

Old Number	Description	New Number
13479	DIPSTICK 6/98	NLA
13480	SEPERATOR SS3	NLA
13482	DISPERSER SS3	NLA
13484	BRACKET,REGULATOR	NLA
13485	DOWEL 1/2 x 1	NLA
13488	HARNESS	NLA
13489	CONNECTOR,DIPSTICK TUBE	NLA
13514	DRIVE	NLA
13515	NAMEPLATE,KEYSWITCH-STOP-PREHE	NLA
13526	COVER,CYLINDER SIDE FRONT W30	NLA
13548	NUT SS1A	NLA
13554	NIPPLE 3/4 NPT x 4 BRASS	NLA
13555	CAPSCREW	24778
13559	COUPLING	NLA
13562	CLAMP	NLA
13563	CLAMP	NLA
13567	LOCKWASHER 5/16 IT	NLA
13571	GENERATOR UR 30KW 1PH	NLA
13602	DAMPER,HYD W80/120	NLA
13603	ELBOW 3/4" CxM 90	NLA
13628	CAPSCREW M12x1.5x30 DIN 961	NLA
13633	HOSE	11779
13639	NUT 3/4-10 NC JAM HEX STEEL ZI	NLA
13641	BRACKET,FUEL SOLENOID	NLA
13660	ISOLATOR	NLA
13666	ORIFICE	NLA
13681	PARTLIST	13765
13682	METER,WATER TEMP-SKIPPER PANEL	NLA
13683	FLYWHEEL ASSEMBLY	24064
13690	PLATE,MANIFOLD END	NLA
13695	PARTLIST VIRE	NLA
13696	PLATE,SEA WATER PUMP MNT 4-60	NLA
13698	ADAPTER,OIL FILTER 4-60	NLA
13699	LINE,BREATHER 4-60	NLA
13701	BRACKET,ALTRN 51A 4-60	NLA
13704	BUSHING,SAO SHAFT SUPPORT 4-60	NLA
13705	ISOLATOR	NLA
13709	ISOLATOR	NLA
13710	RESISTOR 12 OHM,70W	NLA
13720	STRAINER,OIL PICKUP	NLA
13721	ADAPTER	NLA
13722	SWITCH,GENERATOR ROTARY CONTRL	NLA
13725	LED,CLEAR LENS	32975
13727	PANEL,GENSET CONTROL,ROTARY	NLA
13728	PANEL,REMOTE CONTROL,ROTARY	NLA
13734	HARNESS,GEN PANEL 12321	NLA
13759	PLUG	NLA
13771	PANEL,INSTRUMENT	13353
13775	WIRE #16	31980-31989
13784	PUMP,INJECTION HYDRAULIC	NLA
13785	CAP,EXCHANGER	NLA
13790	REGULATOR,GENERATOR 13789 4-60	NLA
13800	KIT A WPDS 10-15	NLA
13801	KIT B WPDS 10-15	23887
13820	REMOTE EXPANSION TANK	24177
13821	MANUAL,PARTS PRICE BOOK	NLA
13827	TRANSMISSION FOR V-DRIVE P21ML	NLA
13828	FLANGE,MANIFOLD END	NLA

Old Number	Description	New Number
13832	GEAR,RING	NLA
13834	CABLE,KEYSWITCH TO ENGINE	NLA
13836	CABLE,PANEL TO GENERATOR	NLA
13842	PLATE,AIR SWITCH MOUNT	NLA
13843	ADHESIVE	NLA
13844	SWITCH,AIR	NLA
13848	ISOLATOR,AIR SWITCH	NLA
13849	BRACKET,SUMP OIL SUCTION PIPE	NLA
13850	MOUNT,REAR LEFT 16 IN RB	NLA
13851	MOUNT,REAR RIGHT 16 IN RB	NLA
13853	MOUNT SYS 4-107 RB 16 IN	NLA
13860	HOSE,OIL	NLA
13861	HARNESS,MARINE 4-91	NLA
13862	PULLEY,FRESH PUMP 4-91	NLA
13863	MOUNT,FRONT CENTER W30	NLA
13864	MOUNT,FRONT RIGHT W30	NLA
13865	BRACKET,OIL FILTER/DRAIN LINE	NLA
13867	BASE,GENSET WPDS 10-15	NLA
13868	METER,OIL PRESSURE-SKIPPER PNL	NLA
13873	BELT,FAN	NLA
13879	SOLENOID,FUEL 4-91	NLA
13881	ELECRIC STOP 4-91	NLA
13882	LEVER	NLA
13883	COUPLING,SOLENOID 4-91 SHUT-OF	NLA
13884	COUPLING,SOLENOID ASSY 4-91 SH	NLA
13885	SCREW	NLA
13886	SCREW	NLA
13887	PLATE,BACK 4-60	NLA
13890	CAPSCREW 3/8NFx3/4 NYLOK SOCKE	NLA
13916	HARNESS,GENSET BR30-45KW	NLA
13917	BELT	13873
13922	GROMMET	NLA
13926	CLAMP,CABLE RBC 1/4 x 1/4	NLA
13927	ELBOW	300821
13930	IMPELLER	33779
13939	SPRING,FUEL SOLENOID	NLA
13943	BALL JOINT	33482
13949	PULLEY,CRANKSHAFT	NLA
13951	PLUG,SUMP MAGNETIC 1/2 NPT W/G	NLA
13952	GASKET,PLUG 13951	13951
13956	SPACER 1.500OD,0.9375ID,0.25LG	NLA
13964	JUMPER,TERMINAL BLOCK 30 AMP	NLA
13971	SCREW,DRIVE NO 2 x 0.188	NLA
13972	RAIL,RIGHT COMPRESSR FRONT W40	NLA
13973	RAIL,LEFT COMPRESSOR FRONT W40	NLA
13974	COUPLING PILOT BORE RB TRX	NLA
13975	TRANSMISSION FOR V-DRIVE SA1V	NLA
13976	TRANSMISSION FOR V-DRIVE SA0V	NLA
13986	SOLENOID,FUEL	21824
13987	NIPPLE	NLA
14000	DIPSTICK 4/98	NLA
14032	PLATE,BACK JC SERIES	NLA
14046	BOX,GENSET WPDS JC	NLA
14047	BASE,GENSET 10-15KW JC	NLA
14055	BASE,GENSET 10-15KW JC RADIATR	NLA
14065	PLATE,BACK WB	NLA
14066	HOUSING,FLYWHEEL WB	NLA
14073	TANK,EXPANSION WB	NLA

Old Number	Description	New Number
14074	PLATE,BACK 4-107	14128
14075	HOUSING,FLYWHEEL	NLA
14082	CONDENSER SS1A	NLA
14084	HOUSING,FAN SS1A	NLA
14087	HOUSING,CONDENSER SS1A	NLA
14089	BRACKET,REMOTE PANEL	NLA
14113	MANIFOLD,EXHAUST 4-91	NLA
14114	MANIFOLD,EXHAUST W40LS	15564
14115	MANIFOLD,INTAKE W40LS LOW	NLA
14117	EVAPORATOR BOTTOM SS1A	NLA
14119	PANEL SS1A	NLA
14128	PLATE,BACK W40	NLA
14134	CONDENSER SS1A	NLA
14158	GASKET	21929
14162	BEARING,BALL 30- 55-13	NLA
14165	BEARING,BALL 30- 62-23.8-DUBL	NLA
14166	BEARING,BALL 45- 85-30.2-DUBL	NLA
14167	O-RING RB TRX	NLA
14168	BEARING,BALL 100-150-24-2 SEAL	NLA
14174	GASKET,HOUSING RB TRX	NLA
14198	GASKET	14197
14200	SEAL RB TRX	NLA
14201	SEAL RB TRX	NLA
14222	BOLT RB TRX	NLA
14250	HOLDER,BRUSH	NLA
14251	BRUSH	NLA
14254	CLIP,BEARING	NLA
14264	RESISTOR	NLA
14265	RESISTOR 500 OHM,50W	NLA
14266	RECTIFIER,NEGATIVE	NLA
14268	RECTIFIER,VOLTAGE CONTROL	NLA
14269	RECTIFIER ASSEMBLY	NLA
14294	PLATE 2.5:1	NLA
14295	PLATE 1.5:1	NLA
14296	GEAR	NLA
14300	REDUCTION UNIT	NLA
14302	BAND,BRAKE	NLA
14305	GEARCASE ASSY	NLA
14309	HOUSING,REDUCTION SAO	NLA
14312	PINION	NLA
14315	SCREW	NLA
14317	SHAFT	NLA
14321	GASKET	286204
14322	BAND	14302
14324	BALL JOINT	NLA
14325	FINGER ASSEMBLY	NLA
14329	SCREW	NLA
14330	SCREW	NLA
14331	PIN	NLA
14333	SPACER,BEARING SAO	NLA
14335	LEVER	NLA
14338	CARRIER	NLA
14339	SHAFT,TAIL	NLA
14341	SHAFT	NLA
14342	SLEEVE	NLA
14343	PIN	NLA
14344	TABWASHER,CONNECTING ROD BOLT	NLA
14345	SCREW	NLA

Old Number	Description	New Number
14349	HOUSING	NLA
14357	COUPLING,OUTPUT SAO REDUCTION	NLA
14359	NUT,LOCKING	NLA
14361	WASHER	NLA
14364	BRACE	NLA
14368	BALL JOINT	NLA
14373	RING	NLA
14374	RING	NLA
14376	PLATE,COVER SA1	NLA
14384	BEARING	14877
14385	BEARING	NLA
14386	PIN	NLA
14387	BOLT	NLA
14392	DIPSTICK	NLA
14397	LEVER	NLA
14398	LINK,END ASSEMBLY	NLA
14400	RING	NLA
14402	PIN	NLA
14433	PLUG	NLA
14435	SLIPPER,CHAIN TENSIONER	NLA
14439	DIPSTICK	NLA
14440	LOCKWASHER	31758
14441	NUT	31760
14442	NUT	31760
14443	WASHER,CYLINDER HEAD	NLA
14444	SEAL	17729
14446	KEY	NLA
14450	WASHER	NLA
14451	WASHER	NLA
14455	PLUG 5/8-18 UNF HEX HEAD STEEL	NLA
14456	BRACKET,ROCKER-NOT TAPPED	NLA
14457	VALVE	20261
14458	VALVE	17626
14461	CIRCLIP,PISTON PIN	NLA
14465	PLATE,INJECTION PUMP MOUNTING	NLA
14466	CAMSHAFT W30	NLA
14472	TAPPET .010 W30	NLA
14473	TAPPET .020 W30	NLA
14474	PUMP,OIL W30	NLA
14476	NUT	NLA
14478	STUD,FUEL PUMP	NLA
14479	COVER,ROCKER W30-50	NLA
14481	SCREW	NLA
14482	STUD,CYLINDER HEAD SHORT	NLA
14483	PLATE,ROCKER BRACKER W30	NLA
14484	SHAFT,OIL PUMP DRIVE	NLA
14485	HEAD,CYLINDER W30 TO 786A/D443	NLA
14486	PLATE,FRONT W30	NLA
14488	STUD,CYLINDER HEAD LONG	NLA
14490	WASHER	11945
14491	SPINDLE	NLA
14494	WIRE,GLOWPLUG CONNECTING	NLA
14496	WASHER	NLA
14497	WASHER	NLA
14498	WASHER	NLA
14499	BOLT	NLA
14500	PLUG,TAPR BRASS .763x.751x3/8	NLA
14502	CRANKSHAFT W30	NLA

Old Number	Description	New Number
14503	ROD,CONNECTING W30 CYL 2 & 4	NLA
14504	ROD,CONNECTING W30 CYL 1 & 3	NLA
14505	TABWASHER,CONNECTING ROD	NLA
14509	KIT,TENSIONER REPAIR	14655
14511	NUT,PILLAR 7/16NF X 3/8 NF X 1	NLA
14512	CLIP	NLA
14513	BOLT	11935
14514	CIRCLIP	NLA
14517	WASHER	NLA
14518	SCREW	NLA
14519	WASHER	14517
14521	SCREW	NLA
14522	SCREW	NLA
14523	BOLT	NLA
14524	SCREW	NLA
14525	SETSCREW	NLA
14527	GASKET,FRESH WATER PUMP	NLA
14529	GLOWPLUG 12VDC,70WATT	23769
14530	SCREW	NLA
14531	KEY,WOODRUFF CAMSHAFT W30	NLA
14532	BOLT	NLA
14533	WASHER	NLA
14534	LINE	17960
14536	SEAT,VALVE-INTAKE	NLA
14537	INSERT	NLA
14538	STUD,THERMOSTAT HOUSING	NLA
14539	KIT	NLA
14540	NUT,CAMSHAFT W30	NLA
14541	WASHER	14453
14543	RELAY	13682
14546	COTTER	NLA
14547	BRACKET,ROCKER-TAPPED	NLA
14551	SPRING,ROCKER SHAFT	NLA
14557	STUD	NLA
14558	STUD	NLA
14560	STUD,MAIN BEARING CAP	NLA
14561	VALVE	NLA
14565	PUMP,INJECTION W30	NLA
14568	GASKET	11861
14571	GASKET	NLA
14573	GASKET	17929
14575	CUP	NLA
14576	SEAL	NLA
14577	SEAT,VALVE SPRING LOWER W30	NLA
14579	PLUG,TAPR BRASS .162x.145x3/16	NLA
14581	EYE,LIFTING	NLA
14582	SCREW	NLA
14583	BRACKET,FUEL FILTER	NLA
14584	PULLEY	NLA
14585	LINE,INJECTOR 1 W30	NLA
14586	LINE,INJECTOR 4 W30	NLA
14587	GASKET	13544
14588	STRAINER,OIL	NLA
14589	PLATE,CAMSHAFT LOCATING	NLA
14590	LINE,INJECTOR 2 W30	NLA
14591	LINE,INJECTOR 3 W30	NLA
14592	PLATE,TIMING INDICATOR	NLA
14593	PLUG,EXPANSION CUP 0.500 STEEL	NLA

WESTERBEKE SUPERSESSION LISTING

15

Old Number	Description	New Number
14594	COVER	NLA
14597	PLUG	NLA
14599	ROTOR	NLA
14601	GASKET,HEAD	17892
14602	PIN	NLA
14603	ROCKER W30-50	NLA
14607	STUD,INJECTOR	NLA
14609	LINE USE 17960 LGTH AS REQD	17960
14611	COVER,TIMING	NLA
14613	NUT	23235
14615	BEARING SET,ROD .010 W30	NLA
14616	BEARING	21908
14617	WASHER	32417
14618	WASHER	32418
14619	WASHER	32417
14620	WASHER	32418
14623	BEARING	21909
14625	RIVET	NLA
14626	PETCOCK	NLA
14630	PISTON	NLA
14631	PISTON	NLA
14633	RING SET 0.010 1 CYL W30	NLA
14637	MANIFOLD	NLA
14639	STUD	NLA
14640	STUD	NLA
14641	LINE,INJECTOR RETURN	23844
14642	WASHER,CYL HEAD PLUG 5/8UNF	NLA
14644	THERMOSTAT	NLA
14645	CIRCLIP	NLA
14646	PLUG	NLA
14647	WASHER	NLA
14648	WASHER	NLA
14651	PLATE	NLA
14652	WASHER,TIMING COVER W30	NLA
14653	WASHER,CYLINDER HEAD W30	NLA
14657	WASHER,WELCH	14553
14659	COVER	NLA
14660	KIT,LIFT PUMP, MINOR	NLA
14663	BOLT	12351
14665	CAMSHAFT W30 W/TACH DRIVE	NLA
14666	HOUSING	NLA
14669	GEAR	NLA
14670	WASHER	NLA
14671	BUSHING	NLA
14672	VALVE	31062
14673	WASHER,LIFT PUMP CHECK VALVE	NLA
14675	DRIVE,TACH 90 DEGREE 4-60	NLA
14676	BLOCK,SHORT 107	NLA
14677	PUMP,INJECTION WPDS-10-15KW	NLA
14678	PUMP,INJECTION W40	NLA
14680	PUMP,INJECTION PROP	NLA
14685	BUSHING,IDLER GEAR W40	NLA
14688	CONNECTOR	11937
14706	STUD 3/8NFx2-3/8	NLA
14727	LINE,INJECTOR 3 107 HYD PUMP	NLA
14728	LINE,INJECTOR 4 107 HYD PUMP	NLA
14729	LINE,INJECTOR 2 107 HYD PUMP	NLA
14730	LINE,INJECTOR 1 107 HYD PUMP	NLA

Old Number	Description	New Number
14749	LINE,INJECTOR 4 4-99 HYD	NLA
14750	LINE,INJECTOR 1 4-99 HYD	NLA
14751	LINE,INJECTOR 2 4-99 HYD	NLA
14752	LINE,INJECTOR 3 4-99 HYD	NLA
14769	LINE,INJECTOR 1 4-99	NLA
14770	LINE,INJECTOR 2 4-99	NLA
14777	FILTER,FUEL	19509
14812	LINE	14747
14814	LINE,INJECTION PUMP TO FILTER	NLA
14826	GEAR	NLA
14827	GEAR	NLA
14828	GASKET,DROP BOX HSNB SA1-120	NLA
14829	HOUSING	NLA
14830	PLATE	NLA
14832	CAPSCREW	31646
14833	SWITCH,STARTER LUCAS	NLA
14835	PLATE,REDUCTION ADAPTER	NLA
14836	GEAR	285990
14837	PINION ASSY, LONG	285989
14838	PINION ASSEMBLY,SHORT SAO	NLA
14839	GEAR,REDUCTION DRIVING SAO	NLA
14840	BUSHING,PINION SAO	286229
14841	BUSHING,PINION SAO	285988
14842	SHAFT,PINION SAO	285985
14843	BEARING,BALL 30- 62-23.8-DUBL	NLA
14844	KEY,WOODRUFF # 9 3/16 x 3/4	NLA
14845	PLATE,CLUTCH-STEEL	285993
14846	PLATE,PRESSURE SAO	NLA
14847	SLEEVE,OPERATING SAO	NLA
14848	KEY,WOODRUFF # 13 3/16 x 1	NLA
14849	PIN,FINGER SAO	285996
14850	BAND	NLA
14851	FINGER,SAO	NLA
14852	LEVER	NLA
14853	CAM,REVERSE SAO	285975
14854	COLLAR,SCREW SAO	NLA
14855	PLATE,CLUTCH	285992
14856	NUT	NLA
14857	SHAFT,TAIL	NLA
14858	SHAFT,TAIL	NLA
14859	SCREW,LOCK PRESSURE PLATE SAO	NLA
14860	SLIDE	NLA
14861	SHAFT,CROSS SAO	NLA
14862	YOKE ASSEMBLY,SAO	NLA
14863	COUPLING,OUTPUT SAO	NLA
14864	RETAINER,OIL SEAL SAO	NLA
14865	THRUSTWASHER,TAILSHAFT SAO	NLA
14866	THRUSTWASHER,TAILSHAFT SAO	NLA
14867	COVER	NLA
14869	BRACE,SAO	NLA
14870	SPRING,SAO	290415
14871	SPACER,SHORT PINION SAO	NLA
14872	SPRING,LOCK SAO	NLA
14873	NUT	NLA
14874	RING,RETAINING	285984
14875	LOCKWASHER,TAILSHFT	263762
14878	PIN	NLA
14879	PIN,BRAKE BAND LOCK SAO	NLA

Old Number	Description	New Number
14880	BREATHER	NLA
14883	TUBE	NLA
14884	SEAL,OIL CROSS SHAFT SAO	NLA
14885	SEAL,OIL	NLA
14886	O-RING	NLA
14887	PIN,ROLL	NLA
14889	TUBE,DIPSTICK	NLA
14890	BAFFLE,SAO COVER	NLA
14891	HOUSING,SAO	NLA
14892	PLATE,FRONT SAO	NLA
14897	RING,RETAINING	NLA
14899	SHAFT,TAIL	NLA
14900	PLATE,ADAPTER SAO	NLA
14902	RING,RETAINING TAILSHAFT SAO	NLA
14903	RING,RETAINING	NLA
14951	RING,RETAINING	NLA
14952	RING,RETAINING	NLA
14953	RING,RETAINING	NLA
14954	BEARING	NLA
14955	PIN,IDLER SHAFT SSL/SSR	NLA
14956	PIN,SHIFT LEVER	14955
14957	KEY,OUTPUT SHAFT SSL/SSR	NLA
14958	O-RING	NLA
14959	O-RING	NLA
14960	RACE,BEARING	NLA
14961	RACE	NLA
14962	RACE	NLA
14963	BEARING,NEEDLE THRUST	NLA
14965	BEARING	NLA
14966	BEARING	14965
14967	BEARING	NLA
14968	BEARING	NLA
14970	NUT,LOCKING OUTPUT COUPLING	NLA
14971	SEAL,INPUT SHAFT	NLA
14973	WASHER	NLA
14974	SHAFT,IDLER 14998 HOUSING	NLA
14976	SHAFT	NLA
14980	WASHER,OUTPUT COUPLING SSL/SSR	NLA
14982	SHAFT,OUTPUT SSL/SSR	NLA
14983	IDLER,SSL/SSR	NLA
14984	COUPLING,OUTPUT SSL-SSR	NLA
14985	CLUTCH	NLA
14988	GEAR	NLA
14989	WASHER	NLA
14993	GASKET	NLA
14995	SHOE,CLUTCH	NLA
14996	SHAFT	NLA
14998	HOUSING	NLA
14999	CAPSCREW	31605
15011	HOUSING,FLYWHEEL JC GEN	NLA
15013	HOUSING,FLYWHEEL WPDL	NLA
15032	HOUSING,FLYWHEEL RB	NLA
15044	HOUSING,FLYWHEEL SA1 4-107	NLA
15045	HOUSING,FLYWHEEL HYD W40	NLA
15046	HOUSING,FLYWHEEL RB	NLA
15050	MANIFOLD,EXHAUST 4-91	NLA
15056	MANIFOLD,EXHAUST 4-60	NLA
15059	COVER,MANIFOLD EXHAUST FLANGE	NLA

Old Number	Description	New Number
15060	MOUNT,FRONT 4-60	NLA
15061	BRACKET,SOLENOID-START	NLA
15063	NAMEPLATE,GEN REMOTE CTL ROTAR	NLA
15064	DAMPER,SAO 4-60	NLA
15067	MARKER,TERMINAL BLOCK 13447	NLA
15070	HOUSING,THERMOSTAT 4-60	NLA
15071	BRACKET,FUEL FILTER 4-60	NLA
15072	PLATE,AIR FILTER TOP 4-60	NLA
15073	PLATE,AIR FILTER BOTTOM 4-60	NLA
15074	FILTER,AIR	NLA
15076	WINGNUT 8-32	NLA
15078	MOUNT,REAR W60	NLA
15080	FLYWHEEL 4-60	NLA
15081	TUBING	NLA
15083	MANIFOLD,INTAKE 4-60	NLA
15084	SUMP,OIL 4-60	NLA
15090	HOUSING,FLYWHEEL SAO 4-60	NLA
15092	BRACKET,EXCHANGER 4-60	NLA
15094	PLATE,MANIFOLD WATER INLET	NLA
15098	PUMP,SEA WATER 4-60	295625
15099	NUT,LOCKING	NLA
15100	NAMEPLATE,GENSET CTL ROTARY SW	NLA
15101	BRACKET,THROTTLE 4-60 SSR	NLA
15104	ADAPTER,DIPSTICK TUBE TO SUMP	NLA
15105	FLEXIBLE EXHAUST LINE 2.0"x12	NLA
15106	BRACKET,SEA WATER PIPE SUPPORT	NLA
15116	TRANSMISSION 1:1 HYD P31L	NLA
15117	TRANSMISSION 1.5:1 HYD P32L	NLA
15118	TRANSMISSION 2:1 HYD P33L	NLA
15119	TRANSMISSION 2.5:1 HYD P34L	NLA
15120	TRANSMISSION 3:1 HYD P35L	NLA
15124	HARNESS,GEN PANEL 13727	NLA
15125	HARNESS,GEN PANEL-TILTING	NLA
15130	WIRE #14	31970-31979
15131	KIT,WATER PUMP 16432 MAJOR REP	NLA
15132	MARKER	NLA
15133	PLUG	NLA
15135	DIAPHRAGM,LIFT PUMP	NLA
15136	KIT,LIFT PUMP 17569	NLA
15138	HARNESS,GENSET WPDS-15KW	NLA
15139	JUMPER,TERMINAL BLOCK 15 AMP	NLA
15143	BASE,GENSET BR30	NLA
15154	HOUSING SS3	NLA
15156	MOUNT VIRE 7	NLA
15158	LEVER,FUEL SHUTOFF EMERGENCY	NLA
15163	COVER SS3	NLA
15164	MANIFOLD SS3	NLA
15166	HOSE	11652
15170	HARNESS,MARINE 4-154	NLA
15171	BRACKET,REGULATOR	NLA
15172	SOLENOID	NLA
15176	MOTOR,STARTER/GENERATOR	NLA
15177	PLUG	NLA
15178	PLUG	NLA
15180	PLATE,THROTTLE CABLE BRACKET E	NLA
15181	FLEXIBLE EXHAUST LINE 2.5"x12	NLA
15183	SCREW,FUEL SOLENOID PLUNGER LI	NLA
15184	BRACKET,SOLENOID WPD3	NLA

Old Number	Description	New Number
15186	LEVER,FUEL SOLENOID	NLA
15190	SOLENOID,FUEL	23041
15196	ADAPTER,OIL SUCTION	NLA
15201	STUD 3/8NFx2-1/8 CHROMATE	NLA
15203	SPRING	NLA
15210	STUD 3/8NFx1-1/2 CHROMATE	NLA
15212	STARTING AID L25 THERMOSTART F	NLA
15215	BELT	NLA
15219	BOX,GENSET CTL PNL BR30	NLA
15220	BLOCK,TERMINAL 12POS	50192
15221	MARKER	50197
15224	RAIL,LEFT & RIGHT VIRE	NLA
15228	BELT	13585
15231	BRACKET,EXCHANGER 4-60	NLA
15234	SILENCER,INTAKE WPDS-20	NLA
15236	SILENCER,INTAKE W80-120	NLA
15243	LED,CLEAR LENS W/WIRE & TERMNL	32975
15249	MOUNT	NLA
15250	ISOLATOR	NLA
15251	BOLT 3/4NCx1 HEAVY HEX HEAD	NLA
15254	FLANGE SS3	NLA
15256	COVER SS3	NLA
15257	COVER,SEA WATER PUMP	NLA
15261	MANUAL,OWNER VIRE 7	NLA
15262	HARNESS,GENSET WPDS-20KW AUTO	NLA
15263	BODY,SEA WATER PUMP	NLA
15264	HARNESS,GENSET WPDS-20KW MAN	NLA
15266	SCREW	NLA
15267	NUT,LOCKING	NLA
15271	SCREW	NLA
15276	ELBOW,WATER INJECTED VIRE/DS	NLA
15282	KIT,FUEL SOLENOID WPD3 RETRO	NLA
15295	RADIATOR SS3	NLA
15298	SLINGER,CRANKSHAFT FRONT	NLA
15299	EYE,LIFTING	NLA
15301	CIRCLIP	NLA
15303	TAPPET .010 4-60 W50	NLA
15304	SHAFT,ROCKER 4-60	NLA
15305	WASHER,SPRING-ROCKER SHAFT	NLA
15306	DOWEL,MAIN BEARING CAP	NLA
15307	PLATE,CAMSHAFT LOCATING 4-60	NLA
15308	GASKET	NLA
15313	CLIP,BEARING RETAIN 4-60 FWP	NLA
15316	HEAD,CYLINDER 4-60	NLA
15317	GUIDE,VALVE EXHAUST STD 4-60	NLA
15318	GUIDE,VALVE EXHAUST 0.010 4-60	NLA
15319	GUIDE,VALVE INTAKE STD 4-60	NLA
15320	GUIDE,VALVE INTAKE 0.010 4-60	NLA
15321	INSERT,COMBUSTION 4-60	NLA
15322	STUD	NLA
15323	VALVE	NLA
15324	VALVE,EXHAUST 4-60	NLA
15325	SPRING,VALVE OUTER 4-60	NLA
15326	PUSHROD 4-60	NLA
15329	HOUSING,THERMOSTAT 4-60	NLA
15330	PIPE	NLA
15331	BRACKET	NLA
15332	CRANKSHAFT 4-60	NLA

Old Number	Description	New Number
15333	GEAR	NLA
15334	PULLEY,CRANKSHAFT 4-60	NLA
15335	DISC,TIMING 4-60	NLA
15336	TENSIONER ASSY,CHAIN 4-60	NLA
15337	FLYWHEEL ASSEMBLY	NLA
15338	TABWASHER,FLYWHEEL 4-60	NLA
15339	PUMP,OIL 4-60	NLA
15340	GASKET,OIL PUMP TO BLOCK 4-60	NLA
15341	GASKET,TACH DRIVE HOUSING 4-60	NLA
15342	ROD,CONNECTING 4-60	NLA
15345	ROD,CONNECTING 4-60	NLA
15346	LINER,CYLINDER 4-60	NLA
15347	PLUG,TAPR BRASS .433x.429x.434	NLA
15348	DOWEL,TAPPED	NLA
15349	DAMPER,TIMING CHAIN	NLA
15350	LOCKWASHER 4-60	NLA
15351	INDICATOR,TIMING 4-60	NLA
15352	ADAPTER	NLA
15353	GASKET,LUBE OIL ADAPTER 4-60	NLA
15354	PLATE	NLA
15355	TABWASHER	NLA
15356	LINE,OIL STRAINER TO PUMP 4-60	NLA
15357	DIPSTICK 4-60	NLA
15358	PUMP,LIFT	NLA
15359	PUMP,INJECTION 4-60	NLA
15360	HUB,INJECTION PUMP DRIVE 4-60	NLA
15361	CAPSCREW,INJ PUMP DRIVE HUB	NLA
15362	GASKET,HUB TO FRONT PLATE 4-60	NLA
15363	GEAR,INJECTION PUMP DRIVE 4-60	NLA
15364	PLATE,INJECTN PUMP DRIVE GEAR	NLA
15365	FLANGE,INJECTN PUMP DRIVE GEAR	NLA
15366	CHAIN,INJECTION PMP DRIVE 4-60	NLA
15367	BOLT,BANJO	NLA
15368	BLOCK,TENSIONER	NLA
15369	GASKET,TENSIONER BLOCK	NLA
15370	LINE,INJECTOR 1 4-60	NLA
15371	LINE,INJECTOR 2 4-60	NLA
15372	LINE,INJECTOR 3 4-60	NLA
15373	LINE,INJECTOR 4 4-60	NLA
15375	WASHER,PULLEY-GENERATOR 13789	NLA
15376	BRACKET,GENERATOR 13789 4-60	NLA
15377	PILLAR	NLA
15378	PULLEY,FRESH PUMP 4-60	NLA
15380	FLANGE,WATER PUMP PULLEY 4-60	NLA
15381	GASKET,FRESH PUMP-ADAPTER 4-60	NLA
15382	GASKET,FRESH PMP ADPTR-BLK4-60	NLA
15384	SUMP	NLA
15385	GASKET,FRONT PLATE TO BLOCK	NLA
15387	CAMSHAFT 4-60	NLA
15388	GEAR,CAMSHAFT 4-60	NLA
15389	GEAR,CRANKSHAFT-CAMSHAFT 4-60	NLA
15390	COVER,TIMING 4-60	NLA
15391	GASKET,TIMING COVER TO PLATE	NLA
15392	BOLT	NLA
15393	INJECTOR 4-60	NLA
15394	GASKET,BACKPLATE 4-60	NLA
15395	INDICATOR,TIMING	NLA
15396	PIN,PISTON 4-60	NLA

Old Number	Description	New Number
15397	PLATE,FRONT 4-60	NLA
15398	LINE,OIL TO TENSIONER 4-60	NLA
15399	COVER,ROCKER 4-60	NLA
15400	SCREW,ROCKER ADJUSTING	NLA
15401	ROCKER 4-60	NLA
15402	WASHER	NLA
15403	GASKET,OIL SEAL FLANGE	NLA
15404	SHAFT,OIL PUMP & TACHOMETER	NLA
15405	HOUSING,TACHOMETER DRIVE 4-60	NLA
15406	SEAL,TACHOMETER DRIVE SHAFT	NLA
15407	LOCKWASHER	NLA
15409	PUMP,FRESH WATER 4-60	NLA
15412	THRUSTWASHER,UPPER 4-60	35751
15413	THRUSTWASHER,LOWER 4-60	35751
15414	ADAPTER	NLA
15415	BEARING	17582
15416	GASKET,SUMP SIDE COVER 4-60	NLA
15417	SPRING,VALVE INNER 4-60	NLA
15418	SEAT,VALVE SPRING-UPPER	NLA
15420	SEAL,OIL CRANKSHAFT REAR	NLA
15421	BUSHING,DIPSTICK 4-60	NLA
15422	WASHER,THERMOSTAT BYPASS ADPTR	NLA
15423	BANJO,INJECTOR DOUBL PUSH-ON	NLA
15426	FILTER	19509
15428	MANIFOLD	15083
15429	RING,RETAINING	NLA
15431	STUD,INJECTOR	NLA
15432	STUD,THERMOSTAT HOUSING	NLA
15433	STUD,SUMP 4-60	NLA
15434	PLUG,TAPR BRASS .288x.280x9/32	NLA
15436	BUSHING,INJECTION PUMP DRIVE	NLA
15438	GASKET	17587
15439	DOWEL,BLOCK TO BACKPLATE	NLA
15440	PLUG	NLA
15441	WASHER,CLAMP INTAKE MANIFOLD	NLA
15442	DOWEL	NLA
15443	BLOCK,SHORT 4-60	NLA
15444	ELEMENT	NLA
15445	BEARING SET,MAIN STD 4-60	NLA
15446	BEARING SET,MAIN .010 4-60	NLA
15447	BEARING SET,ROD STD 4-60	NLA
15448	BEARING SET	NLA
15449	PISTON ASSY STD 4-60	NLA
15450	PISTON ASSY .010 4-60	NLA
15451	LINER,CAMSHAFT BEARING	NLA
15452	BLOCK ASSY 4-60	NLA
15459	BRACKET,ROCKER-PLAIN 4-60	NLA
15460	BRACKET,ROCKER-OIL FEED 4-60	NLA
15461	BRACKET,ROCKER-TAPPED 4-60	NLA
15462	PLUG,SUMP DRAIN 4-60	NLA
15467	RING	NLA
15468	BANJO,INJECTOR DOUBL PUSH/THD	NLA
15469	CIRCLIP,PISTON PIN 4-60	NLA
15470	BEARING	NLA
15471	O-RING,OIL PUMP COVER	NLA
15472	BELT	NLA
15473	THERMOSTAT	24688
15474	O-RING,BLOCK TO BACKPLATE	NLA

Old Number	Description	New Number
15475	GASKET	NLA
15476	TENSIONER,CHAIN 4-60	NLA
15477	SHAFT,INJECTION PUMP DRV 4-60	NLA
15478	SEAL,FUEL FILTER COVER	NLA
15479	BRUSH,GENERATOR 13789	NLA
15480	LINE,INJECTOR RETURN-PLASTIC	NLA
15481	PLUG,TAPR BRASS .273x.245x1/4	NLA
15483	WASHER	NLA
15484	WASHER,FIBRE	NLA
15485	WASHER	15367
15486	WASHER,ROCKER SHAFT	NLA
15487	SPRING,ROCKER SHAFT 4-60	NLA
15488	NUT	NLA
15489	LOCKWASHER	NLA
15490	STUD	NLA
15491	STUD	NLA
15492	STUD	NLA
15493	STUD,ROCKER BRACKET-LONG	NLA
15494	BOLT,FLYWHEEL 4-60	NLA
15495	STUD,ROCKER BRACKET-SHORT	NLA
15496	STUD	NLA
15497	SCREW	NLA
15498	GROMMET	NLA
15499	O-RING,SUMP 4-60	NLA
15500	WASHER	12522
15501	WASHER	NLA
15502	ADAPTER,INJECTION PUMP RETN LN	NLA
15503	GASKET,INJECTION PUMP COVER	NLA
15504	GASKET,REDUCTION HSG TO ADAPTR	NLA
15505	STUD,REDUCTION HSG TO TRANSMSN	NLA
15506	ADAPTER,REDUCTION HSG TO TRANS	NLA
15507	GASKET,REDUCTION HSG TO TRANSM	NLA
15508	HOUSING,REDUCTION	NLA
15509	COVER,REDUCTION LOWER OUTPUT	NLA
15510	COUPLING,OUTPUT SNOW-NABSTEDT	NLA
15511	PINION,REDUCTION UNIT	NLA
15512	COVER,REDUCTION UNIT	NLA
15514	NUT,OUTPUT COUPLING TO SHAFT	NLA
15515	SHIM .005 REDUCTION UNIT	NLA
15516	SHIM .007 REDUCTION UNIT	NLA
15517	SHIM .020 REDUCTION UNIT	NLA
15518	CAPSCREW,REDN ADAPTER TO TRANS	NLA
15519	PIN,REDUCTION HSG TO ADAPTER	NLA
15520	CAPSCREW,LOWER COVER TO HSG	NLA
15522	BEARING,REDUCTION UNIT	NLA
15523	SEAL,REDUCTION UNIT	NLA
15524	TRANSMISSION	34407
15525	REDUCTION UNIT,SNOW NABSTEDT	NLA
15530	PULLEY 6x2xA 4x2xA W80-120	NLA
15535	PANEL,GENSET CONTROL BR30	NLA
15537	HARNESS,MARINE 4-230	NLA
15538	HARNESS,MARINE 6-346	NLA
15541	BRACKET,COMPRESSOR W80	NLA
15543	BRACKET,COMPRESSOR ADJUST W80	NLA
15546	BLOCK,TERMINAL, 155AMP,600VOLT	NLA
15547	BLOCK-END,TERMINAL FOR 15546	NLA
15548	CHANNEL	NLA
15549	CLAMP	NLA

Old Number	Description	New Number
15550	NAMEPLATE,10A SLOW BLOW	NLA
15551	NAMEPLATE,OVERSPEED	NLA
15552	NAMEPLATE,FIELD BREAKER	NLA
15553	NAMEPLATE,AC VOLTAGE ADJUST	NLA
15558	COUPLING 1.5IN BORE P21-P33	23673
15560	TEE 1/4 COMPRESSION STEEL	NLA
15561	SPACER	24991
15565	BRACKET,SHIFT VIRE	NLA
15566	PARTLIST	15162
15570	SENSOR SS3	NLA
15574	POWER SUPPLY SS3	NLA
15578	ISOLATOR SS3	NLA
15614	RING	15613
15628	LINK,PUMP 11621	NLA
15643	HANDLE	11716
15645	PIN,CLEVIS	NLA
15654	MOTOR,STARTER HYDRAULIC	11620
15662	SPRING,PUMP VALVE	NLA
15664	CAP,UNLOADING VALVE	NLA
15676	BASE SS3	NLA
15677	COVER SS3	NLA
15678	LAMP,RED	NLA
15681	DAMPER,W7	NLA
15683	BOLT,CARRIAGE 3/8NCx1	NLA
15686	SOLENOID,VALVE SS3	NLA
15718	PLATE,SCREW-TERMINAL BLOCK 50A	NLA
15730	BRACKET,REMOTE LUBE OIL FILTER	NLA
15731	VALVE	NLA
15732	ELBOW 1/2NPT STREET 90 IRON	NLA
15733	NIPPLE 1/2 NPT x 6 STEEL	NLA
15734	NIPPLE 1/2 NPT x 10 STEEL	NLA
15735	CLAMP,HOSE 65	NLA
15746	PANEL,INSTRUMENT 4-107LS	NLA
15760	HOUSING,THERMOSTAT W30-50	24661
15764	SPACER 1.000OD,0.562ID,9-16LG	NLA
15765	PLATE,COMPRESSOR MOUNT 4-107	NLA
15766	BRACKET,COMPRESSOR W40-50	NLA
15775	PARTLIST	11708
15777	HOSE	11501
15778	SPACER,MOUNT FRONT RIGHT 20 IN	NLA
15779	SPACER,MOUNT FRONT LEFT 20 IN	NLA
15784	MANIFOLD,EXHAUST W30-50	NLA
15801	WASHER	NLA
15802	WASHER	NLA
15813	NUT	15812
15825	SCREW	NLA
15829	STUD	15828
15844	PIN	NLA
15846	BEARING	18260
15848	BEARING	NLA
15850	SEAL	NLA
15851	SEAL,CRANKSHAFT VIRE 7	NLA
15853	SEAL	NLA
15854	O-RING	NLA
15857	RING	NLA
15860	CIRCLIP	NLA
15861	CIRCLIP,PISTON PIN VIRE	NLA
15864	CUP	NLA

Old Number	Description	New Number
15872	SHIM	20537, 25038 & 20539
15873	RING	NLA
15874	GEAR	NLA
15875	GEAR	18195
15876	SHAFT	18222
15880	BUSHING,CONNECTING ROD	NLA
15882	GASKET,CYLINDER TO CRANKCASE	NLA
15884	PISTON	NLA
15885	RING,PISTON STD	NLA
15886	GASKET	NLA
15891	KEY	NLA
15898	BOLT	NLA
15910	COUPLING TO S/N 22999	NLA
15911	WASHER	NLA
15912	KEY	NLA
15913	SILENCER	18196
15914	ELBOW	16712
15916	FLANGE,EXHAUST	NLA
15920	ROD,CONNECTING	NLA
15924	PULLEY	16712
15927	ELBOW	NLA
15942	FILTER	16712
15943	GASKET	15944
15944	PLUG	NLA
15950	BELT	NLA
15952	REGULATOR	NLA
15954	GENERATOR	NLA
15957	CONDENSER	NLA
15958	CONTACT SET	37436
15962	COIL,IGNITION	NLA
15968	KIT,CARBURETOR	NLA
15973	RING,PISTON STD CHROME PLATED	NLA
15975	RING,PISTON 0.5 MM O/S CHROME	NLA
15976	NUT	NLA
15978	CABLE	18274
15980	GASKET SET	NLA
15983	GASKET	18237
15985	ELBOW,INJECTED EXHAUST	33067
15987	PANEL SS3	NLA
15996	STANDOFF SS3	NLA
15997	TABWASHER,CRANKSHAFT PULLEY	NLA
15999	PLUG,EXPANSION CUP 2.000 STEEL	NLA
16000	SPIRALWRAP 1/2	NLA
16008	HOSE	NLA
16012	KIT,DIODE INSTALLATION WPDS	NLA
16014	NUT,TACH CABLE	NLA
16016	CONNECTOR	NLA
16017	KIT,SS1A ORIFICE	NLA
16020	HOUSING,FLYWHEEL SAO	NLA
16026	HARNESS,PANEL SS3	NLA
16027	ADAPTER,TRANSMISSION TO HSG	NLA
16029	TACH CABLE 15 FOOT W40	NLA
16031	PLATE,BACK W80-120	NLA
16034	LEVER,THROTTLE W40	NLA
16036	HOUSING,FLYWHEEL UNIV W30	NLA
16038	PLATE,BACK W30	NLA
16040	MOUNT,REAR W30-40-50	NLA
16041	MARKER	NLA

Old Number	Description	New Number
16059	HOSE,EXCHANGER TO PUMP	NLA
16062	PLATE,FRONT DS	NLA
16063	MOUNT,DS/W7	NLA
16070	HOUSING,FLYWHEEL SA1 4-154	NLA
16073	BUSHING,SAO SHAFT SUPPORT W40	NLA
16076	HOUSING,FLYWHEEL UNIV W40	NLA
16082	DIODE 1N3208	NLA
16083	TRANSFORMER	NLA
16085	DIAC	NLA
16089	GENERATOR PC 3.5KW 1PH	NLA
16090	STUD 3/8NCx2-1/2 BRASS	NLA
16091	NUT 3/8-16 NC JAM HEX BRASS	NLA
16095	CABLE,ALTERNATOR TO REGULATOR	NLA
16100	RIVET	NLA
16101	KEY,WOODRUFF # 25 5/16 x 1-1/2	NLA
16103	BEARING,BALL 60-130-31	NLA
16104	LINING,BRAKE BAND	34688
16107	GEAR	34691 from s/n 6A1
16107	GEAR	34693 to s/n 6A1
16109	PIN,RELIEF VALVE	NLA
16114	PAD,THRUST	NLA
16119	SCREW	NLA
16123	SCREW,COLLAR LOCK	NLA
16124	CLIP	NLA
16125	O-RING	16126
16128	BEARING,NEEDLE	NLA
16130	TUBE,SUCTION	NLA
16131	THRUSTWASHER,FRONT PLATE	NLA
16133	HOUSING,PUMP FR S/N 6A1	34691
16134	GEAR	34691 from s/n 6A1
16134	GEAR	34693 to s/n 6A1
16138	PINION ASSY	16111, 16112 & 16115
16139	BEARING,ROLLER	NLA
16140	PINION ASSY	NLA
16141	THRUSTWASHER,DRIVE GEAR	NLA
16142	PLATE	34692
16143	PLATE,CLUTCH-INNER	34692
16144	BEARING,NEEDLE ROLLER	NLA
16146	RING,RETAINING,CONTROL VALVE	NLA
16149	O-RING	NLA
16151	GEAR	16152
16154	BAFFLE,TRANSMISSION	NLA
16156	SEAL	NLA
16158	PAWL	NLA
16159	LEVER	NLA
16160	BUSHING,CONTROL LEVER	NLA
16161	PLATE	NLA
16163	SHAFT,TAIL	NLA
16166	PIN,ROLL	NLA
16167	WASHER	NLA
16170	PLATE,PISTON BACKUP	NLA
16173	PIN,REVERSE BAND HOUSING	NLA
16180	SHAFT	16186
16184	BAND,REVERSE	16183
16185	PISTON ASSEMBLY	NLA
16188	ROD,DIPSTICK	16187
16189	DECAL	NLA
16190	HANDLE,DIPSTICK	16187

Old Number	Description	New Number
16191	BUSHING	NLA
16192	COLLAR	NLA
16193	COLLAR	34689
16194	PISTON,FORWARD	NLA
16197	COLLAR ASSEMBLY	NLA
16198	SPRING	NLA
16199	SPRING,RELIEF VALVE	NLA
16201	RING,RETAINING	NLA
16211	COVER	NLA
16212	VALVE	NLA
16216	DIPSTICK	16187
16220	PLATE	34693
16221	CAPSCREW 1/2NCx2-3/8 FULL THD	NLA
16223	VALVE	NLA
16224	COVER	NLA
16225	HOUSING,PUMP TO S/N 6A1	34693
16226	PLATE,FRONT P220 FROM S/N 6A1	34691
16229	PLATE,FRONT ASSEMBLY	NLA
16232	THRUSTWASHER	NLA
16234	PLATE	16237
16235	HOUSING	NLA
16237	PLATE,FRONT-ASSEMBLY TO S/N 6A	NLA
16238	ROD	16187
16239	STANDOFF SS3	NLA
16243	SUMP SS3	NLA
16246	TRANSMISSION 2:1 DROPBOX SA0	NLA
16251	TRANSMISSION 1:1 HYD 70 WB	NLA
16296	KEY,PUMP DRIVE	NLA
16303	BEARING	NLA
16307	GEAR ASSEMBLY INCL PLUG	NLA
16310	HOUSING SSL/SSR	NLA
16311	GEAR	NLA
16312	GEAR	NLA
16313	GEAR	NLA
16314	CLUTCH	NLA
16315	GEAR	NLA
16316	GEAR	NLA
16320	SPRING,GOVERNOR	NLA
16322	PLUG	19505
16325	TUBING	NLA
16342	ADAPTER,MOUNT FRONT RIGHT	NLA
16344	WASHER	NLA
16345	MOUNT,FRONT W80-120	NLA
16347	MANIFOLD,EXHAUST W120 45 WMF	NLA
16350	FLANGE,EXH MANIFOLD FRONT W80	NLA
16351	GASKET	NLA
16352	CONNECTOR,MALE 3/8NPTx3/8 COMP	NLA
16354	TUBING	NLA
16355	MANIFOLD,EXHAUST W80	NLA
16356	PULLEY 5x4xA 4x2xA W40 PRI	NLA
16361	TRIAC	NLA
16362	CAPACITOR 0.10MF,200VDC	NLA
16366	PLATE,DRIVE SSL/SSR	NLA
16370	HOUSING,THERMOSTAT 4-154	NLA
16371	PLATE,AIR FILTER BOTTOM 4-154	NLA
16372	PLATE,AIR FILTER TOP 4-154	NLA
16377	WASHER	NLA
16380	GASKET,EXH MANIFOLD END 4-154	NLA

Old Number	Description	New Number
16381	PLATE,MANIFOLD END	NLA
16382	BRACKET,RELAY-TILTING PNL	NLA
16384	PLATE,BACK W60	NLA
16385	BRACKET,DIODE-TRIAC MOUNT	NLA
16389	ENGINE 2.5L BMC	NLA
16391	ENGINE 4/98 BMC	NLA
16391	ENGINE 6/98 BMC	NLA
16393	SCREW,COMPRESSOR ADJUSTING	NLA
16394	HARNESS,GEN PANEL 16463	NLA
16395	BOARD,TERMINAL	NLA
16396	TRANSMISSION 2:1 SSR	NLA
16399	HOUSING,FLYWHEEL RB 4-60	NLA
16403	COOLER,OIL 4-154	NLA
16405	SHIELD	NLA
16406	SOCKET	NLA
16407	RELAY,TIME DELAY 12VDC,NO,SPST	NLA
16408	ADAPTER,OIL FILTER-COOLER 154	NLA
16411	BRACKET,ALTRN 105A 4-107 UP RT	NLA
16416	BRACKET,THROTTLE W80-120	NLA
16420	ADAPTER,FLYWHEEL TO 16441 FLEX	NLA
16422	MOUNT,REAR WPD3	NLA
16430	FLYWHEEL 4-154	NLA
16431	GEAR,DRIVE SA1D	NLA
16433	PLUG	NLA
16434	ELBOW	NLA
16435	MOTOR,STARTER-GENERATOR	NLA
16436	PULLEY	NLA
16437	HUB	NLA
16438	REGULATOR	NLA
16439	ISOLATOR	NLA
16440	PULLEY,STARTER/GENERATOR	NLA
16441	DAMPER,RUBBER SSL/SSR	NLA
16445	KIT,WATER PUMP DS-1	NLA
16449	GASKET SET,4-107LS	NLA
16451	DRIVE,TACH CABLE 90	NLA
16455	EXCHANGER	19058
16456	TACH CABLE 4 FOOT 4-60	NLA
16457	TACH CABLE 6 FOOT 4-60	NLA
16458	TACH CABLE 8 FOOT 4-60	NLA
16459	TACH CABLE 10 FOOT 4-60	NLA
16460	NAMEPLATE,WPD3 BATTERY-FUSE	NLA
16461	NAMEPLATE,WPD3 SWITCHES	NLA
16462	NAMEPLATE,WPD3 115VAC 25AMP	NLA
16463	PANEL,GENSET CONTROL WPD3	NLA
16464	NAMEPLATE,GENSET ID WPD-3	NLA
16467	SHAFT,DRIVE WPD3 GENERATOR	NLA
16471	SUPPORT,MOUNT-FRONT WPD-3	NLA
16473	ISOLATOR	NLA
16476	SPACER 0.750OD,0.438ID,0.750LG	NLA
16488	HOUSING,FLYWHEEL UNIV W60	NLA
16502	LOCKWASHER 3/8 SPLIT MED BRONZ	NLA
16503	WASHER	NLA
16504	WASHER,FIBRE SHOULDER 3/8ID	NLA
16505	ADAPTER,AIR FILTER TO MANIFOLD	NLA
16506	TANK,REMOTE EXPANSION	24177
16507	SHAFT	NLA
16508	HOUSING,FLYWHEEL SSL 4-60	NLA
16511	CUP,ISOLATOR	NLA

Old Number	Description	New Number
16540	SUMP,OIL 4-154	NLA
16548	METER,OIL PRESSURE	11544
16549	METER,WATER TEMPERATURE	37601
16550	METER,AMP	11581
16551	SENDER,OIL PRESSURE	11542
16552	SENDER,WATER TEMP	11543
16570	SPLICE 12-10AWG,NYLON INSULATE	NLA
16578	SPLICE 22-16AWG,NYLON INSULATE	NLA
16616	BRACKET,COMPRESSOR	NLA
16618	PULLEY 6x2xA 4-154	NLA
16620	ELBOW	NLA
16622	PULLEY	NLA
16626	SHAFT,SEA WATER PUMP DRIVE	NLA
16629	SUMP	NLA
16634	PLATE,SEA PUMP MOUNT 4-154	NLA
16636	BRACKET,ALTRN 51A 4-154	NLA
16638	HOUSING,FLYWHEEL JC GEN	NLA
16646	ADAPTER,MOUNT-FRONT LEFT 4-154	NLA
16648	ADAPTER,MOUNT-FRONT RT 4-154	NLA
16649	MANUAL,TECHNICAL W40LB/LS	20502
16650	SPARE PARTS KIT A 4-60	NLA
16652	GEAR,RING	NLA
16659	METER,AMMETER 0-30 FARIA	11581
16660	MOUNT,FRONT 4-154	NLA
16661	MOUNT,FRONT LEFT	NLA
16664	IMPELLER,SEA PUMP SSR20 TRX	NLA
16668	PANEL,PLATE INSTRUMENT DS-1	NLA
16673	BRACKET,THROTTLE W7	NLA
16674	BRACKET,SHIFT DS	NLA
16675	RAIL DS-1	NLA
16681	SWITCH	NLA
16684	POTENTIOMETER	NLA
16685	NAMEPLATE,LIFE BOAT INSTRUCTNS	NLA
16686	GAUGE,OIL PRESSURE 100PSI SW	NLA
16687	BRACKET,COMPRESSION RELEASE DS	NLA
16694	HOSE	303133
16697	PANEL,GEN REMOTE WPD3 NO SAFTY	NLA
16701	WASHER	NLA
16702	PIN	NLA
16703	CAPACITOR 0.05MF	NLA
16704	RESISTOR	NLA
16705	ISOLATOR	NLA
16713	FUSE 5A	NLA
16717	PANEL,GEN REMOTE WPD3	NLA
16718	GROMMET	NLA
16720	CAPACITOR 250MF,50VDC	NLA
16722	SWITCH,TOGGLE,SPST,MOM ON	NLA
16724	BLOCK,TERMINAL 7 POS 30A 2ROW	NLA
16725	MARKER,TERMINAL BLOCK 16724	NLA
16726	PLUG,BUTTON 1/2 HOLE NP BRASS	NLA
16732	LATCH,GENSET COVER WPD3	NLA
16735	MOTOR,STARTER	NLA
16739	FAN,WPDS-20	NLA
16740	BREATHHER 4-154	NLA
16741	BRACKET,REGULATOR WPDS-20	NLA
16743	SWITCH,SHORE	32008
16744	BRACKET,ALTRN 51A W80-120	NLA
16748	CLAMP,CABLE RBC 3/8	NLA

WESTERBEKE SUPERSESSION LISTING

29

Old Number	Description	New Number
16750	BLOCK,TERMINAL 3 POS 15A 2ROW	NLA
16751	HOLDER,FUSE	NLA
16752	PULLEY 7x3xA W80-120	NLA
16756	SETSCREW	23450
16762	MOTOR,STARTER 12VDC COM MARINE	NLA
16763	PANEL,DS NOT WIRED	NLA
16765	STUD	NLA
16767	PLUG,BANJO	NLA
16773	GASKET	NLA
16779	WASHER	17162
16790	CAPSCREW	17169
16795	FILTER,OIL	11951
16796	DIPSTICK	NLA
16807	CAMSHAFT	NLA
16811	PUMP,INJECTION	18908
16834	PISTON	NLA
16843	SHAFT	NLA
16845	HEAD,CYLINDER	NLA
16846	ROCKER	NLA
16848	BRACKET	NLA
16856	PUSHROD	W10 use 18967
16856	PUSHROD	W20 use 18968
16865	PISTON	NLA
16867	FILTER,FUEL	NLA
16874	WEIGHT	NLA
16876	HOUSING,PUMP	NLA
16877	TAPPET,ROLLER	NLA
16878	BOLT	NLA
16879	ROLLER	NLA
16880	BEARING	NLA
16887	BOLT	NLA
16903	STUD	NLA
16933	GASKET	NLA
16945	WASHER	NLA
16964	COVER	NLA
16989	GASKET	NLA
16993	COVER	NLA
16999	RING	NLA
17022	BOLT,BANJO	NLA
17029	CAM	NLA
17031	IMPELLER,SEA PUMP P10/20	NLA
17066	TUBE	NLA
17068	TUBE	NLA
17070	THERMOSTAT	20038
17077	GASKET	18708
17084	CLAMP	NLA
17090	GASKET SET	NLA
17091	GASKET SET	NLA
17096	BOLT	NLA
17125	PIN	NLA
17126	PIN	NLA
17141	FLANGE	18951 & 22103
17142	BOLT	NLA
17143	BOLT	NLA
17145	SETSCREW	NLA
17162	WASHER	NLA
17169	SCREW	NLA
17172	SETSCREW	NLA

Old Number	Description	New Number
17176	BOLT	17196
17177	GASKET	NLA
17182	GASKET	NLA
17185	BOLT,BANJO	NLA
17186	GASKET	NLA
17187	SETSCREW	NLA
17192	BOLT	13629
17193	WASHER	NLA
17195	NUT	15976
17199	NIPPLE	18718
17200	GASKET	NLA
17201	GASKET	16989
17202	GASKET	NLA
17214	GAUGE,WATER TEMPERATURE	NLA
17217	SHAFT,WATER PUMP W7	NLA
17235	HOUSING,FLYWHEEL HYD W80	NLA
17236	RELAY 12VDC 10A,DPDT	NLA
17240	PARTLIST P-10	19228
17242	MOUNT,FRONT LEFT & 120A W80	NLA
17244	PULLEY 7x3xA W120	NLA
17246	HOUSING,FLYWHEEL SAE-2 UR GEN	NLA
17248	MOUNT,FRONT WPDS-20	NLA
17250	GENERATOR UR 45KW 1PH	NLA
17258	MOUNT KIT,FLEXIBLE P-10	NLA
17262	BUSHING 3/8 x 1/4 NPT BRASS	NLA
17265	LEVER,THROTTLE 4-60	NLA
17268	BRACKET,THROTTLE 4-60 SAO/RB	NLA
17270	BRACKET,THROTTLE W30	NLA
17282	TEE 3/4NPTx1/2NPTx3/4NPTBRONZE	NLA
17283	HARNESS,MARINE 4-60	NLA
17292	BELT	NLA
17306	BUSHING,SNAP NYLON 0.812 DIA	NLA
17307	PLUG	30943
17312	PLUG,EXPANSION CUP 1.503 STEEL	NLA
17313	CRANKCASE	NLA
17314	STUD,CYLINDER HEAD SHORT	NLA
17315	STUD,CYLINDER HEAD LONG	NLA
17316	DIPSTICK ASSY	NLA
17317	BEARING,CAMSHAFT-FLYWHEEL END	NLA
17318	BEARING,CAMSHAFT-GEAR END	NLA
17319	BEARING,CAMSHAFT-INTERMEDIATE	NLA
17320	GASKET,GEAR COVER W7	NLA
17321	COVER,GEAR CASE	NLA
17322	DOWEL,CHAIN HOUSING	NLA
17323	SUMP	NLA
17324	GASKET,SUMP	NLA
17325	CAPSCREW,SUMP	NLA
17329	COVER,FEEDPUMP BLANKING	NLA
17330	GASKET,COVER LIFT PUMP AB1W	NLA
17331	BUSHING	NLA
17332	BUSHING,GOVERNOR SHAFT	NLA
17337	GASKET,ROCKER COVER W7	NLA
17338	ROCKER	NLA
17339	BRACKET,ROCKER	NLA
17340	HEAD,CYLINDER AB1W	NLA
17341	GUIDE	NLA
17342	VALVE	NLA
17343	COLLET	NLA

Old Number	Description	New Number
17344	CUP, VALVE	NLA
17345	SPRING, VALVE	NLA
17346	GASKET, HEAD DS/WPD3	NLA
17347	CYLINDER	NLA
17348	SHIM, CYLINDER .003	NLA
17349	SHIM, CYLINDER .005	NLA
17350	SHIM, CYLINDER .010	NLA
17351	SHIM, CYLINDER .015	NLA
17352	SHIM, CYLINDER .020	NLA
17353	PLUG, CYLINDER	NLA
17354	PLUG, CYLINDER HEAD DS	NLA
17355	PLUG, CYLINDER HEAD TO 120 AB1W	11885
17356	O-RING	NLA
17357	SHAFT, DECOMPRESSOR	NLA
17358	LEVER	NLA
17359	SCREW, ROCKER ADJUSTING	NLA
17360	ROCKER, EXHAUST	NLA
17361	BUSHING, ROCKER	NLA
17362	GASKET, ROCKER SUPPORT DS	NLA
17363	SPRING, VALVE INNER	NLA
17364	HOLDER, INJECTOR NOZZLE	NLA
17365	NOZZLE, INJECTOR	NLA
17366	WASHER, INJECTOR NOZZLE DS	NLA
17367	BRACKET, LIFTING	NLA
17368	PUSHROD AB1W	NLA
17369	PLUNGER, PRIMING	NLA
17370	O-RING	NLA
17371	CHAIN ASSEMBLY, PLUNGER	NLA
17372	BUSHING, LEVER	NLA
17374	SEAL	NLA
17375	HOUSING, BEARING FLYWHEEL END	NLA
17376	GASKET, BEARING HOUSING	NLA
17377	BEARING, MAIN FLYWHEEL END W7	NLA
17378	CRANKSHAFT FROM 547 AB1W	NLA
17379	PISTON ASSY STD AB1W	NLA
17380	RING, PISTON	18332
17381	RING, PISTON	18332
17382	RING, PISTON	18332
17383	PIN, PISTON	NLA
17384	BUSHING	NLA
17385	ROD, CONNECTING	NLA
17386	BOLT, CONNECTING ROD	NLA
17387	BEARING SET, ROD STD	NLA
17388	THRUSTWASHER, CRANKSHAFT W7	NLA
17389	GEAR, CRANKSHAFT W7	NLA
17392	BEARING, MAIN GEAR END AB1W	NLA
17393	SHAFT	23952 & 23953
17394	TABWASHER, FLYWHEEL W7	NLA
17395	SHAFT	NLA
17399	CAMSHAFT	NLA
17400	GEAR	NLA
17401	SHAFT	NLA
17402	LEVER	NLA
17403	LEVER	NLA
17404	TAPPET DS	NLA
17406	ROD, CONTROL	NLA
17407	BLOCK	NLA
17408	PIN	NLA

Old Number	Description	New Number
17409	LEVER	NLA
17413	GEAR,GOVERNOR	NLA
17415	SCREW	NLA
17416	NUT,LOCKING	NLA
17417	PLUNGER	NLA
17418	SPRING,SPEEDER	NLA
17419	SPRING	NLA
17420	BELLOWS	NLA
17423	LEVER	NLA
17424	SEAL,OIL	NLA
17427	GASKET,STOP COVER AB1W	NLA
17440	GOVERNOR ASSEMBLY	NLA
17441	SPRING,STOP LEVER	NLA
17442	HEAD,FUEL FILTER	NLA
17444	ELEMENT,FUEL FILTER 21634 HR	NLA
17446	FLANGE,EXHAUST	NLA
17447	GASKET,SILENCER W7	NLA
17448	GASKET,INTAKE MANIFOLD	NLA
17449	AIR CLEANER	NLA
17450	SEAL,AIR CLEANER	NLA
17451	ELEMENT,AIR	NLA
17452	PUMP,OIL	NLA
17454	STRAINER,OIL PUMP DS	NLA
17456	FILTER,OIL	NLA
17457	ELEMENT,OIL	NLA
17458	WASHER,OIL FILTER BOLT W7	NLA
17459	GASKET,OIL FILTER AB1W	NLA
17460	GEAR,OIL PUMP	NLA
17469	HOSE	16694
17470	SHAFT,RAW WATER PUMP DRIVE W7	NLA
17472	ADAPTER,SEA PUMP TO ENGINE DS	NLA
17473	CLIP,STRAINER	NLA
17474	PLATE,SEA PUMP TO ADAPTR DS	NLA
17475	SHIM	NLA
17476	WASHER,WATER PUMP SHAFT W7	NLA
17477	LINE,LUBE OIL CRANKCASE TO HEAD	NLA
17479	PUMP,INJECTION DS	NLA
17480	PUMP,INJECTION WPD3	NLA
17481	SHIM,LIFT PUMP 0.005 DS,W7	NLA
17482	SHIM,LIFT PUMP 0.0025 DS,W7	NLA
17483	SHIM,LIFT PUMP 0.025 DS,W7	NLA
17484	GASKET SET	NLA
17485	GASKET SET S/N 2203 UP	NLA
17486	KIT,FILTER	NLA
17488	CAPSCREW	31527
17491	FLYWHEEL	NLA
17502	SCREW,COVER TO 1635 AB1W	NLA
17504	STUD 5/16NCx5/16NFx2-1/8	NLA
17506	STUD	NLA
17508	SCREW 10x3/8	NLA
17512	PIN,SPRING 1/8x1/2	NLA
17514	DOWEL 1/8 x 11/16	NLA
17515	CIRCLIP,PISTON PIN	NLA
17519	WASHER,FLAT 5/16	NLA
17522	WASHER 5/16	NLA
17530	WASHER,FIBRE	NLA
17531	WASHER,FIBRE 1 IN	NLA
17532	WASHER	NLA

Old Number	Description	New Number
17533	SEAL	NLA
17534	O-RING	NLA
17540	HOLDER,BRUSH	NLA
17541	SPRING	NLA
17562	LINE,FILTER TO INJ PUMP DS	NLA
17563	BOLT,BANJO M12x1.5	NLA
17564	WASHER,BANJO	NLA
17565	BOLT,BANJO	NLA
17566	SCREW,BLEED INJ PUMP DS,W7	NLA
17567	WASHER,BLEED SCREW	NLA
17568	WASHER	24498
17569	PUMP,LIFT DS,W7, WPD3/4	NLA
17570	ADAPTER*FUEL FILTER	NLA
17571	BOLT,BANJO	NLA
17572	LINE,INJECTOR DS,W7	NLA
17573	LINE,LEAK-OFF TO FILTER DS	NLA
17574	BRACKET,FUEL FILTER DS,W7	NLA
17575	LINE,LIFT PUMP TO FILTER WPD3	21881
17576	BOLT,BANJO 1/4BSP	NLA
17577	UNION 1/4 BSPT	NLA
17578	WASHER,FIBRE 1/2	NLA
17579	GASKET	12670
17581	STUD,CYL HEAD	NLA
17582	BEARING,WATER PUMP	NLA
17585	PLUG	NLA
17587	GASKET,SEA PUMP TO TIMING COVR	NLA
17589	BOLT,BANJO	15424
17592	BANJO	15423
17593	SEAT,VALVE INTAKE VD SERIES	NLA
17594	SEAT,VALVE EXHAUST VD SERIES	NLA
17596	BUSHING,CAMSHAFT	18084
17597	VALVE,EXHAUST VD SERIES	NLA
17598	GASKET,HEAD REAR COVER PLATE	NLA
17599	GASKET,OIL SEAL HOUSING	NLA
17600	SCREW,ROCKER SHAFT LOCATING	NLA
17601	PLUG,ROCKER SHAFT	NLA
17608	LINE,OIL PICKUP	17845
17611	GASKET,OIL PUMP INLET W80-120	NLA
17613	PLATE	NLA
17615	GASKET,EXHAUST MANIFOLD W80	NLA
17617	GASKET,OIL PUMP OUTLET W80	NLA
17618	SUMP,OIL W80	NLA
17619	GASKET,TIMING COVER W80-120	NLA
17621	LINE,OIL	NLA
17628	DOWEL,BLOCK TO HEAD VD SERIES	NLA
17629	WASHER,COPPER	NLA
17630	PLUG	NLA
17631	VALVE	NLA
17633	NUT,LOCKING-ROCKER ADJUST	NLA
17634	SHIM,CRANKSHAFT NUT 0.010	NLA
17635	SHIM,CRANKSHAFT NUT 0.015	NLA
17636	BOLT,LOCK PLATE TO PULLEY	NLA
17637	PLUG	NLA
17638	WASHER	NLA
17639	WASHER,FIBRE	NLA
17640	DOWEL,BLOCK TO TIMING CASE	NLA
17642	DOWEL,TIMING COVER TO CASE	NLA
17643	BEARING,BALL	NLA

Old Number	Description	New Number
17644	STUD	NLA
17645	DOWEL,PUMP BRKT TO BLOCK 57VD	NLA
17647	GEAR,OIL PUMP	18077
17648	STUD	NLA
17651	DOWEL	NLA
17652	DOWEL	NLA
17653	SPACER	NLA
17655	BOLT,BANJO OIL TO ROCKERS 5/8	NLA
17661	BRACKET,ROCKER	NLA
17662	BRACKET,ROCKER	NLA
17663	BRACKET,ROCKER	NLA
17665	WASHER,ROCKER SPACER	NLA
17666	WASHER	NLA
17667	WASHER	NLA
17668	PUSHROD W80-120	NLA
17669	STUD,CYLINDER HEAD	NLA
17670	GEAR	18076
17671	GASKET	12402
17673	WASHER,PULLEY LOCK PLATE BOLT	NLA
17674	GASKET,INJECTION PMP ADPTR W80	NLA
17675	THRUSTWASHER,LOWER STD W60 NLA	NLA
17678	WASHER,CAMSHAFT GEAR W60	NLA
17681	NUT	NLA
17682	SEAT,VALVE SPRING-LOWER W60	NLA
17683	LOCKWASHER	NLA
17684	THRUSTWASHER,UPPER STD W60 NLA	NLA
17685	ROD,CONNECTING	NLA
17686	ROD,CONNECTING W60 CYL 1 & 3	NLA
17687	BUSHING,PISTON PIN	NLA
17688	BOLT,CONNECTING ROD W60	NLA
17689	LOCKWASHER	NLA
17690	CAMSHAFT W60	NLA
17692	SCREW,OIL PUMP W60	NLA
17693	NUT	NLA
17694	LINE,OIL	NLA
17696	BRACKET,ROCKER SHAFT W60	NLA
17697	RING	NLA
17698	GASKET	NLA
17699	NUT	NLA
17700	MANIFOLD	NLA
17701	GASKET,AIR FILTER TO MANIFOLD	NLA
17702	WASHER,BANJO	11943
17704	BRACKET,ROCKER SHAFT W60	NLA
17705	GEAR,CAMSHAFT W60	NLA
17706	GEAR,CRANKSHAFT W60	NLA
17707	PIN	11935
17711	SPRING,VALVE INNER W60	NLA
17712	PLUG	NLA
17713	TUBE	NLA
17714	STUD,EXTENSION ROCKER COVR W60	NLA
17716	ROCKER W60	NLA
17717	BUSHING,ROCKER	NLA
17718	PLUG	NLA
17720	DAMPER,TIMING CHAIN	NLA
17722	DOWEL	23245
17723	INSERT	NLA
17726	CRANKSHAFT W60	NLA
17727	SCREW	NLA

Old Number	Description	New Number
17734	GASKET	NLA
17735	SEAT,VALVE SPRING UPPER W60	NLA
17736	BOLT,MAIN BEARING CAP	NLA
17737	PIN,PISTON W60	NLA
17738	FLANGE	NLA
17739	LINER,CYLINDER W60	NLA
17743	SEAT,VALVE	NLA
17745	PLUG	NLA
17746	HUB,INJECTION PUMP DRIVE W60	NLA
17747	GASKET,TIMING COVER W60	NLA
17749	GASKET,INJECTION PUMP HUB W60	NLA
17750	PULLEY	NLA
17751	COVER,ROCKER 4-154	NLA
17754	STIFFENER	NLA
17755	PUMP,LIFT W60	NLA
17757	PULLEY,FRESH PUMP 4-154	NLA
17758	CIRCLIP	NLA
17759	CIRCLIP	15429
17760	CIRCLIP	NLA
17762	CIRCLIP	NLA
17765	WASHER	NLA
17766	LINE USE 17960 LGTH AS REQD	17960
17767	GASKET,TIMING COVER TO BLOCK	NLA
17768	CASE,TIMING-REAR W80-120	NLA
17769	CASE,TIMING-FRONT W80-120	NLA
17770	LINE USE 17960 LGTH AS REQD	17960
17771	GEAR,CRANKSHAFT W80-120	NLA
17772	GEAR,IDLER W80-120	NLA
17774	SHAFT,IDLER GEAR W80-120	NLA
17776	GEAR,TIMING W80-120	NLA
17777	BEARING,IDLER GEAR	NLA
17778	GASKET,IDLER GEAR BEARING	NLA
17780	RING,PISTON STD	NLA
17782	PIN,PISTON VD	NLA
17784	LINE,INJECTOR 1 W60	NLA
17785	LINE,INJECTOR 2 W60	NLA
17786	LINE,INJECTOR 3 W60	NLA
17787	LINE,OIL TO ROCKERS W80	NLA
17789	COVER,CYLINDER SIDE W120	NLA
17790	MANIFOLD,INTAKE W120	NLA
17791	BRACKET,ROCKER	NLA
17792	LINE,OIL TO ROCKERS W120	NLA
17793	PLUG	NLA
17794	GASKET,ROCKER COVER W120	NLA
17796	SCREW,CAMSHAFT BUSHING	NLA
17797	SPACER,EXH MANIF STUD	NLA
17799	IMPELLER,FRESH WATER PUMP	NLA
17801	STUD,CYLINDER HEAD	NLA
17802	LINE,INJECTOR 4 W60	NLA
17805	PULLEY,CRANKSHAFT W120	NLA
17806	DOWEL,OIL PUMP	NLA
17807	WASHER,MAIN BEARING CAP	NLA
17810	WASHER,OIL RELIEF VALVE W80	NLA
17811	SHIM,OIL PUMP 0.003	NLA
17812	SHIM,OIL PUMP 0.003	NLA
17817	NUT,CRANKSHAFT PULLEY W80-120	NLA
17826	STUD,MAIN BEARING CAP-SHORT	NLA
17827	HOUSING,REAR OIL SEAL	NLA

Old Number	Description	New Number
17828	THRUSTWASHER,UPPER	33392
17829	THRUSTWASHER,LOWER	33392
17830	CRANKSHAFT 57VD	NLA
17831	CAMSHAFT W120	NLA
17832	HUB ASSEMBLY INCL GEAR	NLA
17833	CRANKSHAFT 38VD	NLA
17834	CAMSHAFT	23863
17835	GROMMET	NLA
17836	HUB,INJ PUMP DRIVE GEAR W80	NLA
17837	SPACER,BEARING-INJ PMP W80	NLA
17838	HUB,INJ PUMP DRIVE GEAR W120	NLA
17839	LINE,OIL STRAINER TO PUMP	NLA
17840	LINE,OIL PUMP DELIVERY	NLA
17841	STRAINER,OIL VD SERIES	NLA
17842	PULLEY,CRANKSHAFT W80	NLA
17843	VALVE,OIL RELIEF	NLA
17845	LINE,OIL STRAINER TO PUMP	NLA
17846	LINE,OIL DELIVERY FOR 17937 PU	NLA
17847	DOWEL	NLA
17848	RING,SEALING LINER BOTTOM VD	NLA
17852	HEAD,CYLINDER W30 FR 786A/D444	NLA
17854	COVER,ROCKER W80	NLA
17855	COVER,ROCKER W120	NLA
17857	COVER,CYLINDER SIDE W80	NLA
17858	LINER,CYLINDER VD SERIES	NLA
17861	PISTON STD VD SERIES	NLA
17862	ROD,CONNECTING	18106
17863	BOLT,CONNECTING ROD	18108
17864	PLUG	NLA
17865	WASHER,PLUG 17864	NLA
17866	BLOCK,CYLINDER 38VD	NLA
17870	BODY,FRESH WATER PUMP VD SERIES	NLA
17872	BLOCK,CYLINDER 57VD	NLA
17873	HEAD,CYLINDER 57VD	NLA
17875	COVER,TIMING	NLA
17876	TENSIONER,TIMING CHAIN W60	NLA
17877	GASKET,CHAIN TENSIONER	NLA
17878	LOCKWASHER	NLA
17879	STUD,REAR COVER PLATE W80-120	NLA
17880	STUD,PUMP HOUSING	NLA
17881	STUD	NLA
17883	GEAR,INJECTION PUMP DRIVE W60	NLA
17885	NUT	17817
17886	NUT	NLA
17888	GASKET,FRESH PUMP TO BLOCK W50	NLA
17893	PLUG,OIL PUMP	NLA
17895	SCREW,ROCKER ADJUSTING	NLA
17898	KIT,WATER PUMP USE 17798 PUMP	17798
17900	BEARING SET,MAIN .015 W120	NLA
17906	BEARING	24115/24116 11596(2) 11597(2)
17907	RING,PISTON	NLA
17908	BEARING SET,MAIN STD W60	NLA
17910	KIT	NLA
17913	HEAD,CYLINDER W60	NLA
17914	ENGINE	NLA
17915	BLOCK	NLA
17920	GASKET	NLA
17921	ELBOW	NLA

Old Number	Description	New Number
17923	NUT,MAIN BEARING CAP STUD	NLA
17926	THERMOSTAT	24690
17934	GASKET,STRAINER TO OIL PMP W60	NLA
17936	SEAL,OIL	16519
17937	PUMP,OIL	33115
17939	MOTOR,STARTER 12VDC	23952 & 23953
17942	PUMP,INJECTION W60	NLA
17944	SHAFT,OIL PUMP	NLA
17945	RACHET,TENSIONER	NLA
17946	BOLT,OIL PUMP	NLA
17947	TENSIONER	NLA
17948	PUMP,INJECTION	17954
17949	PUMP,INJECTION	17955
17951	ELBOW	NLA
17952	PLUG	NLA
17953	FILTER	19509
17954	PUMP,INJECTION W120	NLA
17955	PUMP,INJECTION W80	NLA
17958	SOLENOID	NLA
17959	SOLENOID	NLA
17960	PIPE	NLA
17962	PUMP,FRESH WATER	17909
17964	SCREW,CAMSHAFT PLATE	NLA
17970	CAPSCREW	NLA
17971	SHIM,CYLINDER LINER 0.076MM	NLA
17972	SHIM,CYLINDER LINER 0.102MM	NLA
17973	SHIM,CYLINDER LINER 0.127MM	NLA
17976	ADAPTER,OIL LINE	NLA
17977	BUSHING,CRANKSHAFT W60	NLA
17978	PLATE	NLA
17979	NOZZLE,CAMSHAFT OIL	NLA
17980	GASKET,MAIN BEARING CAP REAR	NLA
17981	PLUG,HEAD	NLA
17982	WASHER,ROCKER SHAFT W60	NLA
17984	WASHER,FIBRE W60 HEAD PLUG	NLA
17985	SPRING,ROCKER SHAFT	NLA
17986	PLUG,OIL DRAIN	NLA
17988	NUT,CAMSHAFT GEAR	NLA
17989	SPRING	NLA
17991	LOCKNUT	NLA
17994	WASHER,OIL PUMP SPINDLE W60	NLA
17995	WASHER,OIL PUMP SCREW W60	NLA
17996	BUSHING,ROCKER COVER	NLA
17999	BOLT	NLA
18000	STUD	NLA
18001	STUD	NLA
18003	STUD	NLA
18004	STUD	NLA
18005	STUD	NLA
18006	STUD	NLA
18007	STUD	NLA
18009	STUD	NLA
18012	PLATE	NLA
18013	LINE	23847, 13344 & 13343
18015	WASHER	17620
18016	HOUSING,BEARING-INJ PMP DRIVE	NLA
18018	INDICATOR	NLA
18020	KIT,LIFT PUMP REPAIR	NLA

Old Number	Description	New Number
18022	LINE,LEAK OFF	23847, 13343 & 13344
18023	LINE,LEAK OFF-INJECTOR TO FILT	23487, 13343 & 13344
18025	LINE,LIFT PUMP TO FILTER W120	NLA
18026	SUMP,OIL W120	NLA
18032	STUD,CYLINDER HEAD	NLA
18041	LINE,INJECTOR 3 W120	NLA
18045	LINE,FILTER TO INJECTION PUMP	NLA
18047	LINE,FILTER TO INJECTION PUMP	NLA
18048	LINE,FILTER TO PUMP INLET	NLA
18063	WASHER	31765
18065	PIN	NLA
18070	KEY	NLA
18071	KEY	NLA
18072	KEY,CRANKSHAFT GEAR	NLA
18073	KEY	NLA
18074	UNION	NLA
18075	WASHER,CAMSHAFT BUSHING SCREW	NLA
18076	GEAR	NLA
18077	GEAR,OIL PUMP DRIVE W80-120	NLA
18081	HOUSING,THERMOSTAT LOWER 98	NLA
18085	PLATE,CAMSHAFT LOCATING	NLA
18087	BLOCK,CYLINDER 4/98	NLA
18091	HEAD,CYLINDER 4/98	NLA
18095	CRANKSHAFT W80 4/98	NLA
18098	RING,PISTON	22331
18099	RING,PISTON	22331
18100	RING,PISTON	22331
18101	BLOCK,CYLINDER 6/98	NLA
18102	HEAD,CYLINDER 6/98	NLA
18103	CRANKSHAFT W120 6/98	NLA
18104	DOWEL,BLOCK TO HEAD 98 SERIES	NLA
18105	STRAINER,OIL 98 SERIES	NLA
18106	ROD,CONNECTING W80-120	NLA
18108	BOLT,CONNECTING ROD	NLA
18113	GASKET	15391
18114	GASKET	14562
18116	WASHER,THRUST	15412
18117	SEAL,OIL	15411
18119	BEARING SET .020"	NLA
18120	KIT,LIFT PUMP REPAIR	18020
18121	O-RING	NLA
18122	BOWL	NLA
18124	BOLT	NLA
18126	BOLT	NLA
18127	BOLT	NLA
18128	BOLT	NLA
18129	BOLT	NLA
18130	BOLT	NLA
18131	BOLT	NLA
18133	SCREW	NLA
18134	BOLT	NLA
18135	SCREW	NLA
18136	THERMOSTAT	24688
18138	COUPLING	18176
18139	PLUG	19369
18141	PIN	NLA
18150	SLINGER	NLA
18155	COVER ASSEMBLY	NLA

Old Number	Description	New Number
18161	SEAL ASSEMBLY INCL SEAT	NLA
18168	HOUSING,SEA WATER PUMP	NLA
18177	KEY,WOODRUFF	NLA
18178	BODY,SEA PUMP P10700G	NLA
18179	HOUSING,SEA PUMP	39867
18188	SCREW,IMPELLER CVR	31862
18195	PISTON ASSY STD VIRE	NLA
18196	ROD,CONNECTING TO S/N 21999	NLA
18198	CLIP	NLA
18201	CONE	NLA
18202	CRANKSHAFT	NLA
18203	CRANKSHAFT	NLA
18207	GASKET,BLOCK TO TRANSMISSION	NLA
18208	ELBOW	NLA
18210	HOSE,WATER PUMP TO MANIF VIRE	NLA
18212	IMPELLER VIRE	NLA
18215	PLATE,WATER PUMP BODY TO TRANS	NLA
18216	HOUSING,WATER PUMP VIRE	NLA
18219	GEAR	NLA
18220	THRUSTWASHER	NLA
18221	GASKET,EXHAUST MANIFOLD VIRE	NLA
18223	GASKET,IMPELLER VIRE	NLA
18227	CYLINDER	NLA
18231	GASKET SET VIRE 7	NLA
18237	GASKET,CARBURETOR MOUNT VIRE	NLA
18245	NUT M 8 DIN 985	NLA
18247	CAPSCREW	20650, 20658 & 17320
18250	STUD	NLA
18251	STUD	15828
18254	CAPSCREW	298460
18256	PIN,SHIFT LEVER VIRE	NLA
18257	KEY	NLA
18259	BEARING,BALL	NLA
18261	PIN,CONNECTING ROD VIRE	NLA
18262	SEAL	NLA
18263	WASHER	NLA
18266	RING,RETAINING	NLA
18268	PLUG	24373
18269	PLUG	24374
18270	PLUG,MANIFOLD DRAIN	NLA
18282	CONTACT ASSY	NLA
18284	FAN,ALTERNATOR UR	NLA
18285	COVER,END	NLA
18286	STATOR,EXCITER 30-45UR	NLA
18287	DISC	NLA
18292	CLAMP	NLA
18293	KNOB,RHEOSTAT	NLA
18294	RHEOSTAT	NLA
18297	CHASSIS ASSY	NLA
18298	TRANSFORMER,VOLTAGE REFERENCE	NLA
18299	REACTOR ASSEMBLY	NLA
18302	MARKER	NLA
18305	BOARD ASSY	NLA
18307	HARNESS,REGULATOR	NLA
18309	RESISTOR	NLA
18310	RECTIFIER	NLA
18311	RECTIFIER	NLA
18312	RECTIFIER	NLA

Old Number	Description	New Number
18313	RECTIFIER	NLA
18314	SINK,HEAT	NLA
18315	RECTIFIER	NLA
18330	STATOR ASSY 30UR	NLA
18331	STATOR ASSY 45UR	NLA
18332	RING SET STD W7	NLA
18346	SHAFT,FRESH WATER PUMP	22288, 22294 & 20662
18357	ADAPTER*MOUNT UPPER 55A ALTERN	NLA
18358	REMOTE EXPANSION TANK W40 OBS	NLA
18360	TRANSMISSION 2:1 HBW10-2R	NLA
18410	KIT,LIFT PUMP/FLTR/LINES WPD4	NLA
18474	LEVER,THROTTLE	NLA
18482	PANEL WPD3	NLA
18499	LINK,THROTTLE CONTROL	NLA
18503	COUPLING .75IN BORE RV10	23692
18504	COUPLING .875IN BORE RV10	23693
18530	COUPLING 1IN BORE RV10	23694
18534	COUPLING 1.125IN BORE RV10	23695
18544	COUPLING	23697
18570	MANIFOLD	15083
18623	ADAPTER,DAMPER TO FLYWHEEL	NLA
18626	BRACKET,THROTTLE W7	NLA
18639	COVER	NLA
18651	BRACKET	NLA
18680	PULLEY	NLA
18682	SADDLE	NLA
18685	DAMPER	NLA
18696	BRACKET,ALTRN 120A	NLA
18715	RING	NLA
18718	NIPPLE	NLA
18719	HEAD,CYLINDER	NLA
18733	NIPPLE	NLA
18737	PLATE	NLA
18742	COVER,HEAD	NLA
18747	CAMSHAFT	NLA
18773	DIPSTICK	NLA
18782	ROCKER	NLA
18783	DRIVE	NLA
18788	ROCKER	NLA
18789	ROCKER	NLA
18790	ROCKER	NLA
18791	ROCKER	17196
18796	CAMSHAFT	NLA
18802	SCREW	15816
18805	CAPSCREW	NLA
18806	SETSCREW	NLA
18808	CAPSCREW	17196
18809	CAPSCREW	NLA
18810	CAPSCREW	NLA
18814	CAPSCREW	NLA
18816	CAPSCREW	17196
18817	SETSCREW	NLA
18848	PIN	NLA
18855	WASHER	NLA
18857	PLATE	NLA
18858	PLATE	NLA
18864	GASKET	NLA
18866	WASHER	NLA

Old Number	Description	New Number
18869	WASHER	NLA
18870	TUBE	NLA
18875	MOUNT	NLA
18876	MOUNT	NLA
18880	NIPPLE	NLA
18892	GAUGE	NLA
18893	CAPSCREW	17196
18896	COVER	NLA
18897	RING	NLA
18902	KIT	NLA
18904	IMPELLER	17031
18905	CAM	NLA
18906	KIT	NLA
18908	PUMP,FUEL	NLA
18921	RELAY	NLA
18923	GENERATOR	NLA
18958	GEAR	NLA
18959	GEAR	NLA
18963	GASKET SET	NLA
18964	GASKET SET	NLA
18965	GASKET SET	NLA
18967	ROCKER	NLA
18968	ROCKER	NLA
18972	ADAPTER,OIL FILTER W40NA	24264
18975	BRACKET,ALTRN 120A	NLA
18979	GASKET,THERMOSTAT HOUSING	NLA
18980	CAPSCREW 3/8NCx1-1/4 W/HOLES	NLA
18981	CAPSCREW 5/16NFx2-1/4 W/HOLES	NLA
18982	SUMP	11886 NLA
18984	BRACKET,SUPPORT REAR LIFT EYE	NLA
18985	O-RING	NLA
18988	PLATE,FAN SS3	NLA
18990	COUPLING 1.5IN BORE HBW	23712
18992	STRAP,SUMP REAR SUPPORT 4-154	NLA
18994	ADAPTER,LUBE OIL FILTER	32199
19005	WASHER,COPPER	NLA
19006	KIT,WATER PUMP	NLA
19009	SHAFT	NLA
19010	COUPLING	NLA
19011	COUPLING	NLA
19012	COUPLING	NLA
19013	COUPLING	NLA
19014	COUPLING	NLA
19015	COOLER,OIL	34681
19016	TUBE,INJECTED ELBOW 15276	NLA
19017	BRACKET,FUEL SOLENOID	NLA
19026	STRAP,SUMP REAR SUPPORT W120	NLA
19027	ENGINE 3-169	NLA
19028	MANIFOLD,EXHAUST LB49	NLA
19032	PLUG 1/8 NPT HEX HEAD NYLON	NLA
19033	CONNECTOR SS3	NLA
19040	IMPELLER,BRONZE REVERSIBLE SS1	NLA
19041	BRACKET,REGULATOR/START SOLND	NLA
19051	FAN SS3	NLA
19057	FLANGE,EXHAUST MANIFOLD 4-91	NLA
19060	ADAPTER,SEA WATER PUMP 4-154	NLA
19065	NIPPLE	32230
19066	TUBE	NLA

Old Number	Description	New Number
19072	COVER,SUMP SS3	NLA
19075	NUT	NLA
19077	FRAME SS3	NLA
19080	BRACKET,ALTNR 85-120A	NLA
19081	BRACKET,ALTNR 85-120A	NLA
19086	COOLER,OIL	22032
19087	PLUG 1/2 NPT	35747
19088	PULLEY 7x2xA 4-154	NLA
19093	KIT B W80	NLA
19097	RAIL SS3	NLA
19098	PLATE SS3	NLA
19100	HOSE,MOLDED 1-1/2 ID	NLA
19101	ADAPTER,HOSE SS3	NLA
19105	THRUHULL SS3	NLA
19106	THRUHULL SS3	NLA
19107	BRACKET,SOLENOID SS3	NLA
19110	TEE	NLA
19111	FLOWMETER SS3	NLA
19112	SCREW	NLA
19114	O-RING	NLA
19115	UNION	NLA
19116	VALVE SS3	NLA
19117	NIPPLE	NLA
19118	GASKET SS3	NLA
19119	GASKET SS3	NLA
19128	ELBOW,INJECTED	NLA
19165	METER,AMP NOVOX	NLA
19166	METER,OIL PRESSURE NOVOX	11544
19167	SENDER,OIL PRESSURE	11542
19168	METER,WATER TEMPERATURE	37601
19169	SENDER,WATER TEMPERATURE	11543
19170	GENERATOR HR 15KW 3PH 60HZ 12W	NLA
19176	TANK,LUBE OIL HR GENSET	NLA
19189	CAPSCREW	31582
19191	ADAPTER	NLA
19203	PANEL,PLATE-START/PREHEAT	NLA
19205	CABLE,HARNESS ENGINE START	NLA
19206	CABLE,START PANEL TO 19205	NLA
19207	CABLE 10 FT EXTENSION-START	NLA
19208	CABLE,HARNESS ENGINE INSTR	NLA
19209	CABLE,PANEL TO ENGINE	30148
19210	CAPSCREW	30760
19211	ENGINE SR2	NLA
19212	ENGINE SR3	NLA
19213	REGULATOR,VOLTAGE HR	NLA
19215	CABLE,PANEL GAUGE CONNECTING	33904
19219	BRACKET,OIL MANIFOLD DS	NLA
19225	BRACKET,FUEL SOLENOID HR	NLA
19227	PAN,GENSET BASE HR	NLA
19228	MANUAL,OWNER W10-20	NLA
19230	BASE,GENSET HR	NLA
19233	MANUAL,OWNER - HR GENSET	NLA
19234	SEAL,OIL	NLA
19235	FILTER,FUEL HR	NLA
19241	METER,HOUR 120VAC,RESET,2.5DIA	NLA
19242	CONNECTOR,HR-AC OUT 4 PIN MALE	NLA
19243	CONNECTOR,HR-CONTROL 19 PIN MA	NLA
19244	PANEL,OIL PRESSURE METER HR	NLA

Old Number	Description	New Number
19245	FILTER,OIL HR GENSET	NLA
19246	CONNECTOR,HR-AC OUT 4 PIN FEM	NLA
19247	CONNECTOR,HR-CONTROL 19 PIN FE	NLA
19248	CAP,EXHAUST RAIN HR	NLA
19249	BOX,BELL	NLA
19250	RECEPTACLE 15A 125 VOLT	NLA
19251	COVER,BELL BOX 19249	NLA
19256	SPACER 0.313HEX,10-32THD,3/4LG	NLA
19257	SCREW,BRASS 5/16NC X 1	NLA
19258	TERMINAL	NLA
19269	ISOLATOR	11524
19270	ALTERNATOR 12VDC, 55A W/RFI	24684
19273	HOUSING,LUBCEL	19371
19283	PANEL,START/PREHEAT-PROPULSION	NLA
19284	PANEL,START ONLY-PROPULSION	NLA
19285	PANEL,INSTRUMENT MARINE	NLA
19286	MUFFLER,HR GENSET	NLA
19287	PLUG,EXPANSION CUP 1.885 STEEL	NLA
19288	LINE,LUBCEL TO INTAKE MANIFOLD	NLA
19289	LINE,LUBCEL TO INTAKE MANIFOLD	NLA
19290	MANIFOLD,INTAKE - LUBCEL LB49	NLA
19295	SPACER,GENSET TO SUMP-HR	NLA
19298	COVER,OIL TANK-HR	NLA
19300	GASKET,OIL TANK COVER-HR	NLA
19303	PLATE,AIR DUCT HR	NLA
19304	DUCT,AIR OUT HR GENSET	NLA
19306	BOX,GENSET CTL PNL HR	NLA
19307	COVER,CHASSIS 19461-HR	NLA
19332	MANIFOLD,INTAKE 14115 LUB-CEL	NLA
19333	ADAPTER	NLA
19335	BUSHING 3/4 x 3/8 NPT STEEL	NLA
19336	ELBOW 1/2" CxC 90 COPPER WROT	NLA
19338	GASKET,LIFT EYE REAR W80-120	NLA
19344	METER,AMMETER 0-150 AC	NLA
19345	TRANSFORMER,CURRENT 150:5	NLA
19346	METER,VOLT 0-300VAC	NLA
19347	BREAKER,CIRCUIT 150A	NLA
19349	CONDUIT	NLA
19350	CONNECTOR,BOX 1/2 DIA	NLA
19360	BRACKET,COMPRESSOR W60	NLA
19361	PLATE,COMPRESSOR ADJUSTING	NLA
19380	ADAPTER,LUBCEL LINE TO MANIFLD	NLA
19392	HOUSING,FRESH WATER PUMP DS-1	22294
19404	ENGINE 1.8L	NLA
19408	TANK,SUMP SS3	NLA
19422	HOUSING,FLYWHEEL UNIV W50	N
19434	BRACKET,LUBCEL LB49	NLA
19435	BRACKET,OIL FILTER LB49	NLA
19436	SPACER 1.500OD,0.750ID,1.000LG	NLA
19437	BRACKET,FUEL FILTER LB49	NLA
19441	KIT L25	NLA
19448	PLATE,FRONT MOUNT & ALTNR DS-5	NLA
19456	LINE,LUBCEL	24261
19459	BOX,JUNCTION	NLA
19460	SCREW 10-32x1-1/8 SS	31877
19461	CHASSIS,CONTROL PANEL HR	NLA
19462	COVER,BOX 19459	NLA
19464	KIT A	23888

Old Number	Description	New Number
19465	KIT B	23889
19476	KIT A W7	NLA
19477	KIT A WPD-4KW	NLA
19483	NAMEPLATE,GOVT GENSETS	NLA
19484	PUMP,FRESH WATER	NLA
19485	EYE,LIFTING HR GENSET	NLA
19486	GUARD,CRANKSHAFT HR	NLA
19487	SCREEN	NLA
19488	DIPSTICK	NLA
19489	RAIL,GENSET SUPPORT HR	NLA
19491	BRACKET,OIL MANIFOLD HR GENSET	NLA
19492	BRACKET,OIL FILTER HR GENSET	NLA
19493	BRACKET,PANEL MNT HR	NLA
19494	BOARD,PHENOLIC 1/4TK	NLA
19497	WIRE #14/3SJO	NLA
19498	CONDUIT,GREENFIELD 1-1/2	NLA
19499	ADHESIVE,POTTING COMPOUND	NLA
19508	PUMP	11700
19511	LINE,LIFT PUMP TO FILTER W40	NLA
19578	PINION	NLA
19585	LINE,OIL FEED TO ROCKERS HR	NLA
19715	PINION	NLA
19927	TRANSFORMER	NLA
19928	FILTER	NLA
19929	RESISTOR	NLA
19930	DIODE	NLA
19931	BOARD,CIRCUIT	NLA
19932	PETCOCK	13970
19933	KIT,WATER PUMP	NLA
19936	BLOCK,BARE 108	NLA
19939	HEAD,CYLINDER 108	NLA
19941	HOUSING	12334
19943	BEARING	12332
19944	BRACKET,STOP	NLA
19947	RING,RETAINING	NLA
19948	GEAR,RING	13832
19949	GASKET	12663
19951	FERRULE,LUBE OIL DELIVERY LINE	NLA
19953	NUT 5/16-24	31760
19956	PLUG	23143
19958	PLUG,EXPANSION	NLA
19959	SEAL	not used
19961	STUD	12494
19966	LOCKWASHER	31758
19970	WASHER,BANJO	11943
19971	PLATE,DUST	not used
19972	COVER,DUST	not used
19974	GEAR,RING	NLA
19975	GASKET	12659
19980	THERMOSTAT	24688
19982	FILTER,FUEL	32974
19988	PULLEY,CRANKSHAFT	12595
19989	GEAR,INJECTION PUMP	NLA
19991	TABWASHER	14720
19993	BOLT,CRANKSHAFT PULLEY	12613
19994	CAP,TACH DRIVE METAL	12620
19997	SEAT,VALVE EXHAUST	NLA
20011	LINE,INJECTOR 3	12646

Old Number	Description	New Number
20012	LINE,INJECTOR 1	12641
20013	LINE,INJECTOR 2	12645
20014	LINE,INJECTOR 4	12647
20016	LINE,OIL	12651
20018	PLATE,FRONT	12656
20023	GASKET	NLA
20024	HOUSING,TIMING	12678
20025	BLOCK,TERMINAL	39928
20025	COVER,ROCKER	39289 & 14709
20026	COVER,ROCKER	39289 & 14709
20026	MARKER,TERMINAL	39929
20028	CONNECTOR	12009
20031	STRAINER	12686
20034	GEAR,IDLER	12689
20036	PUMP,LUBE OIL	12692
20046	RING	NLA
20047	NUT	31760
20055	LOCKWASHER	31770
20056	LOCKWASHER	31764
20057	LOCKWASHER	31758
20059	NUT	31778
20062	NUT	31766
20069	CAPSCREW	31607
20074	WASHER	NLA
20084	LOCKWASHER	31776
20111	PLUG	NLA
20121	CLAMP,HOSE	NLA
20138	THERMOSTAT,ROBERTSHAW 330F160	NLA
20139	WASHER	NLA
20141	CLAMP,HOSE	NLA
20170	GASKET	NLA
20174	GASKET	18979
20178	HOUSING,OIL PUMP	NLA
20180	PUMP,LUBE OIL	NLA
20219	BLOCK ASSY	NLA
20220	SHAFT,ROCKER	NLA
20224	CASE,GEAR	NLA
20226	COVER,GEAR HOUSING	NLA
20227	SUMP,OIL	NLA
20229	MANIFOLD,INTAKE LB49	NLA
20230	FLYWHEEL ASSY LB49	NLA
20233	INJECTOR	NLA
20239	REGULATOR	NLA
20246	RING SET	NLA
20252	HOUSING,THERMOSTAT	NLA
20254	BODY ASSEMBLY	NLA
20259	GEAR,RING	16652
20263	BEARING SET,MAIN .020 W60	NLA
20264	BEARING SET,ROD 0.1010	NLA
20266	CONTROL	NLA
20267	ELEMENT,OIL FOR 19245 FILTER	NLA
20268	ADAPTER,OIL FILTER HR	NLA
20270	SHEATHING	NLA
20271	HARNESS,GENSET HR-50-100	NLA
20275	MAGNET	NLA
20276	CONNECTOR	NLA
20277	SWITCH	NLA
20279	HOSE	NLA

Old Number	Description	New Number
20281	HOSE	NLA
20282	TAILPIPE,HR GENSET	NLA
20284	KIT	NLA
20287	ELEMENT,FUEL FILTER 19235,COAL	NLA
20288	ELEMENT,FUEL FILTER 19235,WATE	NLA
20289	GASKET,THERMOSTAT DS/W7	NLA
20292	HOUSING,THERMOSTAT W7	NLA
20294	HOSE,OIL TANK HR GENSET	NLA
20295	HOSE,OIL TANK HR GENSET	20294
20297	LINE,OIL TO BYPASS FILTER HR	NLA
20299	LINE,OIL FILTER TO SUMP HR	NLA
20389	MANUAL,OWNER SS3	NLA
20424	INJECTOR,LUBCEL	NLA
20438	WRENCH,FUEL LINE HR GENSET	NLA
20441	TRANSMISSION 1.5:1 SA0	NLA
20446	ELBOW	NLA
20447	ELBOW	NLA
20448	COUPLING	NLA
20449	UNION 1.25 NPT FEMALE	NLA
20450	TEE 1.25NPTx3/8NPTx1.25NPTBRAS	NLA
20456	INJECTOR,REBUILT W40	NLA
20476	WINGNUT 3/8-16 NC	NLA
20478	TUBE,SOLENOID TO CONDENSER SS3	NLA
20480	SCREEN,FLYWHEEL FAN GUARD HR	NLA
20481	METAL,EXPANDED	NLA
20482	SCREEN	NLA
20485	METAL,EXPANDED	NLA
20507	TUBE,OIL SUPPLY LINE-HR GENSET	NLA
20508	ELBOW	NLA
20511	PLUG 1-1/4 NPT SQ HEAD IRON	NLA
20513	ENGINE AC1W 3600	NLA
20517	MARKER,TERMINAL BLOCK	NLA
20518	TRANSMISSION 2.5:1 SA0	NLA
20519	EXCHANGER,HEAT W7,WPD4	NLA
20521	EXPORT CRATE	NLA
20528	COUPLING,GEAR HALF	NLA
20561	ELEMENT,OIL	20288
20569	FILTER,FUEL	NLA
20575	FILTER,FUEL	14776
20578	GASKET	NLA
20633	SEAL,OIL L25 TRX TO V-DRIVE	NLA
20648	ADAPTER,ISOLATOR HR GENSET	NLA
20652	ISOLATOR,PANEL	NLA
20653	GENERATOR YCB 4.5KW 1PH	NLA
20656	BRACKET,FUEL FILTER P-20	NLA
20657	WASHER,SNUBBING	24674
20662	SEAL,FRESH WATER PUMP	NLA
20663	DIESELIFE FUEL ADDITIVE	NLA
20664	ELBOW 3/4NPT x 5/8 HOSE	NLA
20666	TANK,EXPANSION W7	NLA
20668	RING,RETAINING	NLA
20673	ELBOW,WATER INJECTED 2.5NPT 45	NLA
20674	BOX,GENSET CTL PNL WPD4	NLA
20676	THERMOSTAT	NLA
20680	COUPLING,INPUT SHAFT TRX 4-60	NLA
20688	HOUSING,FLYWHEEL WPDS 10-20	NLA
20691	BRACKET,FUEL FILTER SUPPORT DS	NLA
20698	PLATE,BACK YD SERIES	NLA

Old Number	Description	New Number
20703	ISOLATOR,GENSET HD NAVY STYLE	NLA
20714	SHAFT	NLA
20715	IMPELLER	NLA
20719	GASKET SET, LOWER 4-108/ED	11763
20728	SPACER,MOUNT REAR 20 IN	NLA
20734	FILTER,FUEL DS,W7,WPD3/4	NLA
20735	STUD 3/8NFx3-1/8	NLA
20741	NUT 10-32 ELASTIC TYPE 1/4 TK	NLA
20742	ADAPTER,SEA WATER PUMP	NLA
20744	BRACKET,BILGE PUMP & FR L MNT	NLA
20746	FILTER,FUEL	NLA
20748	GENERATOR YCB 3.0KW 1PH	NLA
20749	PANEL,GENSET CONTROL WPD4	NLA
20750	ADAPTER,GENERATOR YCB TO HSG	NLA
20751	ISOLATOR,PANEL 20749	NLA
20753	STUD 5/16NCx10-3/8	NLA
20755	MOUNT,REAR WPD3-4KW	NLA
20756	PLATE,COVER PLATE	NLA
20757	HOLDER,LAMP GREEN T3-1/4MBS	NLA
20758	HARNESS,GEN PANEL 20749	NLA
20760	HARNESS,GENSET WPD-3-4KW	NLA
20914	GENERATOR YD 10KW 1PH 60HZ	NLA
20915	GENERATOR YD 15KW 1PH 60HZ	NLA
20916	GENERATOR YD 20KW 1PH 60HZ	NLA
20929	BRACKET,OIL COOLER	NLA
20934	ADAPTER,RV10S TO HBW	NLA
20936	NAMEPLATE,ENGINE ID	NLA
20938	HOSE	23909
20944	COUPLING,GENERATOR DRIVE YD	NLA
20948	SPIRALWRAP 1/4	NLA
20949	ADAPTER	NLA
20950	HOSE	34857
20952	BASE,GENSET BR30 NAVY ISOL	NLA
20962	BRUSH	NLA
20964	PANEL,PLATE YCB	NLA
20967	PLATE,MOUNT TO SUPPORT SURGE T	NLA
20972	PLATE,FRESH WATER PUMP MOUNT	NLA
20974	BLOCK,TERMINAL 4 POS 20A 2ROW	NLA
20975	MARKER,TERMINAL BLOCK 20974	NLA
20981	COUPLING	23706
20982	COUPLING	23707
20987	NUT	31756
20988	LOCKWASHER 1/4 SPLIT MED STEEL	31752
20989	LOCKWASHER	NLA
20992	BOLT,COUPLING	NLA
20999	COUPLING,GEAR HALF	NLA
21025	SCREW,BUSHING	NLA
21032	HOSE,BREATHER	22980
21042	ALTERNATOR 12/24VDC L25	NLA
21045	PLATE,DRUM ARM	NLA
21046	BEARING,BALL	14277
21049	PLATE,THRUST	NLA
21057	PIN,SPLIT-TRANSMISSION L25	NLA
21059	GEAR,TRANSMISSION MAIN SHAFT	NLA
21060	KEY,TRANSMISSION L25	NLA
21085	PIN,CAM ROLLER	21072
21087	SETSCREW,ADJUSTING CLIP	NLA
21092	VALVE,EXHAUST L25	21092

Old Number	Description	New Number
21109	CAPSCREW 3/8NCx2-1/4	31610
21113	GASKET,ROCKER COVER	21036
21117	THERMOSTAT	24688
21119	GASKET,THERMOSTAT	12663
21120	CAPSCREW 5/16NCx1	31555
21121	HOSE,THERMOSTAT L25	NLA
21128	CAPSCREW 5/16NCx1	31555
21135	MANIFOLD,EXHAUST L25	NLA
21137	LOCKWASHER	NLA
21143	CAPSCREW 5/16NCx1-1/2	31557
21146	LOCKWASHER	NLA
21147	LOCKWASHER 5/16 SPLIT MED STEE	31758
21148	LOCKWASHER	NLA
21149	LOCKWASHER	NLA
21150	NUT,AIR CLEANER STUD L25	NLA
21151	PLUG 1/2 NPT	11494
21153	CLAMP,HOSE	NLA
21154	CLAMP,HOSE 36	294387
21167	CAPSCREW 1/4NCx1/2	31501
21170	CAPSCREW 5/16NCx7/8	31554
21175	CLIP,LOCATING	NLA
21180	CAPSCREW 5/16NCx5/8	31552
21181	CAPSCREW 1/4NCx3/4	31503
21182	CAPSCREW	NLA
21183	CAPSCREW 1/4NCx1	31505
21185	LOCKWASHER 1/4 SPLIT MED STEEL	31752
21186	CAPSCREW 1/4NCx2-1/4	31510
21189	WASHER	NLA
21196	DOWEL	21190
21198	CLAMP,HOSE 20	21878
21204	BOLT,SEA PUMP	NLA
21205	WASHER	NLA
21207	CLAMP,HOSE 16	11405
21211	LOCKWASHER 1/4 SPLIT MED STEEL	31752
21212	LOCKWASHER 1/4 SPLIT MED STEEL	31752
21215	SEAT	21217
21216	SEAL	21217
21224	BLOCK,BARE L25	NLA
21230	BOLT	NLA
21239	NUT 5/16-18 NC HEX STEEL	31756
21246	PISTON STD TO S/N 28177 L25	22845
21253	BOLT,CAMSHAFT GEAR	NLA
21260	BOLT	NLA
21271	BOLT,HOUSING	NLA
21273	CAPSCREW 1/4NCx1/2	31501
21274	CAPSCREW 3/8NCx1	31605
21281	CAPSCREW,MOUNT	NLA
21282	WASHER	NLA
21286	PLATE,FRONT L25	NLA
21289	CAPSCREW,SUMP	NLA
21292	ELBOW,SUMP PLUG	21130
21298	WASHER	NLA
21299	LOCKWASHER 1/4 SPLIT MED STEEL	31752
21300	TUBE ASSEMBLY,OIL PUMP	NLA
21301	CAPSCREW 5/16NCx5/8	31552
21302	LOCKWASHER	NLA
21303	LOCKWASHER 1/4 SPLIT MED STEEL	31752
21306	CAPSCREW	NLA

WESTERBEKE SUPERSESSION LISTING

49

Old Number	Description	New Number
21307	WASHER	NLA
21308	LOCKWASHER 1/4 SPLIT MED STEEL	31752
21311	LOCKWASHER 3/8 SPLIT MED STEEL	31764
21313	PUMP,LIFT L25	NLA
21314	PRIMER,LIFT PUMP L25	NLA
21316	CAPSCREW	21136
21321	CAPSCREW	21136
21326	BOLT,BANJO	NLA
21331	WASHER	21187
21332	NUT	31760
21339	INJECTOR L25	NLA
21340	STUD,INJECTOR	NLA
21341	NUT	31760
21345	BANJO,INJECTOR LEAK OFF L25	21343
21346	LINE,INJ LEAK-OFF TO FLTR L25	NLA
21350	LINE	21349
21351	BOLT,BANJO	17650
21352	WASHER,BANJO M 8	30289
21354	WASHER,BANJO	11944
21356	CABLE,STOP L25	NLA
21363	WASHER	NLA
21364	NUT 5/16-18 NC HEX STEEL	31756
21365	LOCKWASHER	NLA
21366	WASHER,CHAIN CASE	21187
21367	CAPSCREW 5/16NCx5/8	31552
21368	LOCKWASHER	NLA
21371	LOCKWASHER M 6	NLA
21373	PIN, ANCHOR	NLA
21374	SCREW, CLIP	NLA
21379	COVER,INJECTION PUMP L25	NLA
21381	MOTOR,STARTER	21380
21382	CAPSCREW,STARTER	NLA
21383	NUT 3/8-16 NC HEX STEEL	31762
21384	LOCKWASHER 3/8 SPLIT MED STEEL	31764
21388	NUT 5/16 NYLOC	NLA
21390	CAPSCREW,ADJ STRAP	NLA
21392	CAPSCREW 1/2NCx1-1/4	31706
21393	LOCKWASHER 1/2 SPLIT MED STEEL	31776
21394	WASHER,FLAT 1/2 SAE STEEL	31777
21395	CAPSCREW 3/8NCx1	31605
21402	ELBOW,SUMP PLUG	21130
21410	ALTERNATOR 12/24VDC L25	21042
21415	ELBOW,EXHAUST	21040
21416	SCREW,SHAFT LOCK	NLA
21425	DRIVE,TACHOMETER L25	NLA
21428	DRIVE,TACHOMETER L25 ASSY	21425
21435	BRACKET,ALTERNATOR	21169
21444	PIN	21443
21449	HOLDER,LAMP AMBER T3-1/4MBB	NLA
21451	BOX,GENSET REMOTE CTL BR30	NLA
21454	HEATER,WATER JACKET 1000W,115V	NLA
21455	THERMOSTAT,HEATER 21454	NLA
21456	BOX,GENSET CTL PNL BR30	NLA
21458	METER,OIL PRESSURE	35110
21459	RESISTOR,GAUGE 24VDC TO 12VDC	NLA
21461	METER,WATER TEMPERATURE	37601
21463	METER,HOUR	NLA
21464	RELAY 24VDC 10A, DPDT	NLA

Old Number	Description	New Number
21467	BRACKET,OIL COOLER	NLA
21469	PANEL,GENSET CTL BR30DRKTR	NLA
21470	PANEL,REMOTE CONTROL BR30DRKTR	NLA
21471	HARNESS,GENSET BR30 DIRECTOR	NLA
21472	HARNESS,GEN PANEL 21469	NLA
21473	HARNESS,GEN PANEL 21470	NLA
21474	NAMEPLATE,REMOTE INDIC DEREKTR	NLA
21475	SPACER,STARTER MOTOR	NLA
21481	WINGNUT	NLA
21483	BOX,BASE KIT SPARES	NLA
21484	BOX,FIELD KIT SPARES	NLA
21486	BRACKET,IDLER PULLEY BR30	NLA
21492	MOUNT,REAR RIGHT SOLID 40H	NLA
21494	MOUNT,REAR LEFT SOLID 40H	NLA
21496	PANEL	NLA
21500	BRACKET,PANEL SUPPORT YD	NLA
21501	FILTER,PRIMARY FUEL	NLA
21502	BRACKET,PANEL PC BOARD	NLA
21503	BASE,GENSET 10-15KW YD	NLA
21509	HEATER,LUBE OIL 75W,120V	NLA
21510	HEATER KIT,LUBE OIL 75W,120V	NLA
21514	SUMP,OIL W60	NLA
21521	PANEL,GENSET CTL	15239
21528	BASE,GENSET 20KW YD	NLA
21530	ISOLATOR,GEN 250 LB	301148
21534	HARNESS,GENSET INSTRUMENT PANE	NLA
21535	HARNESS,GENSET WPDS-10-15KW	23454
21540	HARNESS,GEN PANEL TO ENG	NLA
21546	BRACKET,SEA WATER PUMP W60	NLA
21552	BRACKET,FUEL SOLENOID	NLA
21559	STANDOFF 10-32x1/2 ALUM HEX FF	NLA
21560	PULLEY,CRANKSHAFT TO APR 78	NLA
21568	STUD,CYLINDER HEAD	NLA
21570	VALVE,BREATHER	NLA
21572	HOUSING,BREATHER	NLA
21573	SEAL,OIL BREATHER	NLA
21574	SUMP	NLA
21575	CAPSCREW,SUMP	NLA
21577	TUBE,BREATHER	NLA
21579	HEAD,CYLINDER AC1W INCL VALVES	NLA
21580	SPRING,VALVE GUIDE	NLA
21582	WASHER,INJECTOR NOZZLE SHIELD	NLA
21583	CYLINDER	NLA
21584	PUSHROD AC1W	NLA
21586	HOUSING,BEARING FLYWHEEL END	NLA
21588	CRANKSHAFT AC1W	NLA
21589	PISTON ASSY STD AC1W	NLA
21590	LEVER,FUEL PUMP OPERATING	NLA
21591	ROD,CONNECTING	NLA
21595	SPINDLE,OVERLOAD/STOP	NLA
21596	LEVER,OVERLOAD/STOP	NLA
21597	UNION,MAIN BEARING HOUSING FLY	NLA
21598	LINE,OIL-CRANKCASE TO CYLINDER	NLA
21599	LINE,OIL-CRANKCASE TO MAIN BEA	NLA
21600	BOLT,BANJO,CRANKCASE	NLA
21601	BOLT,BANJO,CYL HEAD	NLA
21602	WASHER,BANJO-CYLINDER HEAD	NLA
21603	FLANGE,EXHAUST	NLA

Old Number	Description	New Number
21604	AIR CLEANER INCLUDING MANIFOLD	NLA
21605	ELEMENT,AIR CLEANER	NLA
21606	PUMP,INJECTION GEN	NLA
21607	GASKET SET,UPPER	NLA
21608	BOLT,BANJO 3/16BSP-PLATED	NLA
21609	WASHER,COPPER 3/8	NLA
21615	SOLENOID,STARTER	NLA
21625	RAW COUPLING	NLA
21630	KIT W40WC	NLA
21663	MANUAL,OWNER LB49	NLA
21668	SCREEN,AIR INTAKE COVER	NLA
21672	KIT LB49	NLA
21673	THERMOSTAT LB49	24751
21674	MOUNT,REAR LB49	NLA
21675	FILTER,FUEL SPIN-ON LB49	NLA
21677	EXTENSION,OIL PICKUP SCREEN	NLA
21678	HOUSING,FLYWHEEL	NLA
21679	PULLEY,CRANKSHAFT LB49	NLA
21681	BRACKET,CIRCUIT BREAKER	NLA
21682	PANEL,PLATE-GENSET CTL ROTARY	NLA
21684	HOUSING,FLYWHEEL HYD LB49	NLA
21686	INJECTOR,AB1W	NLA
21688	GASKET,STARTER TO BACKPLATE	NLA
21689	PLUG 2 NPT SQ HEAD IRON	NLA
21690	ADAPTER,OIL FILTER W50-60	NLA
21692	COVER*FRONT PANEL FACE	NLA
21696	BRACKET,ALTNR 120A W60 SUPPORT	NLA
21703	HOLDER,INJECTOR NOZZLE	NLA
21708	EYE,LIFTING FRONT	NLA
21710	NIPPLE 1/2 NPT x 1.5 BRASS	NLA
21718	HOUSING,WATER INLET LB49	NLA
21721	EYE,LIFTING LB49	NLA
21723	BRACKET,OIL COOLER	NLA
21727	CLAMP,COMPRESSION 9/16	NLA
21738	BRACKET,FILTERS OIL/FUEL-EYE	NLA
21739	BRACKET,SUPPORT OIL/FUEL FLTR	NLA
21740	BRACKET,SEA WATER PUMP W60	NLA
21742	GASKET,SUMP W60	NLA
21750	BELL,END	NLA
21752	CAPACITOR 100MF,200VDC	NLA
21753	BRACKET,CAPACITOR	NLA
21755	BRACKET,BATTERY CHARGER TERMNL	NLA
21756	CONNECTOR,WIRING	NLA
21757	GENERATOR YD 20KW 3PH 60HZ	NLA
21758	GUIDE,GENERATOR BRUSH	NLA
21759	BRUSH,GENERATOR	NLA
21761	SCREW,HEX CAP-GENERATOR THROU	NLA
21762	COVER,BATTERY CHARGER BRACKET	NLA
21763	POST,BINDING RED-BATTERY CHGR	NLA
21764	SLEEVE,GENERATOR SHAFT	NLA
21765	POST,BINDING BLACK-BATTRY CHGR	NLA
21766	TERMINAL,GROUND	NLA
21769	PIN, LOCATING	NLA
21772	STRAP,GROUND	NLA
21773	STUD,ROTOR THRU	NLA
21774	ADAPTER,GENERATOR	NLA
21775	COVER, END BELL	NLA
21777	HOUSING,TAB CONNECTOR	NLA

Old Number	Description	New Number
21778	HOLDER,FUSE BATTERY CHARGER	NLA
21779	FUSE 15A BATTERY CHARGER	NLA
21780	SPACER,THREADED-BATTERY CHARGR	NLA
21786	STATOR 15YD-3CN	NLA
21787	STATOR 20YD-3CN	NLA
21789	BEARING,BALL 25- 62-17-2 SEAL	NLA
21792	KEY,EXCITER ROTOR	NLA
21793	FAN,ALTERNATOR YD	NLA
21794	KEY,FAN	NLA
21795	RECTIFIER ASSEMBLY,POSITIVE	NLA
21796	RECTIFIER ASSEMBLY,NEGATIVE	NLA
21797	HOUSING,GENERATOR END YD	NLA
21800	SEAL, BEARING-O RING	NLA
21801	STUD,GENERATOR THRU	NLA
21803	BAFFLE,AIR	NLA
21804	KEY,DRIVE COUPLING	NLA
21805	STUD,ROTOR THRU	NLA
21806	BOARD,CONNECTION	NLA
21808	BREAKER,CIRCUIT	NLA
21809	TRANSFORMER,VOLTAGE REFERENCE	NLA
21810	REACTOR	NLA
21863	CLAMP	NLA
21870	CAP,PRESSURE	24306
21876	BUSHING 1.5 x 1.25 NPT STEEL	NLA
21879	BOX,GENSET CTL PNL 30KW	NLA
21880	PUSHROD	NLA
21881	HOSE,LIFT PUMP TO FILTER WPD4	NLA
21888	BRACKET,PANEL MTG YD	NLA
21889	BOX,GENSET CTL PNL WPDS10-20	NLA
21896	MOUNT,FRONT W50	NLA
21898	GAUGE,OIL PRESSURE 80PSI SW	NLA
21900	PANEL,GENSET CTL-ROTARY	NLA
21901	SCREW 6-32x3/4 SS BLACK PAN HD	NLA
21902	SCREW 8-32x3/8 SS BLACK PAN HD	NLA
21909	BEARING SET,MAIN .020 W30	NLA
21911	HEATER,WATER JACKET 750W,115V	NLA
21912	SCREW	NLA
21913	NUT	NLA
21914	SCREW	NLA
21915	SCREW	NLA
21918	O-RING	NLA
21920	SEAL	NLA
21921	SEAL	NLA
21922	SEAL	NLA
21925	RING	NLA
21926	WASHER	NLA
21927	WASHER,BANJO	11944
21928	WASHER	NLA
21929	WASHER	NLA
21930	CIRCLIP	NLA
21931	COLLAR	NLA
21932	NUT	NLA
21933	ROTOR	NLA
21934	SPRING	NLA
21935	SPRING	NLA
21936	SPRING	NLA
21937	PISTON	NLA
21938	STUD	NLA

Old Number	Description	New Number
21939	HUB,DRIVE	NLA
21942	SPRING	NLA
21943	SPRING	NLA
21944	BAR,SHUTOFF	NLA
21946	HEAD,WITH ROTOR	NLA
21948	RETAINER	NLA
21949	GASKETS	NLA
21950	SPRING	NLA
21951	SLEEVE	NLA
21952	SLEEVE	NLA
21953	SLEEVE	NLA
21954	WASHER	NLA
21955	PLATE,END	NLA
21957	SHAFT,DRIVE	NLA
21958	ARM,CONTROL	NLA
21960	CAP,DUST	NLA
21961	HOUSING,WITH PISTON	NLA
21962	STOP,IDLE	NLA
21963	SPRING,GOVERNOR	11785
21964	VALVE	NLA
21965	GASKET	NLA
21966	STUD	NLA
21967	CONN	NLA
21968	SEAL	NLA
21969	CON-SET	NLA
21970	GASKET SET	NLA
21971	RING	NLA
21972	VALVE	NLA
21973	ROD,CONNECTING	NLA
21974	PLUG	NLA
21975	CAP ASSEMBLY	NLA
21976	WASHER	NLA
21977	BALL	NLA
21978	BEARING	NLA
21979	WASHER,BANJO	NLA
21980	WASHER	NLA
21981	WASHER	NLA
21982	WASHER	NLA
21983	WASHER	NLA
21986	MOUNT,REAR BR30	NLA
21989	COUPLING,ENG TO GEN	NLA
21992	PIN,SPRING 3/16x1-3/4	NLA
21993	EXCHANGER,HEAT W60 CUPRO-NICKL	NLA
21994	BEARING	NLA
21995	BRACKET,CHARGER MOUNT TO HSG	NLA
21996	COVER,BATTERY CHARGER PROTECTI	NLA
21997	SHAFT,ALIGNMENT	NLA
21998	COUPLING,FLEX DRIVE WPD4	NLA
22014	DIODE,ZENER	NLA
22015	TRANSISTOR,POWER	NLA
22016	DIODE,RECTIFIER	NLA
22017	SINK,HEAT	NLA
22018	CHARGER,REGULATOR WPD4	NLA
22019	SPACER,SUPPORT 21996 COVER	NLA
22020	HARNESS,GEN FACEPLATE INSTRUME	NLA
22021	HARNESS,GEN FACEPLATE TO PANEL	NLA
22022	HARNESS,REGULATOR PANEL 22237	NLA
22023	BRACKET,REGULATOR	NLA

Old Number	Description	New Number
22024	DIODE,ZENER	NLA
22027	SHAFT,DRIVE	NLA
22028	COUPLING,FLYWHEEL TO FLEX COUP	NLA
22033	HOSE,EXCHANGER TO SEA PUMP	24" 11779
22034	SINK ASSY,BATTERY CHGR REGULAT	NLA
22036	SILENCER-INTAKE MANIFOLD W60	NLA
22038	CONNECTOR	NLA
22098	GASKET	NLA
22099	SCREEN	NLA
22100	ENGINE,VIRE	NLA
22101	ENGINE,VIRE	NLA
22111	SPRING,GOVERNOR	NLA
22120	RESISTOR 150 OHM	23079
22127	GASKET,HEAT EXCHR END COVER	NLA
22130	TEE	NLA
22147	PLUG M16x1.2 DIN 906 CAD	NLA
22155	RING,THRUST	NLA
22156	RING,NEEDLE BEARING	NLA
22180	SEAL,OIL	NLA
22195	RING,SEALING	NLA
22197	DIPSTICK	NLA
22207	GASKET,HBW SHIFT COVER	NLA
22221	TUBING	NLA
22229	TUBE,DIPSTICK ASSEMBLY	NLA
22237	PANEL,GENSET CTL BR30-45	NLA
22240	PULLEY	23792
22242	PUSHROD,LIFT PUMP	NLA
22243	POINTER,TIMING W80	NLA
22245	SPACER,STARTER MOTOR	NLA
22246	O-RING	NLA
22247	WASHER	NLA
22259	FILTER,FUEL SEPARATOR	32974
22265	BUSHING,TEFLON PUMP SHAFT	NLA
22266	FILTER,FUEL SEPARATOR	32974
22267	FILTER,FUEL SEPARATOR	32974
22269	BOWL,WITH PROBES-FILTER SEPARA	NLA
22270	KIT,VACUUM GAUGE RACOR FILTER	NLA
22274	GASKET,DRAIN-FILTER SEPARATOR	NLA
22275	GASKET,LID-FILTER SEPARATOR	NLA
22276	GASKET,BOWL-FILTER SEPARATOR	NLA
22277	BOWL,WITH OUT PROBES-FILTER SE	NLA
22279	BASE,GENSET 10-15KW YD RADIATR	NLA
22280	BRACKET,RADIATOR MOUNT TO BASE	NLA
22281	BRACKET,RADIATOR MOUNT TO BASE	NLA
22284	BRACKET,RADIATOR MOUNT	NLA
22292	PANEL,INSTRUMENT W7	NLA
22294	HOUSING,FRESH WATER PUMP	NLA
22299	HARNESS,GEN PANEL TO ENGINE	NLA
22300	HARNESS,GEN PANEL TO ENGINE	NLA
22304	HARNESS,GEN PANEL 21900	NLA
22305	HARNESS,GEN PANEL 22237	NLA
22309	SWITCH,SAFETY NEUTRAL-PARAGON	NLA
22312	PULLEY,CRANKSHAFT W40	NLA
22315	STRAP,ALTNR ADJUST	NLA
22318	SPACER,FAN TO PUMP PULLEY	NLA
22319	HARNESS,GEN PANEL TO ENGINE-FR	NLA
22320	ADAPTER,LUBE OIL LINES W60	NLA
22322	BRACKET,SHIFT	30756 & 2-30181

Old Number	Description	New Number
22324	PULLEY,CRANKSHAFT W50	NLA
22326	SCREW,COUPLING 7/16NCx3/4	NLA
22336	CAPSCREW M 8x20 DIN 933	17196
22340	SCREW	NLA
22341	WASHER	NLA
22343	CLIP	NLA
22354	CONTACT SET	NLA
22355	SOLENOID	NLA
22356	STUD,MANIFOLD LONG	NLA
22357	CRANKCASE ASSY	NLA
22358	CRANKCASE ASSY TO 1275 AB1W	NLA
22359	SCREW,BREATHER FROM1873 AB1W	NLA
22360	DIPSTICK ASSY FROM 1873 AB1W	NLA
22361	DIPSTICK ASSY FROM 579 AC1W	NLA
22362	SCREW,COVER FROM 1276 AB1W	NLA
22364	SPARKPLUG	NLA
22365	COVER,ROCKER BOX FROM 104 AC1W	NLA
22366	SETSCREW,COVER FROM 104 AC1W	NLA
22370	LOCKNUT	NLA
22371	ROCKER,EXHAUST FROM 474 AC1W	NLA
22372	BUSHING,ROCKER	NLA
22374	HEAD,CYLINDER AB1W TO 1240	NLA
22375	HEAD,CYLINDER	NLA
22377	GUIDE,VALVE FROM 579 AC1W	NLA
22378	GUIDE,VALVE TO 824 AB1W	NLA
22379	CUP,VALVE TO 824 AB1W	NLA
22381	STATOR ASSY 20YD 1PH	21787
22382	SPACER,BEARING	NLA
22384	STUD,INJECTOR	NLA
22385	BAFFLE,AIR	NLA
22386	BELL,END	NLA
22387	PLUG,CYLINDER HEAD FR 120 AB1W	NLA
22388	PLUG,CYLINDER HEAD FR 479 AC1W	NLA
22389	HOUSING,BEARING FLYWHEEL END	NLA
22390	GASKET,BEARING HOUSING	NLA
22391	STUD,ALTERNATOR THRU	NLA
22393	BUSHING,CONNECTING ROD	NLA
22394	WASHER,CONE SHAPED ROTOR THRU	NLA
22396	STUD	NLA
22399	BLOCK,TERMINAL	NLA
22405	COOLER,OIL	34681
22407	GENERATOR UR 50KW 3PH 60H 450V	NLA
22409	BASE,GENSET BR30CG	NLA
22410	MOUNT,FRONT RIGHT BR30CG	NLA
22411	MOUNT,FRONT LEFT BR30CG	NLA
22412	ADAPTER,GEN TO 15249 MOUNT-NO	NLA
22415	MANUAL,TECH BR30CG	NLA
22417	GOVERNOR BR30CG	NLA
22418	BRACKET,GOVERNOR CONTROL	NLA
22422	BOX,GOVERNOR CONTROL	NLA
22423	PANEL,GENSET CTL BR30CG	NLA
22430	BOX,ELECTRIC PANEL	NLA
22431	METER,TACHOMETER 0-2500RPM ELE	NLA
22432	SENDER,TACHOMETER	NLA
22433	HARNESS,GEN PANEL 22423	NLA
22434	HARNESS,GENSET BR30CG	NLA
22435	CABINET,NEMA TYPE 12,48x36x14	NLA
22436	BREAKER,CIRCUIT 50 AMP 600 VAC	NLA

Old Number	Description	New Number
22437	SHUNT TRIP FOR BREAKER 22438	22436
22438	BREAKER,CIRCUIT 100 AMP 600VAC	NLA
22439	MOUNT,CIRCUIT BREAKER TO PANEL	NLA
22440	BLOCK,TERMINAL, 60AMP,600VOLT,	NLA
22441	BLOCK-END,TERMINAL FOR 22440	NLA
22442	BLOCK,TERMINAL,110AMP,600VOLT,	NLA
22443	BLOCK-END,TERMINAL FOR 22442	NLA
22444	BLOCK,TERMINAL, 20AMP,300VOLT,	NLA
22445	BLOCK-END,TERMINAL FOR 22444	NLA
22446	SWITCH,VOLTMETER	NLA
22447	SWITCH,VOLTMETER	NLA
22448	SWITCH,FREQUENCY METER	NLA
22449	SWITCH,FREQUENCY METER	NLA
22450	SWITCH,AMMETER	NLA
22451	SWITCH,AMMETER	NLA
22452	SWITCH,VOLTAGE REGULATION	NLA
22453	SWITCH,HEATER	NLA
22454	SWITCH,SYNCHROSCOPE	NLA
22455	SWITCH,GROUND DETECTOR	NLA
22456	SWITCH,PHASE SEQUENCE	NLA
22457	METER,VOLT 0-600VAC	NLA
22458	METER,AMMETER 0-75	NLA
22459	METER,FREQUENCY 58-62HZ	NLA
22460	METER,WATTMETER 0-40KW	NLA
22461	METER,SYNCHROSCOPE W/IMPED.BOX	NLA
22462	METER,PHASE ROTATION	NLA
22463	TRANSFORMER,CURRENT 75:5	NLA
22464	NAMEPLATE,VOLTAGE CONTROL	NLA
22466	RELAY,DIRECTIONAL POWER	NLA
22467	RHEOSTAT 100 OHM,25W,5%	NLA
22468	TRANSFORMER 240/480 TO 120/240	NLA
22469	KNOB,RHEOSTAT	NLA
22470	WIRE #16 RED MIL-W-16878	NLA
22475	NAMEPLATE,FREQUENCY CONTROL	NLA
22478	FUSE 6A,600V	NLA
22479	NAMEPLATE,SHORE-BUSS INDICATOR	NLA
22481	RESISTOR 1K OHM,175W,5%	NLA
22483	MARKER,WIRE 34-66 VINYL	NLA
22484	MARKER,WIRE 00-33 VINYL	NLA
22485	MOUNT,RESISTOR 50 WATT	NLA
22487	NAMEPLATE,SWITCHBOARD MAIN	NLA
22488	NAMEPLATE,GENERATOR ISGA	NLA
22489	NAMEPLATE,GENERATOR ISGB	NLA
22490	NAMEPLATE,SHORE POWER	NLA
22491	NAMEPLATE,FUSE PANEL	NLA
22492	HOLDER,LAMP	NLA
22493	HOLDER,LAMP	NLA
22494	HOLDER,LAMP	NLA
22495	LENS,WHITE	NLA
22496	LENS,CLEAR	NLA
22498	LAMP 2.5 VOLT	NLA
22499	RESISTOR 500 OHM,50W,FXD	NLA
22500	RESISTOR 500 OHM,50W,VAR	NLA
22502	MARKER,WIRE 00-49	NLA
22503	MARKER,WIRE 50-99	NLA
22504	MARKER,CABLE 00-18	NLA
22506	TRANSFORMER 24V,2AMP	NLA
22507	DIODE	NLA

Old Number	Description	New Number
22508	BLOCK,TERMINAL 20 POS 20A 2ROW	NLA
22509	MARKER,TERMINAL BLOCK 22508	NLA
22510	BRACKET,JACKET WATER HEATER	NLA
22515	CONNECTOR	15289
22516	NAMEPLATE,FUSES-IGSA GENSET	NLA
22517	NAMEPLATE,FUSES-IGSB GENSET	NLA
22518	NAMEPLATE,FUSES-SHORE BR30CG	NLA
22519	NAMEPLATE,FUSES-BUSS BR30CG	NLA
22521	PLATE,FUSE 4 GANG	NLA
22522	PLATE,FUSE 3 GANG	NLA
22524	RELAY 12VAC 25A,SPDT	NLA
22525	RESISTOR 470 OHM,1W	NLA
22526	CAPACITOR 1400MF,30V	NLA
22529	BRACKET,FUEL SEPARATOR	NLA
22530	MOUNT,RESISTOR 25 WATT	NLA
22532	FLEXIBLE EXHAUST LINE 2.5"x16	NLA
22533	ELBOW 2.5NPT 90 MALEABLE	NLA
22540	GUARD,BELT BR30CG	NLA
22546	LAMP,NEON,B1A 1/25W	NLA
22548	GUARD,BELT BR30CG	NLA
22549	BRACKET,CIRCUIT BREAKER MOUNT	NLA
22552	RESISTOR 15K OHM,1/2W,5%,COMP	NLA
22555	CLEANER,AIR	NLA
22556	BAND,AIR CLEANER 22555 MOUNT	NLA
22557	HOOD,AIR CLEANER 22555	NLA
22558	HOSE,AIR CLEANER 22555	NLA
22560	BRACKET,AIR CLEANER MOUNT	NLA
22561	FILTER,FUEL WITH SEPARATOR	NLA
22564	HOSE 0.32ID TEFLON-STAINLESS	NLA
22566	CONNECTOR	NLA
22567	CONNECTOR	NLA
22568	CONNECTOR	NLA
22569	ELBOW	NLA
22570	ADAPTER	NLA
22571	TEE	NLA
22572	ADAPTER	NLA
22573	ELBOW	NLA
22574	ADAPTER	NLA
22575	ELBOW	NLA
22576	ADAPTER	NLA
22577	ELBOW	NLA
22578	ADAPTER	NLA
22579	ELBOW	NLA
22580	VALVE,NEEDLE 1/4NPT STAINLESS	NLA
22581	ADAPTER	NLA
22583	FLANGE,AIR INTAKE ELBOW BR30	NLA
22585	ADAPTER	NLA
22586	TEE,MALE RUN	NLA
22588	ELBOW	NLA
22589	ELBOW 1/4NPT 90 STREET SS	NLA
22591	ELBOW	NLA
22592	HOSE 0.51ID TEFLON-STAINLESS	NLA
22593	CONNECTOR	NLA
22595	CONNECTOR	NLA
22596	ELBOW	NLA
22597	LINE,BLOCK TO GOVERNOR BR30CG	NLA
22598	LINE,GOVERNOR TO BLOCK BR30CG	NLA
22599	LINE,FILTER TO INJ PUMP BR30CG	NLA

Old Number	Description	New Number
22600	LINE,INJ PUMP TO FILTER BR30CG	NLA
22601	LINE,FUEL SUPPLY TO LIFT PUMP	NLA
22603	LINE,TEE TO SEPARATOR BR30CG	NLA
22604	LINE,TEE TO FUEL FILTER BR30CG	NLA
22605	LINE,RETURN FR FILTER BR30CG	NLA
22606	LINE,BLOCK TO OP GAUGE BR30CG	NLA
22607	LINE,BLOCK TO OP SWITCH BR30CG	NLA
22610	FUSE 10A,600V	NLA
22611	CAPACITOR	NLA
22613	COVER,LID-FILTER 22561	NLA
22614	CLAMP,RETAINER-FILTER 22561	NLA
22616	HOUSING,FILTER 22561	NLA
22617	SCREW,BOWL RETAINER	NLA
22618	BRACKET,BOWL-FILTER 22561	NLA
22619	BOWL,METAL-FILTER 22561	NLA
22620	DEFLECTOR,BOWL FLOW-FILTER	NLA
22622	PLUG,BOWL-FILTER 22561	NLA
22623	PETCOCK,BOWL DRAIN	NLA
22625	GASKET,BOWL 22561 FILTER	NLA
22626	BRACKET,FUEL PLUNGER SOLENOID	NLA
22627	RESISTOR 400 OHM,25W,VAR	NLA
22628	RECTIFIER,BRIDGE	NLA
22629	TRANSFORMER,CURRENT 3000:1	NLA
22630	BRACKET,FILTER BRACKET SUPPORT	NLA
22632	STATOR,EXCITER	NLA
22634	ROTOR ASSEMBLY	NLA
22635	SINK,HEAT AND SUPPRESSOR	NLA
22637	BRACKET,OIL PRESSURE SWITCH	NLA
22638	MOUNT,CAPACITOR	NLA
22639	STUD,ALTERNATOR THRU	NLA
22640	SINK,HEAT-RECTIFIER-POSITIVE	NLA
22641	SINK,HEAT-RECTIFIER-NEGATIVE	NLA
22642	BRACKET,OVERSPEED SWITCH-BR	NLA
22827	LINE,INJECTOR 1	NLA
22829	LINE,INJECTOR 2	NLA
22831	BELT,FAN	NLA
22832	BELT,FAN	NLA
22833	WASHER,SUMP DRAIN PLUG W80-120	NLA
22835	ADAPTER,DIPSTICK & OIL FILL	NLA
22836	COVER,ROCKER BOX AC1W S/N 1885	NLA
22837	CAP,OIL	NLA
22838	CASE,GEAR SAO FROM S/N UNKNOWN	NLA
22839	GEAR,SAO	NLA
22840	BEARING	14881
22844	CONNECTOR,PUMP	NLA
22846	MOTOR,STARTER-REBUILT	NLA
22853	TOOL,SLEEVE INSTALLER	NLA
22854	WASHER,OIL LINE UNION	NLA
22855	UNION,OIL LINE-BLOCK TO INJECT	NLA
22856	PINION,STARTER	NLA
22857	REGULATOR	NLA
22900	O-RING	NLA
22902	SCREW,STOP COVER FROM 1229 AB1	NLA
22903	COVER,STOP-RUN LEVER	NLA
22904	HOSE,MANIFOLD TO CYLINDER VIRE	NLA
22905	PLATE,CAMSHAFT THRUST	NLA
22907	THRUST,GOVERNOR ASSY	NLA
22910	VALVE,RELIEF ASSY FROM 591 AC1	NLA

Old Number	Description	New Number
22913	WASHER,SPRING 5/16	NLA
22914	ISOLATOR,LONG STUD VIRE C&C	NLA
22919	BRACKET,ALTNR SUPPORT	NLA
22926	CONNECTOR,FEM 1/4 OD,1/4 HOSE	NLA
22931	PLATE,BACK INCL SEAL W60	NLA
22932	PULLEY 7x2xA W60	NLA
22938	STUD,ROTOR THRU	NLA
22940	SEAT,VALVE	NLA
22941	CELL ASSEMBLY,AIR	NLA
22943	BEARING,MAIN .010 FLYWHEEL END	NLA
22944	BEARING	NLA
22944	BEARING,MAIN .020 FLYWHEEL END	NLA
22945	PISTON ASSY .020 AC1W TO 310	NLA
22946	PISTON ASSY .020 AC1W FROM 311	NLA
22952	BEARING,ROD 0.010	NLA
22953	BEARING	NLA
22953	BEARING,ROD 0.020	NLA
22954	PLATE,CRANKSHAFT GEAR W7	NLA
22955	BEARING,MAIN GEAR END .010 AC1	NLA
22956	BEARING	NLA
22956	BEARING,MAIN GEAR END .020 AC1	NLA
22957	NUT,FLYWHEEL W7	NLA
22958	RING SET	NLA
22958	RING SET .020 FROM 311 W7/WPD4	NLA
22959	CAMSHAFT AB1W TO 1275	NLA
22960	GEAR,CAMSHAFT FROM 1276 AB1W	NLA
22961	SPACER	NLA
22962	SHAFT,EXTENSION	NLA
22963	GASKET,BEARING HOUSING	NLA
22965	BEARING,SHAFT	NLA
22966	HOUSING,BEARING ASSEMBLY	NLA
22969	SPRING,SPEEDER	NLA
22970	SPRING,SPEEDER 2500 RPM	NLA
22971	LINE,LEAK-OFF DS,WPD3	NLA
22973	LINE,LEAK-OFF W7,WPD4	NLA
22974	HOSE,FILTER TO INJ PUMP W7	NLA
22975	WASHER	17567
22976	PUSHROD,LIFT PUMP DS/WPD3	NLA
22977	PUSHROD,LIFT PUMP W7/WPD4	NLA
22978	COVER,ROCKER	21426
22988	SEPARATOR,OIL	21021
22992	MOTOR,STARTER	21037
22993	MOTOR,STARTER	20984
22994	TACHOMETER,DRIVE ASSY	NLA
22995	TACHOMETER,DRIVE ASSY	NLA
22996	FLYWHEEL ASSEMBLY W60	NLA
22997	CLAMP	NLA
22997	CLAMP,HOSE	NLA
23008	TEE,W60 INJ ELBOW BYPASS	NLA
23011	KIT A WPD4	19477
23018	SCREEN,SILENCER	NLA
23020	ELBOW 1/2" FTGxC 90 CU WROT	NLA
23021	COVER,ROCKER W60	NLA
23037	ISOLATOR,CSY YACHTS	NLA
23040	SWITCH,PRESSURE	NLA
23043	MOUNT,REAR W80-120 HD ISOLATOR	NLA
23047	CRANKCASE	NLA
23048	CRANKCASE ASSY	NLA

Old Number	Description	New Number
23049	CRANKCASE ASSY	NLA
23053	DIPSTICK ASSY	NLA
23054	DIPSTICK ASSY	NLA
23056	GASKET,FILLER CAP AC1W	NLA
23057	COVER,GEAR CASE	NLA
23059	TUBE,FILLER CAP	NLA
23060	GASKET,HEAD	17346
23061	CELL ASSEMBLY,AIR	NLA
23062	PLUG,RETAINING-AIR CELL	NLA
23063	FLYWHEEL	NLA
23065	BEARING,MAIN FLYWHEEL END W7	NLA
23066	STUD,MANIFOLD SHORT	NLA
23067	PISTON ASSY .020 AB1W	NLA
23068	PISTON ASSY .030 AB1W	NLA
23069	PISTON ASSY .040 AB1W	NLA
23073	SPINDLE,LINK ASSY	NLA
23074	LINK,CONTROL ROD ASSEMBLY	NLA
23075	ROD,CONTROL	NLA
23076	LEVER ASSY	NLA
23077	LEVER ASSY	NLA
23080	SEAL,OIL	NLA
23081	DIPSTICK,V-DRIVE	NLA
23083	PLUNGER ASSY	NLA
23084	PLUNGER ASSY	NLA
23086	SPRING,SPEEDER-3600 RPM	NLA
23087	PIN,PLUNGER	NLA
23088	CABLE,LN REGLR TO 11549 CABLE	NLA
23089	SCREW,SPEED-STOP	NLA
23090	METER,VOLT	35111
23091	SPRING,LEVER ASSY	NLA
23092	SEAL,LEAD	NLA
23093	PIPE ASSY CRANKCASE/CYLINDER H	NLA
23094	PIPE ASSY-CRANKCASE-BEARING HS	NLA
23095	BOLT,BANJO	NLA
23098	CAP,EXCHANGER RUBBER 4" 2 PASS	NLA
23099	CAP,EXCHANGER RUBBER 4" 4 PASS	NLA
23102	UNION,INSERT ASSY	NLA
23103	UNION,WATER PUMP	NLA
23104	PUMP,WATER	NLA
23109	LINING,BRAKE BAND	NLA
23110	ADAPTER,HOSE-CYLINDER HEAD	NLA
23111	STUD,WATER PUMP	NLA
23112	SHAFT,EXTENSION	NLA
23113	PUMP,INJECTION WPD4	NLA
23116	NUT	31754
23117	MOUNT,FRONT ACCEPT HD ISOLATOR	NLA
23122	MOTOR,STARTER	NLA
23123	PROTECTOR,VOLTAGE	NLA
23134	SPRING,SUPPORT 19315 HOSE	19315
23147	DOWEL 5/16 x 3/4	NLA
23148	PULLEY,CRANKSHAFT W50 MODIFIED	NLA
23149	BRACKET,THROTTLE EXTENSION W50	NLA
23150	SUMP	23201
23151	ELBOW,WATER INJECTED 2.0NPT 45	NLA
23152	ELBOW,INJECTED EXHAUST W60 45	NLA
23153	BRACKET,SUPPORT HEATER	NLA
23154	BUSHING,SAO SHAFT SUPPORT W50	NLA
23162	BRACKET,SHIFT SAO	NLA

WESTERBEKE SUPERSESSION LISTING

61

Old Number	Description	New Number
23163	MOUNT,REAR FOR 11782 ISOLATOR	NLA
23166	V DRIVE RV10D-W 1:1	NLA
23167	LINE,PREHEAT	NLA
23170	WASHER,LOCK	13072
23171	GEAR,RING	NLA
23172	FLYWHEEL ASSEMBLY	NLA
23175	GASKET	30130
23176	SEAL,OIL	16519
23177	PLATE,GEARBOX MOUNTING	NLA
23181	NOZZLE,INJECTOR	NLA
23188	HUB,INJECTION PUMP DRIVE W50	NLA
23201	SUMP,OIL W50	NLA
23202	NUT,CAP	14608
23208	SCREW.TAPPET ADJUST	14452
23209	GASKET	14501
23210	GASKET,HEAD W50	NLA
23211	WASHER,CYLINDER HEAD W60	NLA
23217	STUD,MANIFOLD TO HEAD	NLA
23218	INSERT,VALVE SEAT	NLA
23219	SEAT,VALVE INTAKE	NLA
23221	PLUG,EXPANSION CUP 0.691 STEEL	NLA
23222	PLUG,EXPANSION CUP 1.132 STEEL	NLA
23224	PUSHROD W50	NLA
23228	SHOE,CHAIN TENSIONER	NLA
23234	LOCKWASHER	14574
23238	GEAR,CRANKSHAFT	14475
23239	THRUSTWASHER	33546
23240	THRUSTWASHER	33545
23241	THRUSTWASHER	33546
23242	THRUSTWASHER	33545
23243	BEARING SET,MAIN .010 W50	NLA
23246	BUSHING	NLA
23247	BUSHING,1ST MOTION SHAFT	NLA
23248	CRANKSHAFT W50	NLA
23255	PIN,PISTON	NLA
23257	RING SET 0.020 1 CYL W50	NLA
23258	RING SET STD 1 CYL W50	NLA
23261	PISTON STD W50	NLA
23265	PLUG	NLA
23270	BLOCK,SHORT W50 TO 738B/D460	24641
23273	LINE,INJECTOR 1 W50 HYD PUMP	NLA
23275	LINE,INJECTOR 3 W50 HYD PUMP	NLA
23280	LINE,FILTER TO INJECTION PUMP	NLA
23281	LINE,INJECTION PUMP TO FILTER	NLA
23284	BEARING	NLA
23285	CARRIER	NLA
23286	GEAR,PROP	NLA
23291	STANDOFF,INJECTION PUMP TO THR	NLA
23301	TUBING	NLA
23303	ELBOW,INJECTED EXHAUST W60 FRN	NLA
23305	BUSHING 3/8 NPT x M14x1.5	NLA
23308	SWITCH,PRESSURE N/O,DP	NLA
23310	COVER,BREATHER	NLA
23318	PULLEY 6x2xA W60 CSY	23790
23323	REMOTE EXPANSION TANK L25	NLA
23334	BRACKET,ALTRN 120A W40 UP RT	NLA
23336	CABLE W60 ENG-NO PLUG CSY	NLA
23343	BATTERY RACK 2-8D	NLA

Old Number	Description	New Number
23362	BREATHER,CRANKCASE	NLA
23363	BREATHER	NLA
23372	ELBOW,INJECTED EXHAUST W80-120	NLA
23378	BRACKET,HYDRAULIC PUMP LB49	NLA
23379	COVER,TIMING CASE REAR DRIVE H	NLA
23380	SPACER,HYDRAULIC PUMP TO BRKT	NLA
23408	EXCHANGER-SEE ECN 1002	36889 or 36905
23412	FAN,PUSHER	NLA
23416	ALARM,NO BUZZER	NLA
23420	PANEL,UNGROUND	NLA
23421	SENDER KIT,UNGROUND	NLA
23427	BRACKET,THROTTLE W50-60 REAR	NLA
23429	DECAL,PUMP BLEED CAUTION	NLA
23434	SWITCH SYSTEM,WARNER NEUTRAL	NLA
23439	LINE,FUEL FILTER TO GLOW PLUG	NLA
23440	ADAPTER,PULLEY 16752 ON W60	NLA
23443	TUBE,BUNDY 1/4 X 2.13	NLA
23444	LINE,ASSY FUEL FILTER TO GLOW	NLA
23448	SEAL,ROTARY-CERAMIC FACE ASSY	34253
23451	SETSCREW 7/16-14NCx1 SQ HD	NLA
23453	COUPLING,CRANKSHAFT PULLEY W60	NLA
23454	PULLEY,CRANKSHAFT FR APR 78	NLA
23457	V DRIVE RV10D-W 2:1	NLA
23459	CLAMP,CABLE	NLA
23460	SHIM,CLAMP 23459	NLA
23461	NIPPLE,OIL FILTER	NLA
23465	CAP,RADIATOR	NLA
23468	BRACKET,ALTNR 51A EXTRA W50	NLA
23480	BRACKET,ALTNR 51A EXTRA W60	NLA
23494	CAPSCREW M 8x110	31817
23526	PULLEY 6x6xA W40 PRI	NLA
23527	CABLE W40 ENG-NO PLUG CSY	NLA
23528	COUPLING 1.25IN BORE RV10	23697
23550	HARNESS,GEN PANEL TO ENGINE-FR	NLA
23552	V DRIVE RV20D-W 2.5:1	NLA
23554	MOUNT,REAR RIGHT 3IN ABOVE CTR	NLA
23556	HOUSING,FLYWHEEL YD GEN	NLA
23565	ADAPTER	NLA
23571	SENDER,TEMPERATURE	35109
23579	GEAR,RING COMMON	NLA
23581	CABLE W30 ENG-NO PLUG CSY	NLA
23586	COUPLING	NLA
23587	ELBOW	NLA
23588	BRACKET,ALTNR 120A W50	NLA
23590	CONNECTOR,FEMALE	NLA
23591	PIN,CLEVIS	NLA
23600	SUMP,OIL BR30CG DIPSTICK OPP	NLA
23601	LINE,LEAK OFF-INJECTOR TO FILT	33749
23606	HOUSING	NLA
23609	COUPLING	23690
23610	BAFFLE,AIR-YD GENSET	NLA
23611	TRANSMISSION	NLA
23619	COUPLING,PTO MUST MATE 23629	NLA
23629	COUPLING,PTO MUST MATE 23619	NLA
23630	COUPLING,PTO RAW 23619-23629	NLA
23642	GENERATOR YD 16KW 1PH 50HZ	NLA
23643	GENERATOR YD 16KW 3PH 50HZ	NLA
23651	SCREW,COUPLING 3/8NCx3/4	NLA

Old Number	Description	New Number
23674	COUPLING 1.000 P34-P35	NLA
23675	COUPLING 1.125 P34-P35	NLA
23676	COUPLING 1.250 P34-P35	NLA
23677	COUPLING 1.375 P34-P35	NLA
23678	COUPLING 1.500 P34-P35	NLA
23679	COUPLING	23706
23680	COUPLING	23707
23681	COUPLING	23708
23682	COUPLING	23709
23683	COUPLING	23710
23684	COUPLING	23711
23685	COUPLING	23712
23695	COUPLING 1.125IN BORE RV10	NLA
23696	COUPLING	23697
23699	COUPLING,PILOT NAVY	NLA
23701	COUPLING 1.000 PM-PL TRANSMISS	NLA
23702	COUPLING 1.125 PM-PL TRANSMISS	NLA
23703	COUPLING 1.250 PM-PL TRANSMISS	NLA
23704	COUPLING 1.375 PM-PL TRANSMISS	NLA
23705	COUPLING 1.500 PM-PL TRANSMISS	NLA
23729	CARBURETOR,GAS 100-8	NLA
23730	CARBURETOR,GAS 100-6	NLA
23733	FILTER,FUEL	NLA
23746	SOLENOID	NLA
23754	FLANGE,4 EXHAUST PIPE HALF	NLA
23758	CARBURETOR,GAS 100-12	NLA
23759	ZINC,ANODE ONLY	11885
23762	CAPSCREW	31679
23763	BLOCK,SHORT 108	NLA
23782	ADAPTER,GEAR TO HOUSING W60SL	NLA
23788	PLATE,BACK W30-50-60 COMMON	NLA
23791	STUD 3/8NCx14-3/8 CHROMATE	NLA
23794	STUD 3/8NCx8-7/8 CHROMATE	NLA
23795	STUD 3/8NCx10-13/16 CHROMATE	NLA
23832	METER,VOLT	NLA
23835	BRACKET,ALTNR 51A W40LB	NLA
23841	BELT	NLA
23849	BRACKET,FUEL SOLENOID	NLA
23853	WASHER,CONNECTING ROD BUSHING	NLA
23854	CARBURETOR,GAS 200-8	NLA
23872	COVER,GENERATOR YD W/OVERSPEED	NLA
23873	SWITCH,OVERSPEED CENTRIFUGAL	NLA
23874	BRACKET,OVERSPEED SWITCH-YD	NLA
23895	PUMP,LIFT	NLA
23896	HOUSING,FLYWHEEL SAE-4 COMMON	NLA
23898	BELT	15542
23899	BRACKET,FUEL FILTER	NLA
23913	ADAPTER,LUBE OIL FEED W50	NLA
23914	MOUNT,FRONT LEFT W30	NLA
23916	BRACKET,THROTTLE W50	NLA
23930	MOUNT,FRONT RIGHT W30	NLA
23934	MOUNT,FRONT LB49	NLA
23936	BUSHING	NLA
23944	MOUNT,FRONT W60	NLA
23946	SPACER,MOUNT FRONT LEFT	NLA
23950	COUPLING .875IN BORE	NLA
23953	MOTOR,STARTER 12VDC COM GENSET	NLA
23957	BRACKET,PUMP	33476

Old Number	Description	New Number
23962	BRACKET,ALTNR 51A W58	33476
23977	HEATER,WATER JACKET 2000W,115V	NLA
23979	REGULATOR,VOLTAGE UR	NLA
23980	TRANSFORMER,VOLTAGE REFERENCE	NLA
23991	ADAPTER,BULKHEAD	38275
23997	HUB,IDLER GEAR	NLA
23998	PLUG,TAPER BRASS	NLA
24008	THRUHULL,SG SEA WATER	NLA
24029	BRACKET,ALTNR 51A EXTRA	NLA
24030	STRAP,ALTNR ADJUST	NLA
24035	BOLT 3/4NCx7/8 HEAVY HEX HEAD	NLA
24038	BRACKET,ALTNR 85-120A W58 PRI	33476
24041	RELAY 24VDC 12A,SPNO	NLA
24042	RELAY 24VDC 15A,DPDT	NLA
24045	BLOCK,SHORT W50	NLA
24046	LINER,CAMSHAFT BEARING	NLA
24048	HEAD,CYLINDER W50	24641
24050	ENGINE 2.5L	34920
24062	BRACKET,OIL COOLER	NLA
24064	FLYWHEEL ASSEMBLY W40	NLA
24065	BRACKET,REGULATOR,BREAKER	NLA
24071	PLUG,DIPSTICK HOLE IN BLOCK	NLA
24074	FLANGE INCL INJECTED ELBOW	NLA
24081	ELBOW,INJECTED EXHAUST 45WLF	NLA
24082	ELBOW,EXHAUST SG	NLA
24086	CAPSCREW 3/8NCx3/4 SOCKET FLAT	NLA
24112	ELBOW,WATER INJECTED 45KW	NLA
24113	ELBOW,WATER INJECTED	NLA
24114	BRACKET,COMPRESSOR W50 L RIGHT	NLA
24120	RAIL,LEFT COMPRESSOR FRONT W50	NLA
24121	RAIL,RIGHT COMPRESSR FRONT W50	NLA
24124	NUT,FLYWHEEL TO CRANKSHAFT	NLA
24126	COMPRESSOR KIT W60 SIDE FIELD	NLA
24129	BELT	NLA
24130	NAMEPLATE,GENERATOR ID	NLA
24131	BOLT 3/4NCx2-3/4 HEAVY HEX HD	NLA
24133	METER,OIL PRESSURE	35110
24142	TABWASHER,FLYWHEEL W30 COMMON	NLA
24143	PUMP,SEA WATER	37431
24144	CLAMP,EXHAUST ELBOW-SPLIT	NLA
24148	HOUSING,FLYWHEEL SAE-5	NLA
24152	SPACER,THROTTLE CABLE SUPPORT	NLA
24167	HARNESS,GEN PANEL TO ENGINE	NLA
24176	CONNECTOR,FEMALE	NLA
24178	REMOTE EXPANSION TANK W60	NLA
24181	ALARM,NO BUZZER W50	NLA
24191	CABLE W30 ENG-NO PLUG CSY	NLA
24208	ELBOW,INJECTED EXHAUST W40 90D	NLA
24209	ELBOW,INJECTED EXHAUST W30-50	NLA
24214	KIT,FUEL PRESSURE SWITCH	NLA
24216	CONNECTOR,FEMALE	NLA
24225	BLOCK,TERMINAL	NLA
24226	ELBOW,EXHAUST TO MANIF HORIZ	NLA
24230	ADAPTER,HYD GEAR TO SAE-5 HSG	NLA
24235	BASE,GENSET BR45	NLA
24239	HOSE,RETURNBEND	33527
24240	CAPSCREW 3/8NCx1-1/2 SOCKET HD	NLA
24241	CAPSCREW 3/8NCx2 SOCKET HEAD	NLA

Old Number	Description	New Number
24257	HOUSING	32154
24272	BRACKET,SHUNT & OIL MANIFOLD	NLA
24274	MANIFOLD,EXHAUST W58	NLA
24276	MANIFOLD,EXHAUST W21	35357
24280	SEAL,WATER PUMP	NLA
24287	CABLE W50 ENG-NO PLUG CSY	NLA
24296	FLYWHEEL ASSEMBLY SAE-5 W21-27	NLA
24308	EXCHANGER-SEE ECN 1002	36889 or 36905
24309	COOLER,OIL	34484
24314	MOUNT*FRONT-ADAPTS ISOLATOR TO	NLA
24315	MOUNT,FRONT ISOLATOR TO SADDLE	NLA
24326	ADAPTER,SILENCER TO MANIFOLD	NLA
24340	HEAD,CYLINDER W58 5/16NF STUD	NLA
24356	RING SET STD 1CYL	31048
24357	RING SET	NLA
24358	RING SET	NLA
24359	RING SET	NLA
24360	PISTON	NLA
24361	PISTON	NLA
24362	PISTON	NLA
24381	PLUG	24374
24387	BOLT,MAIN BEARING CAP	NLA
24388	STIFFENER,SUMP FRONT	NLA
24396	SEAL,OIL	31056
24397	GASKET,TIMING COVER	NLA
24406	GASKET	12661
24412	TABWASHER,FLYWHEEL	24142 - 3 each
24433	SHAFT,ROCKER	NLA
24460	CLAMP,FUEL LINE CHANNEL	NLA
24464	LINE,FILTER TO INJ PMP W58	NLA
24474	GASKET,FRESH WATER PUMP W58	NLA
24499	WASHER,BANJO	11943
24502	BANJO,FUEL RETURN FROM INJ PMP	NLA
24515	KEY,WOODRUFF	32904
24518	FLANGE,WATER PUMP PULLEY	NLA
24520	PLUG	24345
24522	COVER,ROCKER W58	NLA
24524	ROD,CONNECTING	NLA
24526	NUT,LOCKING-ROCKER COVER	NLA
24532	LINE,INJECTOR 4 W58	NLA
24533	GEAR,INJECTION PUMP DRIVE	NLA
24537	SPRING,GOVERNOR W58	NLA
24538	KIT,WATER PUMP	24557
24539	HOSE,BREATHER	NLA
24541	BODY,FRESH WATER PUMP	NLA
24543	BLOCK,SHORT W58	NLA
24549	FILTER,FUEL	NLA
24550	LINE	36372
24552	PLUG	30977
24561	SUMP,OIL	NLA
24566	BLOCK,BARE W58,71B	NLA
24569	PUMP,INJECTION W58	NLA
24578	COVER ASSEMBLY-ALTERNATOR-NO R	NLA
24591	DIPSTICK	24976
24593	EYE,LIFTING	30131
24616	TANK,SURGE W58 MANIFOLD SIDE	NLA
24622	BRACKET,THROTTLE W58	NLA
24628	PANEL,PLATE-MARINE INSTRUMENT	NLA

Old Number	Description	New Number
24629	TRANSMISSION 2:1 HBW 50	NLA
24630	TRANSMISSION 1.8:1 HBW100	NLA
24632	TRANSMISSION 2.1:1 HBW220	32565
24640	SILENCER,INTAKE	NLA
24641	HEAD,CYLINDER W50 FR738B/D1741	NLA
24650	HOUSING,SEA WATER PUMP	NLA
24660	PANEL,INSTRUMENT	33860
24667	HARNES	30092
24670	COVER,SUMP OIL LEVEL SENDER	NLA
24675	DRIPTRAY	33744
24676	BRACKET,COMPRESSOR MOUNT W58	NLA
24677	BRACKET,COMPRESSOR SUPPORT W58	NLA
24679	BRACKET,PANEL MTG YD	NLA
24681	V DRIVE RV20D-P 2:1	NLA
24685	ALTERNATOR	24684
24691	ELBOW,INJECTED EXHAUST W58 FR	NLA
24696	BELT	31152
24702	GASKET,MANIFOLD FLANGE TO EXHA	NLA
24703	MOUNT,FRONT 15-20 WMF/WTA	NLA
24705	DECAL,GEN CTL-PREHEAT-START-ST	NLA
24706	HOUSING,FLYWHEEL SAE-3	NLA
24708	COUPLING 1IN BORE PM-PL	NLA
24709	COUPLING 1.125IN BORE PM-PL	NLA
24710	COUPLING 1.250IN BORE PM-PL	NLA
24711	COUPLING 1.375IN BORE PM-PL	NLA
24712	COUPLING 1.5IN BORE PM-PL	NLA
24713	TRANSMISSION 1:1 HYD PM	NLA
24714	TRANSMISSION 1.5:1 HYD PM	NLA
24715	TRANSMISSION 2:1 HYD PM	NLA
24716	TRANSMISSION 2.5:1 HYD PM	NLA
24717	TRANSMISSION 3:1 HYD PM	NLA
24722	FLYWHEEL ASSEMBLY COMMON W30	NLA
24723	FLYWHEEL ASSEMBLY COMMON W40	NLA
24724	FLYWHEEL ASSEMBLY COMMON W50	NLA
24725	FLYWHEEL ASSEMBLY W52-58-100	NLA
24726	FLYWHEEL ASSEMBLY COMMON W60	NLA
24727	FLYWHEEL ASSEMBLY COMMON WPO	NLA
24728	FLYWHEEL ASSEMBLY 15-20-32KW	NLA
24729	GENERATOR 30KW 1PH 60HZ 4WIRE	NLA
24730	COMPRESSOR KIT W58 SIDE FIELD	NLA
24736	ELBOW,INJECTED EXHAUST W30-50	NLA
24740	PANEL,GENSET CTL-TOGGLE	30781
24742	PANEL,PLATE GENSET CTL TOGGLE	NLA
24744	ELBOW,EXHAUST TO MANIF W50	NLA
24750	ELBOW,HOSE	NLA
24755	ENGINE	34931
24756	ENGINE	34938
24757	ENGINE	34977
24758	ENGINE	34979
24759	GENERATOR 4.0KW 1PH 60HZ 3WIRE	NLA
24760	GENERATOR 8.0KW 1PH 60HZ 3WIRE	33396
24761	GENERATOR	30864
24764	SILENCER,INTAKE 11 WMD	NLA
24782	BOLT,BANJO-SUMP M18x1.5	36819
24783	GUARD,AIR DUCT SAE-4 HOUSING	NLA
24788	GUARD,AIR EXHAUST	NLA
24822	HOUSING,SEA WATER PUMP 24143	NLA
24825	COVER,IMPELLER PUMP 24143	NLA

Old Number	Description	New Number
24831	PUMP,LIFT 12VDC INCL FILTER	039275
24845	BRACKET,THROTTLE	NLA
24849	BRACKET,SOLENOID-BREAKER-EYE	NLA
24880	PANEL,INSTRUMENT MARINE-KEY	33866
24883	ALTERNATOR 24VDC, 70A W/REG	NLA
24888	MOTOR,STARTER 24VDC	NLA
24897	BOLT,BANJO-SUMP 1/4-19G BSPT	NLA
24901	BOLT,BANJO-SUMP M14x1.5	36821
24908	FLYWHEEL ASSEMBLY SAE-5 W13	NLA
24909	FLYWHEEL ASSEMBLY SAE-5 W33	NLA
24918	NAMEPLATE	32122
24919	WASHER,SEA PUMP TO 24943 BRKT	NLA
24967	BELT	NLA
24969	WASHER,BANJO	11943
24970	WASHER,BANJO	11944
24971	WASHER,BANJO	11945
24973	WASHER,BANJO M18	36493
24981	SPRING,IDLE STOP ASSEMBLY	NLA
24982	GASKET,HEAD W50	23210
24985	FILTER,FUEL SEPARATOR	32974
24986	NAMEPLATE	35411
24992	MOUNT,FRONT 4.4 WMD	NLA
24993	FILTER,PRIMARY FUEL	32974
30004	SPACER,SEA WATER PUMP BRACKET	NLA
30010	BRACKET,LIFT PUMP,SOLENOID,FLT	NLA
30011	SADDLE,FRONT MOUNT	24319
30019	SILENCER,INTAKE W27	NLA
30026	SILENCER,INTAKE 8KW	NLA
30027	CLAMP,EXHAUST MANIFOLD ELBOWS	NLA
30029	MOUNT,REAR 30 WLF	NLA
30030	PANEL,FRONT-SHEET SG 4.4 WMD	NLA
30031	DUCT,AIR OUT SG 4 WMD HATTERAS	NLA
30032	PANEL,REAR-SHEET SG 4.4-7.7WMD	NLA
30033	DUCT,AIR IN SG 4 WMD HATTERAS	NLA
30034	PANEL,FRONT-SHEET SG 7.7 WMD	NLA
30035	MOUNT,FRONT LEFT 30 WLF	NLA
30036	MOUNT,FRONT RIGHT 30 WLF	NLA
30037	BRACKET,IDLE STOP ASSEMBLY	NLA
30038	SCREW,IDLE STOP ASSEMBLY	NLA
30039	LINK,IDLE STOP ASSEMBLY	NLA
30041	MANUAL,TECH W13-18-21-27-33	NLA
30050	WASHER	NLA
30058	SPRING,INSULATOR RETAINING	21122
30061	ADAPTER,HBWV	NLA
30070	PULLEY,CRANKSHAFT 6x2xO W40	NLA
30072	LINE,LIFT PUMP TO FILTER	34741
30084	LINE,LIFT PUMP TO FILTER	34614
30088	LINE,INJECTORS TO FUEL RETURN	33424
30096	SWITCH,TEMP 204F	39550
30099	BOLT,BANJO	24915
30100	WINGNUT 5/16-18 NC NYLON LOCK	16035
30112	SPACER,SILENCER TO MANIFOLD	NLA
30114	STUD	31592
30118	SILENCER,INTAKE W33 POLY	NLA
30122	MANIFOLD,EXHAUST EXTRUDED W50	NLA
30123	BRACKET,PANEL MTG 4.4KW	NLA
30126	MANIFOLD,EXHAUST	15564
30127	BRACKET,PANEL PC BOARD YD	NLA

Old Number	Description	New Number
30135	SILENCER,INTAKE 12.5 WMD POLY	NLA
30138	PIN,SPRING 1/16x5/16	NLA
30140	TRANSMISSION 1.5:1 HBW100	NLA
30149	TUBE,MANIFOLD TO FW PUMP	NLA
30150	SILENCER,INTAKE W58 POLY	NLA
30151	SILENCER,INTAKE 20KW 12 HOLE	NLA
30155	BRACKET,FUEL FILTER W52	NLA
30156	SILENCER	35241
30157	SILENCER	35242
30158	STANDOFF 10-32x5/16NCx4-1/4 F	NLA
30169	IDLE STOP ASSEMBLY W13-33	NLA
30170	CAPSCREW	31721
30179	LINE,OIL ADAPTER TO COOLER W52	NLA
30180	LINE,OIL COOLER TO ADAPTER W52	NLA
30184	BRACKET,ALTNR 51A EXTRA W80	NLA
30188	TUBE,MANIFOLD TO FW PUMP	NLA
30194	GASKET,OIL FILL CAP W13	30298 CAP,OIL FILL W/GASKET
30212	RETAINER,FUEL FILTER	46669
30214	NIPPLE,OIL FILTER	47123
30216	WASHER,CRANKSHAFT PULLEY	NLA
30220	FILTER,LUBE OIL	36918
30233	FILTER,LUBE OIL	35828
30236	SEAT,VALVE SPRING UPPER	NLA
30292	SEAL,LEAD	37393
30293	WIRE,LEAD SEAL ON GOVERNOR	37393
30296	PLUG 3/8-19 BSPT HEX HD BRASS	NLA
30303	PLATE,CRANKSHAFT	NLA
30321	LEVER,GOVERNOR SPRING	NLA
30333	GLOWPLUG	24353
30343	COVER,ROCKER	NLA
30347	CASE,GEAR	NLA
30349	SUMP,OIL K2C	NLA
30351	BOLT,CONNECTING ROD	36914
30352	CRANKSHAFT	NLA
30359	CAMSHAFT	NLA
30364	PUMP,INJECTION	31283
30368	SPRING,GOVERNOR W13	NLA
30371	LEVER,GOVERNOR SPRING	NLA
30377	ADAPTER,FRESH WATER PMP TO BLK	NLA
30381	STRAP,ALTNR ADJUST	NLA
30388	BLOCK,BARE W33	NLA
30406	COVER,ROCKER W33	NLA
30414	PISTON	37290
30421	RING SET	37282 & 37290
30422	RING SET	37283 & 37291
30423	RING SET	37284 & 37292
30424	RING SET	37285 & 37293
30425	PISTON STD	37683
30426	PISTON 0.25	37684
30427	PISTON 0.50	37685
30428	PISTON 0.75	37686
30429	PISTON	37291
30430	PISTON	37292
30431	PISTON	37293
30433	CAMSHAFT	30547
30436	CAMSHAFT	37281
30444	LINE,INJECTOR 2 W33	NLA
30445	LINE,INJECTOR 3 W33	NLA

Old Number	Description	New Number
30455	COVER,INJECTION PUMP GOVERNOR	NLA
30462	GASKET	30225
30465	STRAINER,OIL PICKUP FLANGE W33	NLA
30466	GASKET,OIL PICKUP	NLA
30468	DRIVE,TACHOMETER ASSEMBLY	NLA
30469	HOUSING,BEARING-PUMP GEAR	NLA
30500	SUMP,OIL-BOTTOM DRAIN	34673
30501	BLOCK,BARE	NLA
30502	BLOCK,BARE	NLA
30504	HEAD NLA S/N REQD FOR NEW P/N	37287 & 37280
30505	HEAD,CYLINDER	NLA
30531	BEARING SET REPL ALL	37673
30532	BEARING SET REPL ALL	37680
30533	BEARING SET REPL ALL	37681
30534	BEARING SET REPL ALL	37682
30536	PULLEY	32181 3CYL
30536	PULLEY	32182 4CYL
30537	CRANKSHAFT	NLA
30539	CAMSHAFT	37280
30540	CAMSHAFT	37279
30580	ROD,TIE	33275
30585	STRAINER,OIL PICKUP M14-W21	NLA
30586	STRAINER,OIL PICKUP M14-W27	NLA
30594	ALTERNATOR 12VDC, 50A	49246 "L"
30594	ALTERNATOR 12VDC, 50A	49249 "K"
30600	HOLDER,DELIVERY VALVE	NLA
30602	SLEEVE,PLUNGER CONTROL	NLA
30603	TAPPET,INJECTION PUMP	NLA
30604	PIN,TAPPET GUIDE	NLA
30605	PLATE,INJECTION PUMP	NLA
30606	SCREW,PLATE ADJUSTING	NLA
30615	SEAT,LOWER PLUNGER SPRING-INJE	NLA
30617	SPRING,PLUNGER-INJECTION PUMP	NLA
30618	RIVET,INJECTION PUMP NAMEPLATE	NLA
30633	STOPPER,INJECTION PUMP NO 07	NLA
30637	STOPPER,INJECTION PUMP NO 11 W	NLA
30640	STOPPER,INJECTION PUMP NO 14 W	NLA
30651	BOLT,BANJO	16988
30652	STOPPER,INJECTION PUMP NO 27 W	NLA
30655	STOPPER,INJECTION PUMP NO 30 W	NLA
30656	STOPPER,INJECTION PUMP NO 31 W	NLA
30657	STOPPER,INJECTION PUMP NO 32 W	NLA
30658	STOPPER,INJECTION PUMP NO 33 W	NLA
30659	STOPPER,INJECTION PUMP NO 34 W	NLA
30660	STOPPER,INJECTION PUMP NO 35 W	NLA
30667	STOPPER,INJECTION PUMP NO 16 W	NLA
30671	STOPPER,INJECTION PUMP NO 25 W	NLA
30672	STOPPER,INJECTION PUMP NO 26 W	NLA
30673	STOPPER,INJECTION PUMP NO 27 W	NLA
30674	STOPPER,INJECTION PUMP NO 28 W	NLA
30675	STOPPER,INJECTION PUMP NO 29 W	NLA
30676	STOPPER,INJECTION PUMP NO 30 W	NLA
30677	STOPPER,INJECTION PUMP NO 31 W	NLA
30678	STOPPER,INJECTION PUMP NO 32 W	NLA
30679	STOPPER,INJECTION PUMP NO 33 W	NLA
30680	STOPPER,INJECTION PUMP NO 34 W	NLA
30681	STOPPER,INJECTION PUMP NO 07 W	NLA
30714	PLUG	24373

Old Number	Description	New Number
30715	PLUG	24349
30716	PLUG	33657
30740	SILENCER,INTAKE W50	NLA
30744	HOSE KIT	31172
30753	BRACKET,SOLENOID-BREAKER	NLA
30755	LINE,FILTER TO INJECTION PUMP	32485
30757	TUBE,MANIFOLD TO FW PUMP	NLA
30758	MANIFOLD,EXHAUST	12411
30766	ADAPTER M12x1.5 MALE TO 1/8NPT	NLA
30769	MOUNT,REAR	24832
30776	ADAPTER,OIL FILTER	32444
30781	PANEL,GENSET CTL-TOGGLE	NLA
30788	TRANSMISSION 1:1 S1000	NLA
30789	DAMPER,S1000-1500	NLA
30791	V DRIVE RV10D-R 2:1	NLA
30809	RECTIFIER	43649
30821	FIELD COIL ASSEMBLY 8KW	NLA
30823	PIN,ANTI-ROTATION	NLA
30824	ARMATURE 12.5KW,60HZ,3WIRE	NLA
30825	ARMATURE 8KW,60HZ,3WIRE	NLA
30826	ARMATURE 4KW,60HZ,3WIRE	NLA
30847	HOSE	30845
30860	GENERATOR 4.0KW,1PH,60HZ,2WIRE	NLA
30861	GENERATOR 3.2KW 1PH 50HZ 2WIRE	NLA
30862	GENERATOR 8.0KW 1PH 60HZ 4WIRE	33396
30863	GENERATOR 6.4KW 1PH 50HZ 4WIRE	NLA
30864	GENERATOR 12.5KW 1PH 60HZ	NLA
30865	GENERATOR 10KW 1PH 50HZ 4WIRE	NLA
30870	ENGINE,BLOCK ASSY W40	NLA
30875	GENERATOR 20KW 1PH	37994
30877	SKIRT,FRONT 21.125 WMD-6-8KW	NLA
30878	SKIRT,REAR 21.125 WMD-6-8KW	NLA
30879	SKIRT,SIDE WMD-6-8KW	NLA
30881	POST,CORNER 21.062	NLA
30882	RAIL,END 21.125	NLA
30883	RAIL,SIDE 40.000	NLA
30884	PANEL,SG TOP 6-8 WMD	NLA
30885	PANEL,SG SIDE 6-8 WMD	NLA
30886	PANEL,SG FRONT 6-8 WMD	NLA
30887	PANEL,SG REAR 6-8 WMD	NLA
30889	ELBOW 1.5NPT 45 MALEABLE	NLA
30893	NUT,ANCHOR 1/4NF,.458OD,.562LG	38772 & 31503
30894	STANDOFF 6-32x3/8	NLA
30900	GENERATOR 20KW 3PH 60HZ .8PF	NLA
30905	PANEL,TOP-SHEET SG 7.7 WMD	NLA
30906	PANEL,SIDE-SHEET SG 7.7 WMD	NLA
30915	PULLEY 7x2xA W80 C&C	NLA
30916	BRACKET,ADJUSTING STRAP	NLA
30923	PANEL,SIDE-SHEET SG 4.4 WMD	NLA
30925	PLENUM,DISTRIBUTION SG 4.4-7.7	NLA
30929	PANEL,TOP-SHEET SG 4.4 WMD	NLA
30930	COUPLING .75IN HBWV	20981
30931	COUPLING .875IN HBWV	20982
30932	COUPLING 1.000 HBWV	11740
30933	COUPLING 1.125 HBWV	11741
30936	SILENCER,AIR INTAKE	43262
30940	DAMPER,BW-3-7-12-JS	56032
30942	COVER,MARINE INST PANEL-NO KEY	NLA

Old Number	Description	New Number
30944	SWITCH,OIL PRESSURE	34761
30949	TRANSMISSION 2:1 BW3	NLA
30963	GASKET,LUBE OIL ADAPTER	NLA
30968	GASKET,LUBE OIL ADAPTER	NLA
30971	WASHER,INJECTOR	14464
30976	SEAL,OIL	40304
30978	HEAD,CYLINDER S2	NLA
30981	HOUSING,THERMOSTAT LOWER S2	NLA
30992	CASE,TIMING S2	NLA
30994	COVER,TIMING CASE S2	43163
31000	CRANKSHAFT,BOLT 5/8NF,6.3MM S2	NLA
31003	GEAR,FRICITION	32749
31010	PUSHROD S2	NLA
31013	GEAR,CAMSHAFT	NLA
31017	CAMSHAFT S2	NLA
31018	MANIFOLD,INTAKE S2	40483
31019	INJECTOR USE 32743	32743
31023	LINE,INJECTOR 2 S2	NLA
31025	LINE,INJECTOR 4 S2	NLA
31026	PUMP,INJECTION	32509 GEN
31026	PUMP,INJECTION W52	36193 PROP
31034	PUMP,FRESH WATER	32213
31035	PLATE,FRESH WATER PUMP W52	NLA
31041	BEARING SET,ROD 0.76 W52	NLA
31045	BEARING SET,MAIN 0.76 W52	NLA
31049	SPRING,GOVERNOR W52	NLA
31053	GASKET SET,UPPER	32051
31054	KIT,WATER PUMP 32213	32213
31055	SEAL,OIL	24480
31058	SUMP,OIL S2	NLA
31064	RETAINER,POLE SHOE	NLA
31081	ARMATURE 8KW,60HZ,4W	33812
31082	ARMATURE 12.5KW,60HZ,4WIRE	NLA
31094	HOUSING,WATER HEATER DIVERTER	NLA
31102	PULLEY,CRANKSHAFT 5 MM KEY	NLA
31109	PULLEY,ALTNR 120A MOT W52	NLA
31127	HARNESS,MARINE W30-40-50	NLA
31130	HARNESS,MARINE W80	NLA
31131	HARNESS,MARINE W120 8 WIRE	NLA
31134	HARNESS,GENSET	31133
31141	PLATE,TIMING COVER	NLA
31142	COUPLING	11742
31143	COUPLING	11743
31144	COUPLING	18990
31153	FLANGE,AIR INTAKE SG	NLA
31159	SPACER 1.000OD,0.516ID,0.875LG	NLA
31160	NIPPLE	34424
31162	LINE,INJECTOR RETURN W120	NLA
31167	BRACKET,PANEL-GENSET CONTROL	NLA
31171	EYE,LIFTING	NLA
31174	SILENCER,INTAKE	35242
31183	HEAD,FILTER	NLA
31200	STRAP,ALTNR ADJUST 7.7 SG	NLA
31212	SILENCER,INTAKE W70	37449
31213	SILENCER,INTAKE 25 WMF	37450
31226	MOTOR,STARTER 12VDC 32KW	38384
31227	MOTOR,STARTER 12VDC W70-100	NLA
31229	HOSE,FUEL RETURN	NLA

Old Number	Description	New Number
31243	TRANSMISSION 2.8:1 BW3	NLA
31249	TRANSMISSION 1.8:1 HBW150V	NLA
31251	TRANSMISSION 1.5:1 HBW20	32564 & 32553
31252	TRANSMISSION 2.7:1 HBW220	32566 & 32553
31253	TRANSMISSION 1.5:1 HBW400	NLA
31254	TRANSMISSION 2:1 HBW400	NLA
31255	TRANSMISSION 3:1 HBW400	NLA
31257	COOLER,OIL	34544
31260	ROD,GOVERNOR	33276
31262	ENGINE	34923
31264	ENGINE	34927
31270	PULLEY 5.5x2xA 5.5x1xB W50	NLA
31272	FLANGE,AIR IN SG HOSE TO SILEN	NLA
31278	ELBOW,INJECTED EXH 90 7/8" 2"	NLA
31283	PUMP,INJECTION W13	NLA
31309	PANEL,FRONT-SHEET SG 11-12 WMD	NLA
31310	PLATE,FAN OPENING	NLA
31311	DUCT,AIR IN & OUT SG 11-12.5	NLA
31312	PANEL,REAR-SHEET SG 11-12.5WMD	NLA
31313	PLENUM,DISTRIBUTION SG 11-12.5	NLA
31314	PANEL,TOP-SHEET SG 11-12.5 WMD	NLA
31315	PANEL,SIDE-SHEET SG 11-12.5WMD	NLA
31317	POST,CORNER 23.125	NLA
31320	SILENCER,INTAKE W58	NLA
31334	RAIL,SIDE 23.125	NLA
31338	SADDLE,FRONT MOUNT 11.5 CTRS	NLA
31340	MOUNT,REAR 11.5 RD60-80	NLA
31344	WASHER,SPRING	NLA
31345	SHIM 0.70	NLA
31346	SHIM 0.65	NLA
31347	SHIM 0.60	NLA
31348	SHIM 0.50	NLA
31349	SHIM 0.40	NLA
31350	SHIM 0.30	NLA
31351	SHIM 0.20	NLA
31352	SHIM 0.15	NLA
31353	SHIM 0.10	NLA
31354	THRUSTWASHER	NLA
31356	PIN,SHAFT	NLA
31357	CHAIN	NLA
31358	FLANGE,OUTPUT	31403
31359	COVER,GEARCASE	NLA
31360	CLUTCH	NLA
31361	THRUSTWASHER	NLA
31362	SHAFT,OUTPUT	NLA
31363	GEAR,REVERSE	NLA
31364	LEVER,CONE	NLA
31365	CAM,SHIFTING CONTROL	NLA
31366	COVER,SHIFT	NLA
31367	SEAL	NLA
31369	LEVER,SHIFT	NLA
31370	SHAFT,SHIFTING LEVER	NLA
31371	BRACKET,SHIFT	33005
31372	HOUSING,GEAR CASE	NLA
31373	SHAFT,INPUT	NLA
31374	GEAR,OUTPUT	NLA
31375	SPRING	NLA
31376	DIPSTICK	NLA

Old Number	Description	New Number
31377	DOWEL	NLA
31378	HOUSING,GEARCASE BW7	NLA
31379	DIPSTICK BW7	NLA
31381	THRUSTWASHER	NLA
31382	BEARING,NEEDLE CAGE	NLA
31384	PIN	NLA
31385	DISC,INNER BW7	NLA
31386	SHIM 3.00	NLA
31389	SHAFT,SHIFTING FORK BW7	NLA
31390	PIN,SHIFT	NLA
31391	SPRING	NLA
31392	GASKET,SHIFT COVER	NLA
31394	SHIM 0.60	NLA
31396	SHIM 0.40	NLA
31397	SHIM 0.30	NLA
31398	SHIM 0.20	NLA
31399	SHIM 0.10	NLA
31400	SHIM 0.15	NLA
31401	SHIM 0.65	NLA
31402	SHIM 0.70	NLA
31403	FLANGE,OUTPUT BW7	NLA
31404	SEAL	NLA
31405	DOWEL 12MM x 28MM DIN 6325	NLA
31408	SEAL,OIL	NLA
31410	BEARING,INNER	NLA
31411	SEAL,OUTPUT SHAFT	NLA
31412	NUT,SHAFT BW7	NLA
31413	SHAFT,IDLER GEAR BW7	NLA
31417	SHIM 2.90	NLA
31418	SHIM 3.10	NLA
31420	SHIM 3.30	NLA
31421	SHIM 3.40	NLA
31422	SHIM 3.50	NLA
31424	SHIM 3.70	NLA
31425	SHIM 3.80	NLA
31428	SHIM 4.10	NLA
31430	CIRCLIP	NLA
31432	SUPPORT,ROLLER	NLA
31433	SHAFT,OUTPUT	NLA
31434	PIN,LOCKING	NLA
31435	SHAFT,OUTPUT	NLA
31437	DISC,OUTER BW7	NLA
31438	WASHER	NLA
31439	DOWEL 8MM x 24MM DIN 6325	NLA
31440	SHAFT,SHIFTING BW7	NLA
31441	COVER,SHIFT	NLA
31444	LEVER,SHIFT	NLA
31445	SHIFT ASSEMBLY,COMPLETE	NLA
31446	SPRING	NLA
31448	HOUSING,FRONT BW7	NLA
31449	SLEEVE,SLIDING BW7	NLA
31450	FORK,SHIFTING	NLA
31452	CAPSCREW	17196
31453	NUT	NLA
31454	CAPSCREW M 8x25 DIN 912 GR10.9	NLA
31456	BEARING	NLA
31458	WASHER	NLA
31459	BALL	NLA

Old Number	Description	New Number
31460	NUT	18242
31461	WASHER	NLA
31463	LOCKWASHER	NLA
31464	WASHER	NLA
31465	CAPSCREW	13629
31466	CIRCLIP	NLA
31467	CAPSCREW	298460
31470	SETSCREW M 6x12 DIN 553	NLA
31471	PLUG M14x1.5 DIN 908	NLA
31472	NUT,HEX	NLA
31474	CAPSCREW M 8x30 DIN 6912	NLA
31477	BOLT	NLA
31478	O-RING,SHIFTING LEVER SHAFT	NLA
31479	SPACER,EXHAUST ELBOW	NLA
31487	RAIL,SIDE 32.250	NLA
31488	RAIL,END 23.125	NLA
31490	PLATE,EXHAUST HOUSING COVER	NLA
31493	MOUNT,FRONT	NLA
31496	GASKET,LUBE OIL-MNT TO BLK W52	NLA
31565	CAPSCREW 5/16NCx3-1/2	NLA
31574	CAPSCREW 5/16NCx5-3/4	NLA
31657	CAPSCREW 7/16NCx1-1/2	NLA
31710	CAPSCREW 1/2NCx2-1/4	NLA
31909	SCREW 8-32x1/4 SS PHIL PAN HD	NLA
31910	SCREW 8-32x3/8 SS PHIL PAN HD	NLA
31938	CAPSCREW 1/4NFx1/2 SEMS	NLA
32001	PANEL,SG TOP 4.4 WMD	NLA
32002	PANEL,SG FRONT 4.4 WMD	NLA
32003	PANEL,SG REAR 4.4 WMD	NLA
32004	PANEL,SG SIDE 4.4 WMD	NLA
32005	SKIRT,SIDE 32.250 WMD4	NLA
32012	REGULATOR,VOLTAGE 30KW FIDELIT	34615
32022	BRACKET,HYDRAULIC PUMP MOUNT	NLA
32040	HOUSING	32260
32063	PANEL,SG FRONT 12.5 WMD	NLA
32064	PANEL,SG REAR 11-12.5 WMD	NLA
32065	PANEL,SG TOP 11-12.5 WMD	NLA
32066	PANEL,SG SIDE 11-12.5 WMD	NLA
32070	ENGINE	NLA
32074	COVER,ELECTRIC 4 IN SQUARE BOX	NLA
32075	CONNECTOR,ROMEX	NLA
32078	SPRING,TORQUE	NLA
32080	FORM,FAST MOVING PARTS #1	NLA
32081	FORM,FAST MOVING PARTS #2	NLA
32084	SKIRT,SIDE 28.375 WLF-30KW	NLA
32085	BRACKET,PLENUM BRACE	NLA
32086	PLATE,PLENUM SUPPORT	NLA
32087	POST,CORNER 34.625 45 WLF	NLA
32089	RAIL,SIDE 28.375	NLA
32090	RAIL,END 27.250	NLA
32095	DUCT,AIR IN & OUT SG 30	NLA
32097	SKIRT,FRONT 24.50	NLA
32098	SKIRT,REAR 24.50	NLA
32099	PLENUM,DISTRIBUTION SG 15-20	NLA
32100	BOX,GENSET CONNECTN 30 WLF	NLA
32101	PANEL,SG FRONT 30 WLF	NLA
32102	PANEL,SG REAR 30 WLF	NLA
32103	PANEL,SG SIDE 30 WLF	NLA

Old Number	Description	New Number
32104	PANEL,SG TOP 30 WLF	NLA
32108	MOUNT,FRONT CENTER W21-27-33	NLA
32110	MOUNT,FRONT ISOLATOR TO SADDLE	NLA
32111	BRACKET,SHIFT S1000	NLA
32114	PLUNGER,FUEL SOLENOID 24338	NLA
32115	ADAPTER,OIL FILTER W80	NLA
32131	SPRING,FUEL SOLENOID 24338	NLA
32132	FORM,SPARE PARTS KIT LISTING	NLA
32138	PANEL,SG FRONT 11 WMD	NLA
32141	PANEL,FRONT-SHEET SG 20 WTA	NLA
32142	DUCT,AIR IN & OUT SG 15-20	NLA
32143	PANEL,REAR-SHEET SG 15-20 WTA	NLA
32144	PANEL,TOP-SHEET SG 15-20 WMF	NLA
32145	PANEL,SIDE-SHEET SG 15-20 WMF	NLA
32146	PLENUM SG 30 WLF	NLA
32150	MANIFOLD,EXHAUST W100	NLA
32156	HOUSING,THERMOSTAT W100	NLA
32166	BRACKET,SUPPORT PLENUM	NLA
32167	PLENUM ADAPTER 30 WLF	NLA
32168	BRACKET,ROCKER	NLA
32169	HOSE,BREATHER	32170
32179	HOSE,BYPASS	NLA
32181	PULLEY,CRANKSHAFT	32181 3 Cyl
32181	PULLEY,CRANKSHAFT	32182 4 Cyl
32185	CLIP,SCREEN RETAINING	NLA
32188	SCREW,DRIVE NO 8 x 0.375	NLA
32189	SKIRT,REAR 27.250 30WLF W/EXH	NLA
32190	RAIL,END 24.500	NLA
32193	POST,CORNER 25.250	NLA
32196	FLANGE,EXHAUST MANIFOLD REAR	NLA
32198	SKIRT,REAR 27.250 WLF-30 PLAIN	NLA
32199	ELBOW,WATER INLET SG 1 IN HOSE	NLA
32200	SKIRT,SIDE 28.375 WLF-30 W/EXH	NLA
32201	SKIRT,FRONT 27.250 WLF-30KW	NLA
32202	PLENUM,DISTRIBUTION SG 30	NLA
32203	BRACKET,EXH SUPPORT	32466
32204	ELBOW,EXHAUST SG90 1-7/8 RED	41700
32209	PANEL,SG FRONT 20 WMF/WTA	NLA
32210	PANEL,SG REAR 25 WTA	NLA
32211	PANEL,SG SIDE 15-25 WMF/WTA	NLA
32212	PANEL,SG TOP 15-25 WMF/WTA	NLA
32214	BODY,FRESH WATER PUMP W58	NLA
32224	HOSE,ELBOW 2-1/4" x 1-3/8"	NLA
32225	TUBE,MANIFOLD TO FW PUMP W100	NLA
32231	PLUG,BUTTON 2-1/4 HOLE	NLA
32233	WASHER,BELLEVILLE	NLA
32235	HOUSING,STATOR	NLA
32236	STATOR 15-22.5KW 1PH	NLA
32237	STATOR,EXCITER 15-22.5KW	32236
32238	ROTOR ASSEMBLY 15-22.5KW	NLA
32239	BOX	NLA
32240	REGULATOR	38925
32241	RING,RETAINING	NLA
32242	PANEL,PLATE	34485
32242	RECTIFIER	35301
32244	ADAPTER	33306
32245	RING,CLAMPING	NLA
32246	DISC,DRIVE	NLA

Old Number	Description	New Number
32247	FAN,ALTERNATOR	NLA
32248	BLOCK,TERMINAL-GROUND	NLA
32249	SCREEN,EXHAUST AIR	NLA
32252	GROMMET,BOX TO ALTERNATOR	NLA
32256	MOUNT,FRONT LEFT W70 18-22.5"	NLA
32260	HOUSING,FLYWHEEL-COMMON W/22.5	NLA
32261	FLYWHEEL ASSEMBLY W70 14MM	NLA
32264	MOUNT,REAR RV10D-R	NLA
32266	FLYWHEEL ASSEMBLY 25KW 14MM	NLA
32287	GENERATOR 3.2KW 1PH 50HZ 3WIRE	NLA
32288	GENERATOR 45KW 1PH 60HZ	NLA
32289	ADAPTER 1/8NPT TO 1/4OD FLARE	NLA
32294	DUCT,AIR IN & OUT SG 7.7 WMD	NLA
32303	PANEL,SG FRONT 4 WMD	NLA
32304	PANEL,SG REAR 4 WMD	NLA
32305	PANEL,SG SIDE 4 WMD	NLA
32306	PANEL,SIDE-SHEET SG 4 WMD	NLA
32307	SKIRT,FRONT/REAR 21.125 WMD-4	NLA
32308	SKIRT,SIDE 32.250 WMD-4	NLA
32312	FLYWHEEL ASSEMBLY 3.0 WMD	NLA
32314	BOX,GENSET CTL PNL 45 WLA	NLA
32316	MANIFOLD,FRESH WATER RETURN	NLA
32318	EXCHANGER,HEAT W100,32 WTF	36890
32319	MOUNT,FRONT RIGHT 25 WMF	NLA
32320	MOUNT,FRONT LEFT 25 WMF	NLA
32328	SPACER	NLA
32332	HOUSING,FLYWHEEL 3.0 WMD	NLA
32336	TRANSMISSION 1.58:1 DROP CENTR	NLA
32337	TRANSMISSION 2.03:1 DROP CENTR	NLA
32338	TRANSMISSION 2.47:1 DROP CENTR	NLA
32339	TRANSMISSION 2.93:1 DROP CENTR	NLA
32364	SWITCH,OIL PRESSURE	37323
32369	STUD 7/16NFx1-5/16	NLA
32371	PANEL,FRONT-SHEET SG 15 WMF	NLA
32383	STUD 5/16NFx2-1/4	NLA
32393	GENERATOR 22.5KW 1PH 60/50HZ	37994
32408	PANEL,SG FRONT 15 WMF/WTA	NLA
32409	REGULATOR	38925
32423	DRIPTRAY 25-45KW 15.38x40.50	NLA
32428	EXCHANGER,HEAT	24774
32441	BRACKET,SILENCER TO MANIFOLD	NLA
32452	DRIPTRAY 3 WMD	NLA
32453	MOUNT,REAR 3.0 WMD	NLA
32456	PULLEY,CRANKSHAFT	NLA
32458	BRACKET,SOLENOID,BREAKER	NLA
32461	MANUAL,OPERATOR 4.4-12.4 WMD	NLA
32463	GENERATOR 30KW 3PH 60HZ 12W .8	NLA
32479	GENERATOR 12.5KW 3PH 60HZ 4W Y	NLA
32482	FLYWHEEL ASSEMBLY 12B/10	NLA
32486	COOLER,OIL CUPRO-NICKEL	NLA
32501	EXCHANGER	36895
32503	GENERATOR 45KW 3PH 60HZ SAE3	NLA
32526	ARMATURE 3.2KW,50HZ,3WIRE	NLA
32527	PUMP,INJECTION WPDS-20KW	NLA
32534	HARNESS,MARINE W70 8 WIRE	36605
32536	HARNESS,MARINE W100 8 WIRE	NLA
32540	PANEL,SG FRONT 25 WMF	NLA
32548	ISOLATOR,MAR	11687

Old Number	Description	New Number
32563	TRANSMISSION 2.47:1 DROP CENTR	NLA
32564	TRANSMISSION 1.5:1 HBW250	NLA
32569	BRACKET,THROTTLE W10-2	NLA
32573	PANEL,FRONT-SHEET SG 32 WTF	NLA
32574	ELBOW,EXHAUST SG 45 DEGREE	NLA
32576	PANEL,REAR-SHEET SG 32 WTF	NLA
32577	PANEL,SIDE-SHEET SG 32 WTF	NLA
32578	PANEL,TOP-SHEET SG 32 WTF	NLA
32579	BOLT,BEARING COVER	NLA
32588	DUCT,EXCITER	NLA
32592	PLENUM,INTAKE SG 32	NLA
32593	BRACKET,PLENUM TO DUCT	NLA
32594	SKIRT,FRONT 27.875 WTF-32KW	NLA
32606	SKIRT,REAR 27.875 WTF-32KW	NLA
32607	CAPSCREW 5/16NCx2 BRASS	NLA
32610	STATOR 15-22.5KW 3PH	NLA
32611	STATOR ASSY INCL HSG 1PH	NLA
32612	STATOR ASSY INCL HSG 3PH	NLA
32615	GENERATOR 32KW	NLA
32617	PUMP,SEA WATER	NLA
32618	ISOLATOR,MAR	33719
32626	LEVER,SHIFT BW3	NLA
32629	HOUSING,FLYWHEEL-COMM W100 3/4	NLA
32660	CRANKSHAFT W70 M14 FW BOLTS	NLA
32666	BOLT,FLYWHEEL	NLA
32667	WASHER,FLYWHEEL	NLA
32674	COTTER,VALVE	40307
32687	GASKET,INT MANIF W70	41365
32702	SPRING,OIL RELIEF VALVE	NLA
32712	GASKET,FRESH PUMP	41376
32725	LOCKWASHER	19262
32726	WASHER	31789
32757	SUMP,OIL	NLA
32765	GEAR,CRANKSHAFT	NLA
32771	BOLT,CRANKSHAFT PULLEY	NLA
32772	ROCKER	40709
32776	LINE,INJECTOR LEAK-OFF W100	NLA
32788	STRAINER,OIL	NLA
32796	BEARING SET,MAIN 0.254 W100	NLA
32807	PLUG	13341
32819	SHAFT,OIL PUMP	23143
32856	HOSE	21498
32857	CORE,OIL COOLER	NLA
32866	CAMSHAFT W100	NLA
32867	ADAPTER,OIL FILTER W100	NLA
32870	STUD,INJECTOR	NLA
32874	FILTER,OIL	40154
32876	STUD	12501
32889	HOUSING,WATER PUMP W100	NLA
32891	MANIFOLD,INTAKE	33707
32892	BLOCK,BARE W100	NLA
32893	BLOCK,LOWER	NLA
32894	PUMP,INJECTION 108B,32KW E GOV	NLA
32896	BLOCK,BARE W70	NLA
32899	GLOWPLUG	24353
32900	WIRE,GLOWPLUG CONNECTING	NLA
32911	GENERATOR 3PH	NLA
32913	CAPSCREW	NLA

Old Number	Description	New Number
32929	GUARD,BELT 6-11 WMD	NLA
32931	LINE,LIFT PUMP TO FILTER	34614
32939	ALTERNATOR 12VDC,35A	NLA
32941	PLATE,BACK	NLA
32951	HOSE,MANIFOLD TO FW PUMP W100	48" HOSE 2-1/4" WIRE INSERTED
32965	SCREW*DAMPER TO FLYWHEEL 1.75	NLA
32967	SCREW*INJECTION PUMP	NLA
32976	TRANSMISSION 2.03:1 DROP CENTR	NLA
32979	PANEL,SG FRONT 32 WTF	NLA
32980	PANEL,SG REAR 32 WTF	NLA
32981	PANEL,SG SIDE 32 WTF	NLA
32982	PANEL,SG TOP 32 WTF	NLA
32988	ADAPTER FW RETURN W100	40095
32990	MOUNT,FRONT LEFT	NLA
32992	MOUNT,FRONT RIGHT	NLA
32998	ELBOW,WATER INJECTD	39976
33005	BRACKET,SHIFT BW3	NLA
33007	GUARD,BELT 4.4 WMD	NLA
33008	PLYWOOD 22-3/4x34-1/2x3/4	NLA
33011	RAIL,END 27.875	NLA
33012	POST,SIDE 28.187	NLA
33013	RAIL,SIDE 31.750	NLA
33014	POST,CORNER 28.187	NLA
33015	RAIL,CENTER 27.875	NLA
33019	PANEL,SIDE-SHEET SG 3.0 WMD	NLA
33020	PANEL,TOP-SHEET SG 3.0 WMD	NLA
33021	PANEL,FRONT-SHEET SG 3.0 WMD	NLA
33022	BASE,GENSET 45 WLA	NLA
33023	PLENUM,DISTRIBUTION SG 3.0 WMD	NLA
33024	PANEL,REAR-SHEET SG 3.0 WMD	NLA
33025	DUCT,AIR IN & OUT SG 3.0 WMD	NLA
33026	PLATE,AIR TO ENGINE SG 3.0 WMD	NLA
33027	PLATE,VERTICAL SUPPORT	NLA
33030	DOWEL	302575
33046	IMPELLER	32620
33047	PUMP,LIFT 12VDC	NLA
33050	GUARD,BELT 12.5 WMD	NLA
33054	GUARD,BELT 3.0 WMD	NLA
33065	BRACKET,LIFT PUMP W52	NLA
33066	BRACKET,LIFT PUMP W58	NLA
33080	PLATE,REAR MOUNT	NLA
33081	PLATE,FRONT MOUNT	NLA
33082	ADAPTER,AIR INTAKE SG 3.0 WMD	NLA
33085	RAIL,END 18.750 3.0 WMD	NLA
33086	RAIL,SIDE 30.500	NLA
33087	POST,CORNER 18.750 3.0 WMD	NLA
33103	ELBOW 1.5NPT 90	NLA
33113	BUSHING,OIL PUMP	NLA
33116	LINE,OIL DELIVERY	NLA
33117	SPRING,OIL RELIEF VALVE	NLA
33120	LEVER,GOVERNOR	NLA
33121	ADAPTER,SILENCER	NLA
33127	PLUG,TAPER-ROCKER COVER	NLA
33142	BEARING SET	38279
33143	BEARING SET	38280
33144	BEARING SET	38281
33145	BEARING SET	38282
33158	PULLEY,CRANKSHAFT	NLA

Old Number	Description	New Number
33160	BLOCK,BARE	NLA
33166	CASE,GEAR	NLA
33191	ROTOR,OIL PUMP	NLA
33195	SCREEN,OIL PICKUP	NLA
33199	WASHER,GOVERNOR	NLA
33202	SHAFT,GOVERNOR GEAR	NLA
33207	STOPPER,INJECTION PUMP	NLA
33208	SPRING,INJECTION PUMP RETURN	NLA
33210	SHIM,PUMP TAPPET 0.55	NLA
33211	SHIM,PUMP TAPPET 0.65	NLA
33212	DOWEL,TUBULAR	NLA
33215	GENERATOR 32KW 3PH 60HZ 12W .8	NLA
33217	ALTERNATOR KIT 120A PRIM W58	NLA
33218	TUBE,LIFT PUMP TO FILTER W58	NLA
33219	LINE	36372
33221	LINE	39094
33226	BRACKET,BELT GUARD 15KW	NLA
33229	BRACKET,BELT GUARD 15KW	NLA
33239	BRACKET,BELT GUARD 3.0 WMD	NLA
33244	PULLEY,CRANKSHAFT W70	NLA
33261	PANEL,SG FRONT 3 WMD	NLA
33262	PANEL,SG REAR 3 WMD	NLA
33263	PANEL,SG SIDE 3 WMD	NLA
33264	PANEL,SG TOP 3 WMD	NLA
33269	TRANSMISSION 1.5:1 HBW360	NLA
33270	TRANSMISSION 2.1:1 HBW360	NLA
33271	TRANSMISSION 3:1 HBW360	NLA
33274	COVER,TIE ROD WITH STOP LEVER	56116
33281	STRAINER,OIL PICKUP	NLA
33283	STRAINER,OIL PICKUP M16-W27	NLA
33284	ALTERNATOR KIT 51A EXTRA W52	NLA
33287	ENGINE	34934
33296	RETAINER,BEARING	NLA
33306	ADAPTER,FLYWHEEL TO AAE GEN	NLA
33320	ELBOW,EXHAUST TO MANIF LEFT	37327 Manifold Kit
33332	PLYWOOD 31-7/8x68x3/4	NLA
33348	SWITCH,OIL PRESSURE	37323
33353	LABEL,AC OUTPUT CONNECTIONS	NLA
33356	BLOCK,TERMINAL 6 POS 30A 2ROW	NLA
33357	MARKER,TERMINAL BLOCK 33356	NLA
33359	RAIL ASSEMBLY 6-8 WMD	NLA
33366	ELBOW,EXHAUST TO MANIF CENTER	37327 Manifold Kit
33375	BRACKET,BELT GUARD	38604
33376	BRACKET,BELT GUARD	NLA
33385	HOUSING,FLYWHEEL-COMM W70 3/4"	NLA
33386	GLOWPLUG	34467
33393	GENERATOR 32KW 1PH 60HZ 4WIRE	NLA
33396	GENERATOR 8.5KW 1PH 60HZ 4WIRE	NLA
33397	GENERATOR 6.8KW 1PH 50HZ 4WIRE	NLA
33405	MOTOR,STARTER-REBUILT 32940	NLA
33406	PANEL,INSTRUMENT	46637
33408	ELBOW,EXHAUST TO MANIF RIGHT	37327 Manifold Kit
33409	MANIFOLD,EXHAUST 6.5-11 TWG	NLA
33412	FLANGE,EXHAUST MANIFOLD REAR	37327
33420	RAIL,GENSET 48-9/16 LG 32KW .8	NLA
33421	MOUNT,REAR 32 WTF .8PF	NLA
33422	BRACKET,PANEL MTG 32KW	NLA
33434	SHIM,INJECTOR 1.30	NLA

Old Number	Description	New Number
33435	SHIM,INJECTOR 1.40	NLA
33437	SHIM,INJECTOR 1.45	NLA
33438	SHIM,INJECTOR 1.50	NLA
33439	SHIM,INJECTOR 1.55	NLA
33443	SHIM,INJECTOR 1.75	NLA
33446	SHIM,INJECTOR 1.90	NLA
33447	SHIM,INJECTOR 1.95	NLA
33449	NUT,RETAINING	NLA
33452	MOTOR,STARTER 12VDC - R & D	NLA
33465	MANIFOLD,EXHAUST ASSY 6-11 TWG	37327
33468	ARMATURE 3.2KW,50HZ,2WIRE	NLA
33474	HOSE	32951 & 22559
33475	HOSE 2-1/4 IN WIRE INSERTED	NLA
33484	GASKET,LIFT PUMP	30548
33486	MOTOR,STARTER 12VDC	NLA
33488	ADAPTER,FRONT EXHAUST W100	NLA
33491	FILTER 12 PACK	36200
33501	ENGINE,GAS	NLA
33508	PUMP,INJECTION 30KW	NLA
33509	PUMP,INJECTION 45KW	NLA
33510	FILTER 12 PACK 30220 OIL	NLA
33511	MANUAL	36250
33531	ELBOW,WATER INJECTD	39976
33536	SKIRT,SIDE 31.750 WTF-32KW	NLA
33546	THRUSTWASHER SET 0.003	NLA
33548	CRANKSHAFT	NLA
33549	GEAR,CRANKSHAFT	NLA
33551	ENGINE	34904
33553	ENGINE,GAS	34910
33556	PLATE,BACK W46	NLA
33559	ARRESTOR	34894
33560	GOVERNOR,MECHANICAL	R033560
33562	HOUSING	34682
33570	ROD,THREADED 3/8-24NF 3-7/8 LG	NLA
33571	ROD,THREADED 3/8-24NF	NLA
33573	GUARD,BELT 6.5-11 TWG	36237
33581	TOOL,TAPER RING REMOVER	NLA
33583	TOOL,CAMSHAFT BUSHING	NLA
33584	TOOL,COMPRESSION GAUGE ADAPTER	NLA
33585	TRANSMISSION 1.7:1 HBW360A	NLA
33586	TRANSMISSION 2.2:1 HBW360A	NLA
33587	TRANSMISSION 3:1 HBW360A	NLA
33610	STUD 7/16NCx7/16NFx2-1/4	NLA
33614	CONNECTOR,CHOKE TO CARBURETOR	NLA
33628	SHUTDOWN,OVERSPEED	41196
33631	SWITCH,TOGGLE	48263
33632	SWITCH,TOGGLE	48261
33633	SWITCH,TOGGLE	48304
33634	GENERATOR	37428
33636	PUMP,SEA WATER	37431
33638	STUD 5/16NFx3	NLA
33661	STUD M 8x48 DIN 939	NLA
33663	SEAL,OIL	32805
33688	BOX,GENSET CTL PNL 6.5-11 TWG	NLA
33689	COVER*GENERATOR CONTROL PANEL	NLA
33690	BRACKET,PANEL MNT	NLA
33711	BRACKET,INJECTION PUMP SUPPORT	NLA
33720	KIT	31186

Old Number	Description	New Number
33742	TOOL,BEARING INSTALLER	NLA
33744	DRIPTRAY	NLA
33751	CARBURETOR	NLA
33762	ADAPTER,MANIFOLD TO HEAD W46	37172
33770	HEATER KIT,WATER JACKET-NAVY	NLA
33772	MUFFLER HYDRO-HUSH B	34936
33781	TOOL,COMPRESSION GAUGE	NLA
33793	BLOCK,BARE K3A	NLA
33794	HEAD,CYLINDER	NLA
33809	ALTERNATOR 32VDC, 35A KIT	NLA
33811	METER,VOLT 32VDC NEG GND	NLA
33813	LAMP,GAUGE 32-36VDC	NLA
33836	RETAINER,POLE SHOE 8.5KW	NLA
33848	ADAPTER,MANIFOLD TO HEAD W18	37171
33850	FLANGE,EXHAUST MANIFOLD FRONT	NLA
33852	FLANGE,EXHAUST MANIFOLD FRONT	NLA
33854	FLANGE,EXHAUST MANIFOLD REAR	NLA
33856	FLANGE,EXHAUST MANIFOLD REAR	NLA
33868	SPACER,TERMINAL BLOCK	NLA
33874	BOX,SPARE PARTS KIT	NLA
33875	BOX,ELECTRIC	NLA
33876	BOX,ELECTRIC AC OUTPUT	NLA
33877	FORM,UPDATE TO 32139 ED 3	NLA
33910	RESISTOR,GAUGE 32VDC TO 12VDC	NLA
33920	MOUNT,FRONT 35B-42B 14.5-16"	41686
33925	TUBE,BREATHER	34076 & 34894
33935	SWITCH,OIL PRESSURE	37323
33936	MANIFOLD,EXHAUST ASSY W46	37172
33940	PLATE,ALTERNATOR SUPPORT	NLA
33942	BASE,GENSET 45 WLF	NLA
33944	BRACKET,PANEL MTG 45WLF	NLA
33948	BRACKET,COMPRESSOR W70	NLA
33949	LABEL,DEALER DISPLAY KIT	NLA
33950	KIT,DEALER DISPLAY	32405
33951	RACK,DEALER DISPLAY INCL SIGN	NLA
33952	MANIFOLD,EXHAUST ASSY W18-21A	37171
33954	ADAPTER,OIL FILTER	34560
33964	DRIPTRAY	36376-10,8 & 4.4kw
33964	DRIPTRAY	37354-15kw btd
33964	DRIPTRAY	37378-12.5btg, 11btd
33964	DRIPTRAY	37378-15btg
33964	DRIPTRAY	37378-8.5btg, 12.5btd
33977	DIAPHRAGM	36315
33982	TRANSMISSION,REBUILT BW3	NLA
33983	TRANSMISSION 1.58:1 DROP CENTR	NLA
33985	GENERATOR 45KW 3PH 60HZ 12W .8	NLA
34003	PLATE,LOCKING SEA PUMP TANG	NLA
34006	STUD 5/16NCx5/16NFx1-3/16	NLA
34008	BAFFLE,MANIF BCD-6KW	NLA
34009	BAFFLE,MANIF W46	NLA
34017	GASKET	36609
34022	SILENCER,INTAKE W46 GENSET	NLA
34031	CONNECTOR	37293
34037	HEAD,CYLINDER E1	49203
34038	BLOCK,BARE E1	NLA
34050	BLOCK,SHORT E1	NLA
34057	GASKET,HEAD	37566
34060	BOLT,MAIN BEARING CAP	NLA

Old Number	Description	New Number
34061	SUMP,OIL	NLA
34063	CASE,TIMING	NLA
34098	BLOCK,BARE E5	NLA
34099	CRANKSHAFT E5	NLA
34103	BLOCK,SHORT E5	NLA
34105	HEAD,CYLINDER E5	NLA
34106	DISTRIBUTOR	43600 & 43608
34114	MODULE	40609 generator
34114	MODULE	40610 propulsion
34134	VALVE,INTAKE E1-3-5	NLA
34135	SHAFT,ROCKER INTAKE	NLA
34137	SHAFT,ROCKER EXHAUST	NLA
34148	SPROCKET,CRNK-TIME CHAIN 2 ROW	NLA
34151	BEARING SET	37567
34152	BEARING SET,ROD 0.25	37568
34154	BEARING SET,ROD 0.76	37570
34199	COOLER,OIL	35130
34226	EXCHANGER,HEAT-PROD 8 BTD	36390
34229	BRACKET,EXCHANGER RIGHT	NLA
34230	BRACKET,EXCHANGER LEFT	NLA
34231	TUBE,MANIFOLD TO EXCHANGER	NLA
34331	SUMP,OIL TO S/N 157971	38333 + 38334
34364	ROTOR,OIL PUMP ASSEMBLY	34363
34394	SPRING,OIL RELIEF VALVE	NLA
34405	ISOLATOR,MAR	32013
34406	TRANSMISSION,FEMALE OUTPT SHFT	NLA
34408	GENERATOR BC 6.5KW 1P TO 31018	37438
34409	ALTERNATOR 12VDC, 72A W/RFI	42835 & 300746
34414	GENERATOR BC 4.5KW 1P TO 31023	37429
34415	COOLER,OIL	36650
34428	MOUNT,FRONT LEFT 16-18-22.5 IN	NLA
34448	WASHER,BANJO M10	11944
34454	MOTOR,STARTER 24VDC 32KW	NLA
34455	PANEL,PLATE	33916
34456	PANEL,PLATE	33917
34457	HOUSING,PUMP 33636	37431 Pump Kit
34465	IMPELLER	34440
34522	MANIFOLD,EXHAUST W13A 4.4 BCD	37319
34531	MANIFOLD,EXHAUST ASSY W27A	37324
34539	MANIFOLD,EXHAUST ASSY W33A	42029
34542	ADAPTER,MANIFOLD TO HEAD W27A	37324
34549	BRACKET,OIL COOLER SUPPORT W46	NLA
34555	GASKET,EXH MANIF TO ADPTR W33A	35703
34556	PLATE,BACK W27A-33A-38B-42B	NLA
34560	ADAPTER,OIL FILTER W46	NLA
34595	GENERATOR 4.8KW 1PH 50HZ 4WIRE	NLA
34603	ALTERNATOR 12VDC,130A W/REG	NLA
34622	REGULATOR	34615
34624	PLATE,BACK W41G-70G	NLA
34627	GENERATOR 45KW 1PH 60HZ 4WIRE	NLA
34632	BRACKET,ALTNR 51A EXTRA W70	NLA
34634	PULLEY 7x3xA W70	NLA
34637	BRACKET,MUFFLER	NLA
34644	EXCHANGER	36897
34652	EYE,LIFTING FRONT	NLA
34653	HARNESS,GEN PANEL 35016	36538
34654	HARNESS	36695
34662	BRACKET,THROTTLE W46	NLA

Old Number	Description	New Number
34664	COOLER,OIL HBW GEARS	NLA
34671	BOLT,ROCKER BRACKET	NLA
34674	BLOCK,BARE-SIDE OIL FILL	NLA
34675	BLOCK,BARE-SIDE OIL FILL	NLA
34678	MOUNT,FRONT LEFT 45 WLF	NLA
34679	MOUNT,FRONT RIGHT 45 WLF	NLA
34683	BRACKET,SHUT-OFF CABLE	NLA
34701	MANIFOLD,EXHAUST ASSY W41G	NLA
34704	MOUNT KIT,CONVERT TO RD60/80	NLA
34705	FILTER,GAS LIFT PUMP	35920
34706	GASKET,GAS LIFT PUMP COVER	35920
34707	DUCT,AIR OUT SG 8.0 BTD RED	NLA
34708	DUCT,AIR IN SG 8.0 BTD RED	NLA
34716	PANEL,FRONT-SHEET SG 8 BTD RED	NLA
34717	PANEL,FRONT/REAR-SHEET RED	NLA
34725	BAFFLE,MANIF W27A	NLA
34726	BAFFLE,MANIF W33A	NLA
34728	MOUNT,FRONT W33A	NLA
34734	ADAPTER,MANIFOLD TO HEAD 15BTG	37326
34740	PLATE,BACK W13A	NLA
34745	BAFFLE,MANIF BTG-8.5-15KW	NLA
34748	BAFFLE,MANIF W46	NLA
34750	ADAPTER,MANIFOLD TO HEAD-FRONT	37319
34752	ADAPTER,MANIFOLD TO HEAD-REAR	37319
34756	MOUNT,FRONT LEFT & ALTNR W13A	NLA
34762	PLATE,BACK 9.0 BTG	NLA
34764	PLATE,BACK 6.5 BCG	NLA
34772	PANEL,TOP-SHEET SG 8 BTD RED	NLA
34776	PANEL,SIDE-SHEET SG 8 BTD RED	NLA
34778	RAIL,END 19.750	NLA
34779	POST,CORNER 19.750	NLA
34782	PLUG 3/8 NPT	NLA
34787	EXCHANGER	36899
34790	EXCHANGER	36898
34792	SKIRT	36068
34793	MANIFOLD,EXHAUST ASSY 4.0 BCG	NLA
34803	MANIFOLD,EXHAUST ASSY CB	37326
34814	ENGINE,GAS	NLA
34816	ENGINE	NLA
34819	THERMOSTAT	NLA
34821	GOVERNOR,MECHANICAL	R034821
34822	GENERATOR	37430
34823	ENGINE,GAS	NLA
34824	ENGINE 2.2L	NLA
34843	TUBING,VINYL SHRINK 1.500ID	NLA
34845	PANEL,SG FRONT 4-6BCD,8BTD RED	NLA
34846	PANEL,SG FR/REAR 4-10BC/BT RED	NLA
34847	PANEL,SG SIDE 8 BTD WINDOW RED	NLA
34848	PANEL,SG SIDE 4-6BCD,8BTD RED	NLA
34849	PANEL,SG TOP 4.4-6 BCD,8 BTD R	NLA
34864	BRACKET,ALTNR 90A W46 PRI	NLA
34872	PLATE,BACK 8.5 BTG	NLA
34883	PULLEY,ALTNR 130A MOT W46	NLA
34884	BRACKET,ALTNR 130A W46 PRI	NLA
34886	DECAL,SHIFT LEVER DIRECTION	NLA
34889	BAFFLE,MANIF W13A	NLA
34904	ENGINE,BLOCK ASSY W46	NLA
34906	ENGINE,BLOCK ASSY E1	NLA

Old Number	Description	New Number
34910	ENGINE,BLOCK ASSY E5	NLA
34914	SWITCH,TEMPERATURE-OIL,ADJSTBL	NLA
34915	ENGINE,BLOCK ASSY 15 WMF MECH	41308 & 39314
34920	ENGINE,BLOCK ASSY 71B,W58,20KW	NLA
34923	ENGINE,BLOCK ASSY 82B,25BED	NLA
34927	ENGINE,BLOCK ASSY W100	41044
34929	ENGINE,BLOCK ASSY W12B	NLA
34931	ENGINE,BLOCK ASSY 4.4KWD	NLA
34934	ENGINE,BLOCK ASSY 6KWD	NLA
34938	ENGINE,BLOCK ASSY 8KWD	NLA
34944	MANIFOLD,EXHAUST CB	NLA
34945	HARNESS,MARINE W18-21A-27A-33A	36561
34945	HARNESS,MARINE W18-21A-27A-33A	36561
34949	MANIFOLD,EXHAUST 4.0 BCG	NLA
34958	BRACKET,SOLENOID,BREAKER	NLA
34977	ENGINE,BLOCK ASSY 38B/27/27A	NLA
34978	UNION 1.5 NPT	NLA
34979	ENGINE,BLOCK ASSY W33	NLA
35002	MUFFLER	34936
35016	PANEL,GENSET CTL	36539
35021	EXCHANGER	36893
35022	INSULATION	NLA
35024	BRACKET,THROTTLE W13A	NLA
35028	MOUNT,FRONT 4.4 BCD	NLA
35038	COVER*FUEL PUMP OPENING IN HEA	NLA
35086	FLANGE,MANIFOLD TO KEEL COOLER	NLA
35090	BRACKET,GOVERNOR 4 BCG	NLA
35093	BRACKET,IGNITION COIL & EYE	NLA
35105	GEAR,RING	NLA
35106	BRACKET,MAGNETO	NLA
35108	METER,WATER TEMPERATURE	37601
35110	METER,OIL PRESSURE 100PSI	37603
35111	METER,VOLT 12VDC	37605
35112	METER,TACHOMETER	36590
35117	RESISTOR,GAUGE 24/32VDC TO 12V	NLA
35118	HOLDER,LAMP	42893
35119	RESISTOR,GAUGE 32VDC TO 12VDC	NLA
35121	METER,VOLT 24VDC NEG GND FARIA	42156
35123	METER,OIL PRESSURE 80PSI FARIA	39670
35129	FILTER 6 PACK 32874 OIL	41113
35135	EXCHANGER	36903
35146	SPACER,FAN 45 WLF	NLA
35148	SUPPORT,CONTROL PANEL BRACKET	NLA
35149	BRACKET,PANEL MTG BRACE	NLA
35151	BAFFLE,MANIF BCG-6.5KW	NLA
35156	GUARD,BELT 4.0 BCG	NLA
35157	GUARD,BELT 6.5 BCG W/SM GOVNR	NLA
35162	PLATE,BACK 6.0 BCD	NLA
35168	CLAMP,DISTRIBUTOR CAP	NLA
35172	BRACKET,SEA WATER PUMP 4.4 BCD	NLA
35174	BRACKET,DISTRIBUTOR CAP	NLA
35184	ELBOW,FRESH WATER PUMP INLET	NLA
35185	BRACKET,CIRCUIT BREAKER	NLA
35188	SILENCER,INTAKE W52	NLA
35198	PANEL,FRONT-SHEET SG 45 WLF	NLA
35199	DUCT,AIR IN & OUT SG 45 WLF	NLA
35200	PANEL,REAR-SHEET SG 45 WLF	NLA
35202	PLENUM,INTAKE UPPER SG 45	NLA

Old Number	Description	New Number
35203	PANEL,SIDE-SHEET SG 45 WLF	NLA
35204	PANEL,SIDE-SHEET SG 45 WLF	NLA
35205	PANEL, TOP-SHEET SG 45 WLF	NLA
35208	RAIL,SIDE 34.562 45 WLF	NLA
35210	RAIL,END 30.000 45 WLF	NLA
35216	BASE,PLENUM INTAKE	NLA
35218	WINDOW,SG PANEL 8.75 X 6.75	NLA
35219	BRACKET,OIL FILTER	NLA
35221	HINGE,SG PANEL 8 LG	NLA
35222	PANEL,SIDE-SHEET SG 8BTD WIN R	NLA
35224	RAIL,BASE WLF-45	NLA
35226	SPACER,BASE WLF-45	NLA
35229	COVER,PANEL PLATE 35254	NLA
35230	PLENUM,INTAKE SG OUTER	NLA
35231	PANEL,SG FRONT 45 WLF	NLA
35232	PANEL,SG REAR 45 WLF	NLA
35233	PANEL,SG SIDE 45 WLF WINDOW	NLA
35234	PANEL,SG SIDE 45 WLF	NLA
35235	PANEL,SG TOP 45 WLF	NLA
35236	EXCHANGER	36904
35238	THERMOSTAT	35736
35241	SILENCER KIT W52 FIELD UPGRADE	43262
35242	SILENCER KIT 15KW FIELD UPGRAD	43261
35249	PLENUM,INTAKE-INNER,AAE	NLA
35250	PLENUM,INTAKE-INNER,FIDELITY	NLA
35251	CLIP*SPRING-CLOSURE	NLA
35254	PANEL,PLATE	34775
35263	PULLEY	37774
35266	ADAPTER,SEA WATER PUMP	NLA
35272	HOSE KIT	36498 OR 36503
35283	LEVER,CARBURETOR CHOKE	NLA
35284	BRACKET,CHOKE TO CARBURETOR	NLA
35285	SPACER,CHOKE BRACKET	NLA
35288	BRACKET,LIFT PUMP 4-6.5 BCG	NLA
35292	DRIPTRAY 15-20KW	NLA
35298	EXCHANGER	36891
35319	RAIL,LEFT 14088 SPEC B	NLA
35330	DOWEL,TUBULAR SEA PUMP ADAPTER	NLA
35332	PLATE,BACK W40A	NLA
35341	CARBURETOR 4.0 BCG	NLA
35342	CARBURETOR	35343
35343	CARBURETOR 6.5 BCG,9.0 BTG	NLA
35374	INJECTOR W40	NLA
35378	NIPPLE 1.5 NPT x 9 STEEL	NLA
35383	MANUAL	36746
35384	ENGINE,BLOCK ASSY 3KWD	NLA
35386	ENGINE,BLOCK ASSY W13	NLA
35387	CABLE,HARNESS EXTN TO TEMP SW	NLA
35390	ENGINE,BLOCK ASSY W18	NLA
35391	CLOSURE,SG 8.0 BTD	37298
35392	ENGINE,BLOCK ASSY W21	NLA
35393	HEATER,WATER JACKET 750W,120V	55618
35395	GENERATOR 25KW 1PH 60/50HZ 4W	NLA
35398	ENGINE,BLOCK ASSY 11KWD	NLA
35401	ENGINE,BLOCK ASSY 12.5KWD	NLA
35404	MOUNT,REAR 16-18 W40A	NLA
35412	BRACKET,SEA WATER PUMP 6.0 BCD	NLA
35420	SHUTDOWN,OVERSPEED	41225

Old Number	Description	New Number
35421	SHUTDOWN,OVERSPEED	41183
35423	SHUTDOWN,OVERSPEED	41225
35424	SHUTDOWN,OVERSPEED	41183
35425	SHUTDOWN,OVERSPEED	41196
35427	MANIFOLD,EXHAUST	15564
35428	GASKET,EXH MANIF TO ADPTR W40A	NLA
35433	FLANGE,EXHAUST MANIFOLD REAR	NLA
35437	BRACKET,IGNITION COIL CB	NLA
35441	COVER,ROCKER CB	NLA
35463	MANIFOLD,EXHAUST ASSY W40A	NLA
35465	NIPPLE,BREATHER HOSE AB	NLA
35471	GASKET,HEAD AB	NLA
35481	GASKET,BALANCE SHAFT COVER	NLA
35496	BLOCK,SHORT AB	NLA
35497	BLOCK,SHORT CB	NLA
35498	TUBE,OIL-BLOCK TO HEAD	NLA
35499	TUBE,DIPSTICK	NLA
35517	RING SET STD AB	NLA
35523	RING SET 0.75 AB	NLA
35524	RING SET 1.00 AB	NLA
35527	PISTON 0.25 CB	NLA
35531	PISTON 0.75 AB	NLA
35534	ROD,CONNECTING AB	35533
35561	CAMSHAFT AB	NLA
35591	DIPSTICK AB	NLA
35607	CAP,DISTRIBUTOR AB	NLA
35609	ROTOR,DISTRIBUTOR	42201
35638	GASKET,TIMING COVER UPPER 145M	35639
35644	GASKET,TIMING COVER UPPER LONG	35639
35662	SEAL,VALVE STEM	37965
35664	SCREW,ROCKER ADJUST	37967
35665	RESISTOR,IGNITION COIL	NLA
35667	COIL,IGNITION	NLA
35668	WIRE,SPARKPLUG AB	35669
35687	FELT	35686
35688	GASKET SET,UPPER 4.0 BCG	NLA
35689	GASKET SET,COMPLETE 4.0 BCG	NLA
35693	GASKET SET,COMPLETE 6.5BCG	NLA
35704	GUARD,BELT 6.0 BCD	NLA
35707	GASKET,OIL COOLER	NLA
35709	MANIFOLD,EXHAUST 8.5-15 BTG	NLA
35717	PANEL,REAR-SHEET SG 15-20 WMF	NLA
35718	DUCT,AIR IN & OUT SG 15-20	NLA
35721	PANEL,SIDE-SHEET SG 15-15 WMF	NLA
35724	CLOSURE,SHEET AAE	NLA
35725	CLOSURE,SG WTA-15-20KW	NLA
35726	PLATE,CLOSURE	NLA
35732	PANEL,SG REAR 15-25 WMF/WTA	NLA
35733	PANEL,SG SIDE 15-25 WMF/WTA	NLA
35735	PUMP,INJECTION W10	NLA
35743	TERMINAL,DISTRIBUTOR	NLA
35750	PLENUM,INTAKE SG OUTER	NLA
35758	EXCHANGER	36896
35760	HOSE,EXCHANGER TO PUMP	NLA
35761	HOSE,MANIFOLD TO EXCHANGER	NLA
35762	BAFFLE,MANIF W40A	NLA
35764	LABEL,HBW WARNING	NLA
35766	GUARD,BELT 4.4 BCD	NLA

Old Number	Description	New Number
35768	BRACKET,ALTNR 72A EXTRA W70	NLA
35772	BRACKET,SOLENOID-BREAKER	NLA
35779	BLOCK,TERMINAL	NLA
35816	TRANSMISSION 1:1 S1500	NLA
35818	ARMATURE 10KW,50HZ,4WIRE	NLA
35820	SWITCH,TEMPERATURE-EXH ALARM	NLA
35821	GENERATOR	37437
35822	TRANSMISSION 2.47:1 JS	NLA
35823	ENGINE,GAS	NLA
35841	GENERATOR 25KW 3PH 12WIRE SAE4	NLA
35845	SILENCER,INTAKE	NLA
35846	MOUNT,REAR 25 WMF	NLA
35850	MOUNT,FRONT RIGHT 11.5 W26GX	NLA
35865	PLYWOOD,BASE SG 25 WMF	NLA
35866	COVER	36672
35870	PLENUM,INTAKE SG BCD-4.4	NLA
35887	NAMEPLATE	NLA
35888	NAMEPLATE,EXCHANGER	NLA
35892	SUPPORT,DIPSTICK TUBE	NLA
35893	DIPSTICK	NLA
35896	PLATE,BACK W26G	NLA
35898	HARNESS,GENSET 4.4 BCD	NLA
35899	TUBE,DIPSTICK	NLA
35905	TUBE,DIPSTICK	NLA
35910	KIT,INSTRUMENTS	NLA
35918	ARMATURE	35818
35936	COVER,ALTERNATOR	42417
35957	BRACKET,LIFT PUMP W26G	NLA
35976	RESISTOR,BALLAST 3 COIL	NLA
35979	CLAMP,CAPACITOR	NLA
35983	STATOR ASSY INCL HOUSING BC4.5	41218
35986	ENGINE,BLOCK ASSY AB	NLA
35987	EXCHANGER	36900
35992	ENGINE,BLOCK ASSY 25WMF MECH G	NLA
35994	PANEL,REAR-SHEET SG 10 BTD RED	NLA
35995	COVER,AIR INLET SG RED	NLA
35996	SKIRT,REAR 19.750 BCD-4.4KW	NLA
36006	SOLENOID	39624-4-4.5bcg
36006	SOLENOID	39643-6.5-7bcg,9btg
36025	KIT,DIPSTICK	36498 30-45KW
36031	KIT,DIPSTICK	36503
36039	SEAL,DIPSTICK	NLA
36040	PLATE,BACK 8-12.5 BTD 1.6KW	NLA
36041	HANDLE,DIPSTICK	NLA
36042	WASHER,DIPSTICK	NLA
36043	PANEL,PLATE	47256
36046	FLYWHEEL ASSEMBLY W70 15MM	NLA
36047	FLYWHEEL ASSEMBLY 25KW 15MM	NLA
36049	HOSE,OIL TRX S1500 NO COOLER	NLA
36071	PANEL,FRONT-SHEET SG 20-25 WMF	NLA
36072	PLATE,FAN OPENING	NLA
36074	FLYWHEEL	38202
36076	LENS,BATTERY INDICATOR LAMP	36077
36085	BOLT,BANJO-SUMP 3/4-16NF	NLA
36087	TABWASHER,SUMP DRAIN BANJO	NLA
36092	MOUNT,FRONT RIGHT 15 BTD	NLA
36094	HARNESS,MARINE W13A 8 WIRE	NLA
36170	SPRING,FUEL SOLENOID	NLA

Old Number	Description	New Number
36186	PLYWOOD 28x56-1/2x3/4	NLA
36187	PLYWOOD,BASE SG 20 WMF/WTA	NLA
36189	RAIL ASSEMBLY 15-20 WMF/WTA	NLA
36208	TOOL,OIL SEAL INSTALLER	NLA
36210	REGULATOR	38925
36217	EXCHANGER	36902
36225	BRACKET,THROTTLE W13A	NLA
36271	FLOAT,CARBURETOR	NLA
36282	SPRING	NLA
36283	VALVE,ROTARY	NLA
36297	VALVE,NEEDLE & SEAT	38097
36367	EXCHANGER	36901
36370	PULLEY,CRANKSHAFT 5 GROOVE	NLA
36378	BRACKET,LIFT PUMP 9.0 BTG	38240
36380	GOVERNOR,MECHANICAL	R036380
36398	HARNESS,GENSET 9.0 BTG	NLA
36400	BRACKET,EXCHANGER	NLA
36401	ALTERNATOR 12VDC, 35A	40420
36403	GUARD,BELT 15 BTD	NLA
36407	TERMINAL,ALTERNATOR	NLA
36408	PLATE,BACK 4.5-7 BCG	NLA
36420	BRACKET,BELT GUARD	NLA
36421	BRACKET,BELT GUARD	NLA
36422	BRACKET,BELT GUARD	NLA
36428	PULLEY 6x4xA W40NA	NLA
36452	BRACKET,COMPRESSOR W40NA	NLA
36471	GASKET,HEAD AB	36467
36482	HOSE,EXCHANGER TO FW PUMP	34228
36491	CABLE,PANEL TO ENGINE 4 PIN	NLA
36510	RAIL ASSEMBLY,LEFT 8.5 BTG	NLA
36518	TOOL,VALVE GUIDE INSTALLER	NLA
36519	TOOL,VALVE GUIDE REMOVER	NLA
36537	NIPPLE 1 NPT x 7/8 HOSE	NLA
36548	FLANGE,EXHAUST MANIFOLD REAR	NLA
36551	FLANGE,EXHAUST MANIFOLD FRONT	NLA
36559	MOUNT,REAR LEFT 20B-30B	42030
36560	MOUNT,REAR RIGHT 20B-30B	42032
36582	MANIFOLD,EXHAUST ASSY 4.4 BCD	37319
36584	RAIL ASSEMBLY-LEFT WMD-3KW	NLA
36585	RAIL ASSEMBLY-RIGHT WMD-3KW	NLA
36587	GENERATOR 20KW 3PH 50HZ .8PF	NLA
36593	PANEL,SG FRONT 11-15 BTD	NLA
36594	PANEL,SG REAR 11-15 BTD	NLA
36595	PANEL,SG SIDE 11-15 BTD	NLA
36596	PANEL,SG TOP 11-15 BTD	NLA
36600	BRACKET,BELT GUARD	NLA
36606	FLANGE,EXHAUST MANIFOLD REAR	NLA
36610	FLANGE,EXHAUST MANIFOLD FRONT	NLA
36648	COOLER,OIL HBW GEARS 1 IN HOSE	40036 & 36622
36662	DEFLECTOR,SG TOP	NLA
36663	PANEL,TOP-SHEET SG 8 BTD	NLA
36664	PANEL,SIDE-SHEET SG 15 BTD	NLA
36665	PANEL,FRONT-SHEET SG 15 BTD	NLA
36666	PANEL,REAR-SHEET SG 15 BTD	NLA
36667	DEFLECTOR,SG REAR	NLA
36668	PANEL,TOP-SHEET SG 15 BTD	NLA
36673	SKIRT,REAR	NLA
36674	SKIRT,FRONT 22.625 BTD-11-15KW	NLA

Old Number	Description	New Number
36675	SKIRT,SIDE 41.125 BTD-11-15KW	NLA
36676	RAIL,SIDE 41.125	NLA
36677	POST,CORNER 24.062	NLA
36678	RAIL,END 22.625	NLA
36682	SKIRT,REAR 22.625 BTD-11-12.5	NLA
36690	HOSE,EXCHANGER TO PUMP	37506
36695	HARNESS,GENSET	43893
36708	ENGINE,BLOCK ASSY 63B,W52,15KW	41308
36718	COVER,SG EXHAUST OPENING	NLA
36720	PANEL,REAR-SHEET SG 10 BTD	NLA
36722	PLUG 3/8 NPT SQ HD	287077
36723	DEFLECTOR,SG AIR INTAKE	NLA
36724	CLIP,SUPPORT DEFLECTOR 36723	NLA
36726	MANIFOLD,EXHAUST W33A 12.5 BTD	NLA
36728	BRACKET,FUEL FILTER	NLA
36734	RISER,EXHAUST	37403
36744	ELBOW,EXHAUST SG45 2" RED	41674
36757	ENGINE,BLOCK ASSY 20 WMF-WTA	NLA
36800	SUPPORT,DEFLECTOR 36723	NLA
36802	SKIRT,REAR 19.75	NLA
36804	PANEL,TOP-SHEET SG 10 BTD	NLA
36805	RAIL,SIDE 33.375	NLA
36814	MANIFOLD,EXHAUST 4.0 BCG	NLA
36820	BOLT,BANJO-SUMP	NLA
36835	HOSE,EXCHANGER TO PUMP	NLA
36836	HOSE,MANIFOLD TO EXCHANGER	NLA
36853	PLYWOOD,BASE SG 11-15 BTD	NLA
36854	BANJO,INJECTION PUMP	NLA
36860	BANJO ASSEMBLY,INJECTION PUMP	NLA
36861	BANJO ASSEMBLY,INJECTION PUMP	NLA
36862	ISOLATOR ASSEMBLY 65D M12	NLA
36866	HOSE,LIFT PUMP TO FILTER	NLA
36868	HOSE,INJECTORS TO FUEL RETURN	NLA
36894	EXCHANGER,HEAT W13A	NLA
36907	SKIRT,SIDE 33.375	NLA
36908	SKIRT,FRONT 19.75	NLA
36913	PANEL,FRONT-SHEET SG 11-15 BTD	NLA
36920	FILTER	36918
36985	BLOCK,BARE	NLA
37093	PUMP,LIFT MECHANICAL	NLA
37097	SOLENOID,FUEL	37100
37113	GASKET,INJECTOR NOZZLE	NLA
37120	FILTER 12 PACK	37000
37130	PANEL,SG SIDE 10 BTD RED	NLA
37131	PANEL,SG TOP 10 BTD	NLA
37132	PANEL,SG REAR 10 BTD RED	NLA
37135	PANEL,SIDE-SHEET SG 11-15 BTD	NLA
37142	MUFFLER	34936
37160	HOSE,EXHAUST ADAPTER 2" X 6"	NLA
37173	ENGINE,BLOCK ASSY 12C/20B	NLA
37187	HOSE,FUEL SUPPLY & RETURN	NLA
37200	MOUNT,REAR LEFT	42030
37202	MOUNT,REAR RIGHT	42032
37204	FLANGE,MANIFOLD FRONT EXHAUST	NLA
37209	DIODE,POSITIVE-RED DOT	NLA
37210	DIODE,NEGATIVE-BLACK DOT	NLA
37236	MOUNT,FRONT LEFT 4.5-7.0 BCG	NLA
37238	MOUNT	37446

Old Number	Description	New Number
37246	MOUNT,FRONT GENSET	NLA
37247	PULLEY,FRESH PUMP EB/ED	NLA
37265	BRACKET,FILTER,SOLENOID,BREAKR	38045
37275	PISTON STD	37683
37280	CAMSHAFT	NLA
37287	HEAD,CYLINDER	NLA
37297	TRANSMISSION 1.88:1 OPP ROT 71	NLA
37299	MANIFOLD,EXHAUST	NLA
37310	MANIFOLD,EXHAUST	NLA
37316	MANIFOLD,EXHAUST	NLA
37319	MANIFOLD KIT,EXHAUST K2C	NLA
37329	PLYWOOD,BASE SG 10 BTD RED	NLA
37334	MOUNT,FRONT RIGHT	40565
37336	MOUNT,FRONT LEFT	40567
37348	HARNESS,MARINE 20/30B MECH PMP	38116
37349	BELT	38527
37358	CORNER,4 PRONG W/TAPPED HOLE	NLA
37363	DEFLECTOR SG REAR PANEL	NLA
37364	DEFLECTOR SG TOP PANEL	NLA
37365	PANEL,SIDE-SHEET SG WITH DOOR	NLA
37366	PANEL,REAR-SHEET SG 11-15 BTD	NLA
37367	COVER,AIR INLET SG BTD-11-15	NLA
37369	PANEL,TOP-SHEET SG 11-15 BTD	NLA
37372	MANUAL,OPERATOR W40A	NLA
37379	ISOLATOR,MARINE	NLA
37381	HOSE,EXCHANGER TO MANIFOLD	18" 24974
37386	THERMOSTAT	37387
37389	SKIRT,REAR 22.625 BTD-11-15KW	NLA
37392	POST,CORNER 22.063	NLA
37395	COVER,AIR INLET SG BTD-11-15KW	NLA
37396	DEFLECTOR,SOUND-AIR INLET	NLA
37404	PANEL,SG FRONT 11-15 BTD	NLA
37405	PANEL,SG REAR 11-15 BTD	NLA
37406	PANEL,SG SIDE 11-15 BTD	NLA
37407	PANEL,SG SIDE 11-15 BTD WINDOW	NLA
37408	PANEL,SG TOP 11-15 BTD	NLA
37411	PANEL,SG TOP 10 BTD RED	NLA
37412	PANEL,SG SIDE 10BTD WINDOW RED	NLA
37429	GENERATOR 4.5KW BC TO 31023	43092
37434	GENERATOR 20KW,1PH	NLA
37436	CONTACT SET	NLA
37438	GENERATOR 6.5KW BC TO 31018	NLA
37441	COVER,AIR OUTLET SG BTD-11-15	NLA
37445	BRACKET,LIFT PUMP 4.5-7 BCG	NLA
37449	SILENCER,INTAKE W70	48804
37455	HOSE,SEA PUMP TO JS TRX 38/42B	44379
37456	HOSE,TRANSMISSION WATER INLET	11779 10" HOSE 1" WIRE INSERTED
37461	BLOCK,TERMINAL AC	38342
37462	BRACKET,SWITCH	38345
37471	STATOR	37467
37501	ENGINE,BLOCK ASSY 10 BTD	NLA
37539	PLYWOOD,BASE SG 32 WMF	NLA
37540	PANEL,SG SIDE 32 WTF WINDOW	NLA
37604	ENGINE,BLOCK ASSY 30B	54707
37611	CONNECTOR	302852
37612	ELBOW	211015
37618	GUARD,BELT 4.5-7.0 BCG	NLA
37626	BRACKET,SHIFT HBW O'DAY	NLA

Old Number	Description	New Number
37627	MOUNT,FRONT RIGHT 12B O'DAY	NLA
37656	CRANKSHAFT	NLA
37677	BEARING SET,MAIN 0.25	30484
37687	GASKET,HEAD	44849 generator
37687	GASKET,HEAD	44853 propulsion
37702	BEARING SET,MAIN	30480
37710	KIT B 42B FOUR 12.5 BTDA	44852 generator
37710	KIT B 42B FOUR 12.5 BTDA	44856 propulsion
37711	GASKET SET,UPPER 42B,12.5 BTDA	44850 generator
37711	GASKET SET,UPPER 42B,12.5 BTDA	44854 propulsion
37712	GASKET SET,COMPLETE 42B,12BTDA	44851 generator
37712	GASKET SET,COMPLETE 42B,12BTDA	44855 propulsion
37718	ENGINE,BLOCK ASSY E3	NLA
37721	STATOR BC-4.5KW TO S/N 20245	41218
37726	TOOL	37727
37736	PANEL,SIDE-SHEET SG WITH DOOR	NLA
37737	PANEL,SG SIDE 11-15 BTD WINDOW	NLA
37741	BUSHING 3/8 BSPT TO 1/4 NPT	47293
37748	HOSE,MANIFOLD TO EXCHANGER	NLA
37754	ENGINE,BLOCK ASSY 15 BTD	NLA
37763	ENGINE,BLOCK ASSY 35B	NLA
37766	ENGINE,BLOCK ASSY 42B	NLA
37768	ENGINE,BLOCK ASSY 12.5 BTDA	NLA
37773	ENGINE,BLOCK ASSY 32 WTF MECH	NLA
37782	SILENCER,INTAKE W58-71B-32KW	48804
37784	SILENCER,INTAKE W100-108B	48804
37785	SILENCER,INTAKE W52,63B,71C,82	48804
37818	PUMP,LIFT	39273 gas
37818	PUMP,LIFT	39275 diesel
37822	FLYWHEEL ASSEMBLY 8 BTD 1.6KW	NLA
37824	BRACKET,PANEL MTG	36871
37825	ALTERNATOR 12VDC, 35A 8.5BTG	39790 & 30475
37832	CARBURETOR 7.0 BCG	38949
37847	HOUSING,STATOR	41218
37865	COVER,ROCKER	38536
37875	BEARING SET,MAIN STD EB	NLA
37884	PISTON STD EB TO OS09028	NLA
37889	ROD,CONNECTING EB TO OS09028	NLA
37890	BEARING SET,ROD STD EB 15MM	NLA
37893	CRANKSHAFT EB TO OS09028	41630 & 41640
37907	ROCKER,EXHAUST	37908
37926	ROTOR,DISTRIBUTOR	42201
37927	PLATE,DISTRIBUTOR	NLA
37948	SEAL,DUST	NLA
37953	SLEEVE	NLA
37954	SLEEVE	NLA
37960	GASKET,RUBBER-OIL SEAL	NLA
37978	GASKET SET,UPPER 4.5 BCG	NLA
37979	GASKET SET,COMPLETE 4.5BCG	NLA
37986	GENERATOR BC 6.5KW 1P 60HZ 4W	NLA
37994	GENERATOR KIT 20KW,1PH	NLA
38001	GENERATOR 6.5KW BC 60HZ	NLA
38008	FLYWHEEL ASSEMBLY	NLA
38021	HOSE,EXCHANGER TO FRESH PUMP	NLA
38022	HOSE,EXCHANGER TO FRESH PUMP	NLA
38026	LINE,LIFT PUMP TO CARBURETOR	NLA
38035	LINE,LIFT PUMP TO CARBURETOR	NLA
38036	BRACKET,EXCHANGER RIGHT 25 WMF	NLA

Old Number	Description	New Number
38037	BRACKET,EXCHANGER LEFT 25 WMF	NLA
38056	HOSE,EXCHANGER TO FRESH PUMP	NLA
38114	ELBOW,INJECTED 45 2.5VC 5BCD	37402
38120	TUBE,INJECTOR RETURN LINE	NLA
38121	TUBE,INJECTOR RETURN LINE	NLA
38122	LINE,INJECTOR RETURN TO FILTER	NLA
38125	BOX,CIRCUIT BREAKER 4-9 KW	43688
38126	COVER,BREAKER BOX 38125	43689
38133	DAMPER - NOT FOR OUR SPEC	NLA
38134	MANUAL,OPERATOR 5.0 BCD	42871
38170	PLATE,BACK 10.0 BTD	NLA
38172	CONNECTOR,GASDENSER 1/8NPT FEM	NLA
38208	BREAKER,CIRCUIT	42704
38209	BREAKER,CIRCUIT	42705
38210	BREAKER,CIRCUIT	42706
38211	BREAKER,CIRCUIT	42707
38212	BREAKER,CIRCUIT	42708
38213	BREAKER,CIRCUIT	42698
38214	BREAKER,CIRCUIT	42709
38215	BREAKER,CIRCUIT	42710
38230	BRACKET,SOLENOID & CIRC BREAKR	NLA
38237	MOTOR,STARTER REMANUFACTURED	NLA
38252	PANEL,REAR-SHEET SG 5-7.0 BCD	NLA
38253	PANEL,FRONT-SHEET SG 5-7.0 BCD	NLA
38255	PANEL,TOP-SHEET SG 5-7.0 BCD	NLA
38260	DUCT,AIR OUT SG 5-7.0 BCD	NLA
38261	SKIRT,FRONT 17.00 5.0 BCD	NLA
38262	POST,CORNER 16.937 5.0 BCD	NLA
38263	RAIL,SIDE 29.250 5.0 BCD	NLA
38269	SKIRT,REAR 17.000 5.0 BCD	NLA
38273	RAIL,END 17.000 5.0-7.0 BCD	NLA
38287	BRACKET,EXCHANGER 15-20 BTD	NLA
38289	HOSE,SKIRT INLET TO SEA PUMP	NLA
38290	LINE,LIFT PUMP TO FILTER 82B	NLA
38291	TUBE,LIFT PUMP TO FILTER 82B	NLA
38301	GENERATOR BT 15KW 3PH 18KVA .8	39913
38315	PANEL,SG FRONT 5-7 RED	NLA
38316	PANEL,SG REAR 5-7 RED	NLA
38317	PANEL,SG SIDE PLAIN 5-7 RED	NLA
38318	PANEL,SG SIDE WINDOW 5-7 RED	NLA
38319	PANEL,SG TOP 5-7 RED	NLA
38324	BRACKET,ROCKER 3/8 STUD	NLA
38325	STUD,ROCKER BRACKET 3/8	NLA
38376	HOUSING,FLYWHEEL 82B,108B	NLA
38383	RAIL,END 18.250 5.0-7.0 BCD	NLA
38412	DUCT,AIR IN SG 8 BTD PC	NLA
38413	PANEL,REAR-SHEET SG 8.0 BTD PC	NLA
38414	PLENUM,AIR IN SG 8.0 BTD PC	NLA
38415	PANEL,TOP-SHEET SG 8.0 BTD PC	NLA
38438	PULLEY	38694
38442	ADAPTER,HBW250 TO HOUSING	NLA
38454	HEAD,CYLINDER L3A	NLA
38459	PUMP,INJECTION	NLA
38471	FUSE 6.3A	42338
38474	SUMP,OIL 15.0 BDH-6312	NLA
38487	GENERATOR	NLA
38497	GOVERNOR KIT,6.5 BCG RETRO	NLA
38499	ENGINE,BLOCK ASSY 5.0 BCD	42400

Old Number	Description	New Number
38503	ENGINE,BLOCK ASSY 4.5 BCG	NLA
38506	PUMP KIT,FRESH WATER W7/WPD4	NLA
38518	MOUNT,FRONT LEFT 15.0 BTDA	NLA
38535	GASKET,HEAD ED	NLA
38538	COVER,TIMING FR ED TO 1914868	NLA
38539	COVER,TIMING UPPER REAR ED	NLA
38540	GASKET,TIMING COVER ED	NLA
38541	BEARING SET,MAIN STD ED	NLA
38554	BEARING SET,ROD STD ED	NLA
38556	CRANKSHAFT ED TO 1749104 NLA	41640 & 41650
38558	BELT,TIMING ED TO 1S56257	NLA
38561	DISTRIBUTOR	37924
38562	ROTOR,DISTRIBUTR	37926
38563	WEIGHT,DISTRIBUTOR	37930
38564	SPRING,DISTRIBUTOR	37931
38565	SPRING,DISTRIBUTOR	37932
38566	WIRE SET,IGNITION ED	37934
38569	GASKET SET,UPPER 7.0 BCG/BCGA	NLA
38570	GASKET SET,COMPLETE 7.0 BCG	NLA
38616	KIT,CIRC.BREAKER 7.6 BTD 60HZ	38617
38750	ENGINE,BLOCK ASSY 7.0 BCG/BCGA	NLA
38753	STATOR BC-6.5KW 60 HZ ONLY	NLA
38770	PLENUM,INTAKE SG11-15 BTD RED	NLA
38791	HARNESS,GENSET	39430
38792	ALTERNATOR 12VDC,135A	NLA
38797	BREAKER,CIRCUIT	42232
38798	BREAKER,CIRCUIT	42714
38799	BREAKER,CIRCUIT	42236
38800	BREAKER,CIRCUIT	42717
38851	POST,CORNER 22.250	40478
38851	POST,CORNER 22.250	NLA
38852	RAIL,SIDE 41.500	NLA
38853	RAIL,END 23.250	NLA
38856	SKIRT,REAR 23.250 15.0 BTDA	NLA
38866	HOSE,EXCHANGER TO PUMP	NLA
38867	PANEL,SG FRONT 11-15 BTD RED	NLA
38868	PANEL,SG REAR 11-15 BTD RED	NLA
38869	PANEL,SG SIDE 11-15 BTD RED	NLA
38870	PANEL,SG SIDE 15.0 BTDA WIN RE	NLA
38871	PANEL,SG TOP 11-15 BTD RED	NLA
38882	CHOKE,CARBURETOR 35341,35343	NLA
38891	REGULATOR,12VDC ALTNR 38792-4	52635
38892	REGULATOR,12VDC	52635
38900	PULLEY,CRANKSHAFT 1GR 108B	NLA
38902	BREAKER,CIRCUIT	42713
38903	BREAKER,CIRCUIT	42715
38904	BREAKER,CIRCUIT	42716
38929	MANUAL,TECHNICAL	32460
38935	KIT,CIRC.BREAKER 6.8-7 BTG 50H	NLA
38936	KIT,CIRC.BREAKER 10.0 BTG 50HZ	NLA
38937	KIT,CIRC.BREAKER 4.0 BCD 50HZ	NLA
38938	KIT,CIRC.BREAKER 7.5-8.3BTD50H	NLA
38939	KIT,CIRC.BREAKER 8.3 BTD 50HZ	NLA
38949	CARBURETOR 7.0 BCG	NLA
38999	BOX,GENSET REMOTE CTL 32.0WMFM	NLA
39008	RAIL,GENSET 32.0 BED PTO PUMP	NLA
39046	HOSE,SKIRT CONNCTR TO SEA PUMP	16" 11779
39050	DRIPTRAY 32.0BED 15.38x31.00	NLA

Old Number	Description	New Number
39150	HOSE	35027
39194	PANEL,PLATE 32.0 WMFM GENSET	NLA
39196	PANEL,PLATE 32.0 WMFM REMOTE	NLA
39200	GENERATOR KIT 25KW,1PH	NLA
39208	TUBE,DIPSTICK 32.0 WMFM	NLA
39209	DIPSTICK 32.0 WMFM	NLA
39215	HARNESS,GENSET 32.0 WMFM AAP	NLA
39219	BOX,GENSET CTL PANEL 32.0 WMFM	NLA
39231	PANEL,GENSET CONTROL 32.0 WMFM	NLA
39232	PANEL,REMOTE 32.0 WMFM	NLA
39234	HOLDER,FUSE 30A 3 POLE 480VAC	NLA
39235	FUSE 1/10A 600VAC	NLA
39241	SWITCH,ROTARY-VOLTMETER SELECT	NLA
39242	METER,OIL PRESSURE WITH ALARM	NLA
39243	METER,WATER TEMPERATURE-ALARM	NLA
39245	LAMP KIT,METER 39242-39243	NLA
39247	CABLE 30' REMOTE VOLTMETER	NLA
39256	TRANSMISSION 1:1 HYD 71 LO PMP	NLA
39270	STRAP,ALTRN ADJUST	299809
39274	RAIL,GENSET 25.0 BED RIGHT	NLA
39289	COVER,ROCKER W40	NLA
39303	METER,VOLT	39761
39314	GOVERNOR KIT 15WMF ELECTRONIC	NLA
39317	SWITCH,TEMP 195F NO 1/4NPT 2T	NLA
39338	ISOLATOR,GEN 280 LB	NLA
39342	ARMATURE BT 15KW 3PH TO S/N499	NLA
39351	BRACKET,SEA WATER PUMP 4.5 BCG	NLA
39360	PANEL,SIDE SHEET SG20BED RED	NLA
39361	RAIL,SIDE 47.563 20-25 BED	NLA
39365	POST,CORNER 25.563 20-25 BED	NLA
39372	WIRE,GENERATOR GROUND	NLA
39390	BALLJOINT 10-32 ROD END MALE	48516
39440	DIODE	41081
39454	CARBURETOR W/CHOKE 20-25 BEG	NLA
39465	PANEL,SG FRONT/REAR 20 BED RED	NLA
39466	PANEL,SG SIDE 20-25 BED RED	NLA
39467	PANEL,SG SIDE 20BED WINDOW RED	NLA
39468	PANEL,SG TOP 20-25 BED RED	NLA
39535	TRANSMISSION 2:1 HBW 35-2R	NLA
39545	ENGINE,BLOCK ASSY 55A	NLA
39592	PLATE,BACK 15.0 BDHA	NLA
39593	FLYWHEEL ASSEMBLY	NLA
39640	REGULATOR,VOLTAGE BE	42336
39658	BREAKER,CIRCUIT 10AMP 2POLE-IP	NLA
39659	BREAKER,CIRCUIT	42712
39690	KIT,CIRC.BREAKER 3.5 BCG 50HZ	NLA
39691	KIT,CIRC.BREAKER 12.0 BTG 50HZ	NLA
39692	KIT,CIRC.BREAKER 9.4 BTDA 50HZ	NLA
39693	KIT,CIRC.BREAKER 12.0 BTDA 50H	NLA
39697	KIT,CIRC.BREAKER 16.0 BED 50HZ	NLA
39702	KIT,CIRC.BREAKER 5.7-6 BTD 50H	NLA
39747	CONTROLLER,GOVNR 24V	49608
39804	BRACKET,ACTUATOR 20-25 BEDR	NLA
39813	HOUSING,FLYWHEEL 12C-20B-30B	NLA
39823	PANEL,SG SIDE 11-12.5BTD WIN R	NLA
39842	BELT	301073
39887	SPACER	31318
39906	TRANSMISSION 2.47:1 BW7	NLA

Old Number	Description	New Number
39916	MANUAL,TECHNICAL	43317
39953	ENGINE,BLOCK ASSY 7.6 BTD	54199
39965	BRACKET,RADIATOR MNT RIGHT	NLA
39966	BRACKET,RADIATOR MNT LEFT	NLA
40027	COVER,AIR INTAKE	40947
40095	HOSE KIT,MANIFOLD TO FW PUMP	48" HOSE 2-1/4" WIRE INSERTED
40140	MANIFOLD,EXHAUST	41790
40175	BRACKET,FUEL SOLENOID 32.0BEDA	41018
40186	KIT,EXHAUST RISER V-CLAMP 3"	NLA
40198	SPACER	40964
40249	STUD,INJECTOR HOLDER SL	NLA
40256	BLOCK,LOWER SL TO U1050	NLA
40257	PLATE,LOWER BLOCK SEAL SL	NLA
40287	PLATE,TIMING COVER SL	NLA
40344	FILTER,FUEL SL	46404
40348	BRACKET,INJECTION PUMP SUPPORT	NLA
40431	MOTOR,STARTER 24VDC	42731
40477	POST,CORNER 16.937 5.0 BCD	NLA
40478	POST,CORNER 22.250	NLA
40509	HOSE 1-3/4 IN 17-1/4 LG	18" 38848
40545	REGULATOR	39640
40588	MANUAL,OPERATOR 32.0 BEDA	39685
40600	HEATER,BLOCK	NLA
40662	HOSE,BREATHER 108C	NLA
40721	PUMP,INJECTION 108C	NLA
40739	ENGINE,BLOCK ASSY 108C	NLA
40743	ENGINE,BLOCK ASSY 32 WMFMA	NLA
40745	ENGINE,BLOCK ASSY 32WMFMA MECH	NLA
40789	SEAL,OIL	40790
40836	GASKET,EXHAUST MANIFOLD	NLA
40837	FILTER,FUEL	42817
40839	RETAINER,FUEL FILTER CUP	42410
40855	SPARKPLUG	43071
40861	ROTOR,DISTRIBUTOR IGNITER SIG	NLA
40863	SPRING SET,DISTRIBUTOR	NLA
40864	IGNITER,DISTRIBUTOR	NLA
40866	WIRE,DISTRIBUTOR	NLA
40878	CUP,FUEL FILTER	42817
40896	DAMPER,HSW630 SEE ECO 3005	NLA
40910	MOUNT,REAR 75 BEDR	NLA
40931	ADAPTER,DAMPER HSW630 108C	NLA
40954	FLYWHEEL ASSEMBLY 108C HSW630	40960
40957	CONDUIT,FLEX-GARD 0.625 ID	NLA
40958	CONDUIT,FLEX-GARD 0.375 ID	NLA
40959	CONDUIT,FLEX-GARD 0.250 ID	NLA
40965	BRACKET,THROTTLE 90A OBSOLETE	NLA
40990	PULLEY,FRESH PUMP 75BEDR	NLA
40991	PULLEY,CRANKSHAFT 1GR 75 BEDR	NLA
40992	BRACKET,ALTNR 50A 75 BEDR	NLA
40993	STRAP,ALTNR ADJUST 75.0 BEDR	NLA
41028	HOUSING,THERMOSTAT 75 BEDR	NLA
41044	ENGINE,BLOCK ASSY W100A	NLA
41089	RADIATOR & FAN GUARD 75 BEDR	NLA
41092	BREAKER,CIRCUIT	42711
41093	PUMP,SEA WATER	36246
41114	KIT,CIRC.BREAKER 25.0 BEDA 50H	NLA
41131	BREAKER,CIRCUIT	42703
41136	KIT,CIRC.BREAKER 32.0 BED 60HZ	NLA

Old Number	Description	New Number
41139	MANIFOLD,OIL 75KW	NLA
41197	KIT,CIRC.BREAKER 20.0 BED 50HZ	NLA
41216	STATOR BC 4.5KW FR S/N 20246	NLA
41218	STATOR ASSY INCL HSG BC4.5	NLA
41222	BREAKER,CIRCUIT	42702
41261	ENGINE	NLA
41262	KIT,FUEL LINE DBL WALL 32 BEDA	NLA
41263	BRACKET,ALTNR 90A 55B	43848
41266	PLATE,BACK 4.5-7.0 BCGB	NLA
41274	HARNESS,GENSET 15.0 BTDB INDL	NLA
41277	PANEL,BOX & HARN 15 BTDB INDL	NLA
41278	PANEL,GENSET CTL IND'L 12V	NLA
41300	ENGINE,BLOCK ASSY 32.0 BEDA	NLA
41308	ENGINE,BLOCK ASSY 63C,W52,15KW	NLA
41313	HOUSING,THERMOSTAT LOWER 63C	NLA
41352	HOSE,DIPSTICK	32875
41369	WASHER,INJECTOR	14464
41375	GASKET,OIL ADAPTER	32705
41395	ENGINE,BLOCK ASSY 71C,20BEDA	NLA
41408	BOLT,BANJO	24503
41449	LINE,INJECTION PUMP RETURN	NLA
41474	PANEL,SG FRONT/REAR 20 BED WHI	NLA
41497	ENGINE,GAS CA	NLA
41503	ENGINE,GAS CA	NLA
41506	ENGINE,GAS CA	NLA
41509	ENGINE CA	NLA
41513	ENGINE CA	NLA
41516	ENGINE CA	NLA
41532	ENGINE CA	NLA
41544	ENGINE CA	NLA
41565	PULLEY,SEA WATER PUMP	NLA
41566	PULLEY,FRESH PUMP	NLA
41567	PULLEY,CRANKSHAFT	NLA
41574	PLATE,BACK C2	NLA
41627	PISTON STD EB FROM OS09029	NLA
41649	GASKET,TIMING COVER ED	NLA
41652	BELT,TIMING ED FROM 1S56258	NLA
41666	COVER,AIR INLET SG WHITE	NLA
41709	PLENUM,INTAKE SG11-15 BTD WHITE	NLA
41711	MOUNT,FRONT LEFT 82B 18.5-22.5	NLA
41729	MOUNT,FRONT LEFT 90A 18.5-22.5	NLA
41864	FLANGE,OIL SEAL	40794
41923	GASKET,EXHAUST/INTAKE MANIF	NLA
41973	GLOWPLUG 12VDC 55A	24353
41989	STRAINER,OIL PICKUP ASSEMBLY	43481
42026	PUMP,SEA WATER	55624
42038	WASHER,BANJO	30289
42040	ELEMENT,FUEL	46146
42044	GASKET,INJECTOR	48129
42047	BELT,SEA WATER PUMP 60 BED	NLA
42065	ALTERNATOR 12VDC, 90A	30735
42067	CARBURETOR	NLA
42085	GASKET,EXHAUST MAN TO CATALYST	NLA
42117	INSULATION	CONSULT FACTORY FOR ASSY
42120	CATALYST	CONSULT FACTORY FOR ASSY
42139	THERMOSTAT	24689
42141	GASKET,OIL PICKUP	54625
42145	STUD,FUEL SOLENOID BRKT M 6	NLA

Old Number	Description	New Number
42182	ENGINE	NLA
42196	ALTERNATOR 12VDC,100A 44B	NLA
42197	ALTERNATOR 12VDC,135A 44B	NLA
42230	KIT,CIRC.BREAKER 16.0 BEG 50HZ	NLA
42233	ELBOW,EXHAUST	42662
42237	SUPPORT,SG RAIL 101.25 45-55KW	NLA
42238	SUPPORT,SG RAIL 86.55 45-55KW	NLA
42255	HOSE,EXCHANGER TO EXH ELBOW	NLA
42259	HOSE,EXCHANGER TO SEA PUMP	NLA
42266	WIRE,GEN TO BRKR	38643
42267	BREAKER,CIRCUIT	42718
42278	CONNECTOR,WATER PUMP 32BEDA	NLA
42291	GASKET,EXHAUST	48582
42300	BREAKER,CIRCUIT	42696
42331	SCREW 8-32x1/4 SS TRIMMED HEX	NLA
42343	THERMOSTAT	39378
42373	ISOLATOR	NLA
42378	COVER,CONTROL BOX 42379	43411
42379	BOX,GENSET	43415
42381	THROTTLE BODY	NLA
42384	GUARD,BELT	NLA
42386	ELBOW,LOWER EXHAUST	42662
42400	ENGINE,BLOCK ASSY 5.0 BCDB	39953
42432	BRACKET,ACTUATOR RETAINER	NLA
42521	SWITCH,TOGGLE,2 CIRC,REMOTE	48262
42615	BRACKET,TUNED HOSE 32 BEDAR	NLA
42636	PANEL,REAR INR-SHEET SG9.6BCGT	NLA
42637	PANEL,FRONT IN-SHEET SG9.6BCGT	NLA
42656	CONDENSER,DISTR 12 PACK 35680	NLA
42694	GUARD,BELT 4.5-9.6 BCGTC	NLA
42727	HOSE,FUEL 1/2ID	NLA
42733	PUMP,FUEL SUB-ASSY 4.5 BCGTE	NLA
42765	ENGINE	NLA
42776	CARBURETOR 4.5-9.6 BCGTC	52678
42789	DIPSTICK,OPTIONAL EXTND 55B	NLA
42813	BRACKET,PANEL MTG 4.5-9.6 BCGT	NLA
42814	BRACKET,PANEL MTG 4.5-7.2 BCGT	NLA
42820	CAPSCREW 3/8NCx2-3/8 GR 8	NLA
42822	GOVERNOR,MECHANICAL	R042822
42827	BOX,GENSET CTL PNL 4.5-9.6BCGT	NLA
42863	BRACKET,GASDENSER TO LIFT PUMP	NLA
42864	COIL,GASDENSER	NLA
42884	SHUTDOWN,OVERSPEED BCGTC VER1	43376
42952	COLLET,VALVE	30241
42984	SEAL,VALVE STEM	30242
43006	GASKET,INTAKE MANIF	43287
43061	PUMP,FRESH WATER	43809
43085	CONTROL,EFI 4.5-9.6 BCGT 12V	43521
43103	LATCH,DRAW ASSY-HANDLE & KEEP	NLA
43115	LINE,LIFT PUMP TO GASDENSER	44756 & 44757
43135	TOOL,PILOT	NLA
43143	BASE,SG 4.5-9.6 BCGT	43431
43151	SEAL,OIL	31056
43152	LINER,CYLINDER 63C	30988
43169	CAMSHAFT 63C	NLA
43174	HEAD,CYLINDER 63C	NLA
43182	CASE,TIMING 63C	NLA
43196	BEARING SET,MAIN STD 63C	31042

Old Number	Description	New Number
43206	GEAR,CRANKSHAFT 63C	NLA
43212	NOZZLE,INJECTOR 63C	43211
43213	GASKET SET,SUMP 63C,15.0 BTDB	31051
43216	EYE,LIFTING	NLA
43225	INSULATION,LOWER REAR PANEL SG	NLA
43262	SILENCER KIT W52 FIELD UPGRADE	NLA
43272	KIT,CIRC.BREAKER 25.0 BED 50HZ	NLA
43283	PIN,SG PANEL HOLD DOWN	NLA
43336	TRANSMISSION 2:1 HBW 40-2R	NLA
43347	HOUSING,THERMOSTAT 4-9 BCGTC	NLA
43391	CAPSCREW 5/16NCx2 GRADE 2	NLA
43404	WASHER,FENDER 5/16x1-1/2 STEEL	NLA
43418	ADAPTER,OIL FLTR ASSY 4-9BCGTE	NLA
43430	BRACKET,STOP CABLE	NLA
43483	GENERATOR 4.5KW BC 2 POLE	NLA
43497	GENERATOR 9.6KW BC 2 POLE	NLA
43498	GENERATOR 7.2KW BC 2 POLE	NLA
43592	ROTOR,DISTR 43593	43607
43594	MODULE,DISTR VACUUM ADVANCE	NLA
43624	ADAPTER,HYD GEAR TO HOUSING	NLA
43667	SUPPORT,SG RAIL 111.37 65-95KW	NLA
43695	SILENCER	44356
43788	CARBURETOR	52883
43793	GOVERNOR,MECHANICAL	R043793
43823	HOUSING,AIR INTAKE/FILTER 44A	NLA
43839	SPACER,STOP CABLE	NLA
43890	LINE,INJECTOR RETURN 36A	44500
43891	LINE,INJECTOR RETURN 44A	44496
43898	HARNESS,PANEL	43913
43915	GUARD,BELT	44365
43976	ROD,CONNECTING	37077
44084	ENGINE,BLOCK ASSY 8-10 BTDA	54200
44146	PLATE,BACK 10.0 BTD 24 VDC	NLA
44188	GUARD,BELT 4.5-7.0 BCGB	NLA
44207	BOLT,BANJO	24503
44208	SPACER,INJ PMP LINE	24504
44265	THRUHULL 3/4 NPT BRONZE	NLA
44268	SEACOCK 2 NPT	NLA
44381	HOSE,BREATHER 35.0 WID	NLA
44381	TUBE,DIPSTICK	NLA
44400	ENGINE	NLA
44478	ENGINE	NLA
44479	ENGINE	NLA
44544	PANEL,GENSET CTL	46887
44575	HARNESS,MARINE R&D	NLA
44578	PANEL,BOX & HARN	44878
44590	ELBOW,AIR INTAKE 6BG1	NLA
44595	PANEL,BOX & HARN	44877
44718	PIPE,AIR INTAKE 4BG1	NLA
44723	HOUSING & COVER,AIR INTAKE	53815 genset
44723	HOUSING & COVER,AIR INTAKE	54627 propulsion
44754	BRACKET,BREAKER	45592
44791	EXCHANGER,HEAT	48514
44899	KIT,CIRC.BREAKER 32.0 BEDA 60H	NLA
44931	CONNECTOR,HOSE 1-1/2 90 DEGREE	NLA
44932	CONNECTOR,HOSE 1-1/2 45 DEGREE	NLA
44933	CONNECTOR,HOSE 1-1/2 STRAIGHT	NLA
44944	ARMATURE C2-4.5	NLA

Old Number	Description	New Number
44945	ARMATURE C2-7.2	NLA
44946	ARMATURE C2-9.6	NLA
44949	STATOR C2-4.5	NLA
44950	STATOR C2-7.2	NLA
44951	STATOR C2-9.6	NLA
44964	PANEL,BOX-HARN 20-25BEDR 24SRC	NLA
44975	PULLEY,ALTNR 135AMP W71G	NLA
44980	PIPE,AIR INTAKE 6BG1	NLA
45081	GASKET,EXH MAN	39487
45119	DIPSTICK,OPTIONAL EXTND	NLA
45120	BRACKET,DIPSTICK 8-10 BTDA	NLA
45121	VALVE,ANTI-SIPHON & LOOP 1.25"	NLA
45126	TUBE,DIPSTICK OPTNL	NLA
45192	GASKET,BACKPLATE	NLA
45219	GASKET,SILENCER	44324
45222	GASKET,EXHAUST MANIF	43955
45226	COOLER,OIL	46295
45227	SPACER,COOLER	45677
45276	BOLT,OIL COOLER	46296
45326	GENERATOR 8.0 BEG C TO 256991	49671
45327	GENERATOR 10.0 BEG C TO 257005	49673
45328	GENERATOR 12.5 BEG C TO 256769	49675
45329	GENERATOR 15.0 BEG C TO 257077	49134
45392	CAPSCREW M 8x65 JIS-FLANGE 8T	NLA
45684	HARNESS,GENSET CTL 8.0 BCDT	NLA
45767	GASKET,IMPELLER	33032
45783	ALTERNATOR 12VDC, 35A 7A-11A	NLA
46008	ENGINE,BLOCK ASSY	NLA
46044	BELT,COG	NLA
46087	PANEL,BOX & HARN	44968
46120	PUMP,SEA WATER	42026
46214	HOUSING & COVER,AIR IN 8 BCDT	NLA
46225	GOVERNOR,MECHANICAL	R046225
46240	HARNESS,PANEL 44575 15 PIN SRC	NLA
46328	SILENCER,INTAKE 71C-82B-108C	48804
46331	BALL	NLA
46383	PANEL,INSTRUMENT	49179
46435	BRACKET,DIPSTICK TUBE	NLA
46436	TUBE,DIPSTICK 5.0 BCG	NLA
46444	CARBURETOR 8.0-15.0 BEG	NLA
46452	DRAIN,AIR SILENCER 5.0 BCG	NLA
46461	PANEL,GENSET CTL 5.0 BCG	55426
46494	WIRE,AVR VOLTAGE SENSE 8-15BEG	NLA
46511	ADAPTER,ACTUATOR TO CARBURETOR	NLA
46623	KIT,WATER PUMP 46120	55718
46676	METER,HOUR 12/24VDC VDO	NLA
46687	SUPPORT,SG RAIL 101.37 65-95KW	NLA
46723	PC BOARD ASSY,OVERSPEED	56075
46740	CARBURETOR 5.0-7.0 BCGC	NLA
46745	GENERATOR BC 7.0KW 1P	NLA
46754	METER,WATER TEMP UNGD 250F	55095
46756	SPRING	38458
46757	SLEEVE,CARBURETOR VENT TUBE	NLA
46803	DIPSTICK	48810
46892	SENDER	34911
46894	SENDER	34912
46911	RING SET STD	37667
46912	RING SET 0.25	37668

Old Number	Description	New Number
46913	RING SET 0.50	37669
46917	O-RING	46297
46918	SEAL,OIL	30209
46960	ELBOW,INJECTED	48070
46963	CARBURETOR 4.5-9.6 BCGTC	NLA
46964	CARBURETOR 4.5-7.0 BCGB	NLA
46966	ISOLATOR,PANEL	36652
46996	MANIFOLD,EXHAUST SUB-ASSY	47973
47131	PISTON STD	55714 & 55711 MUST REPL ALL
47132	PISTON 0.25	55715 & 55712 MUST REPL ALL
47133	PISTON 0.50	55716 & 55713 MUST REPL ALL
47156	CARBURETOR	47620
47248	GASKET,ROCKER COVER	45834
47395	PLUG,CAMSHAFT	NLA
47462	LEVER,FUEL SHUT-OFF	54330
47466	GEAR,CRANKSHAFT 55C	54338
47478	FLANGE,OIL SEAL REAR CRANK	54322
47564	PUMP,FRESH WATER	49950
47578	CASE,TIMING 4LE1	NLA
47592	STUD,COVER/SMP M6x16	54302
47838	SCREW M 8x20 DIN 991	42598
47871	CONTROLLER,GOVNR 24V	46945
47895	ENGINE,BLOCK ASSY 44B	54852
48068	ENGINE,BLOCK ASSY 55B FOUR	NLA
48090	SCREW,SPEED SET	30323
48092	VALVE,INTAKE	47129
48093	VALVE,EXHAUST	47128
48190	ADAPTER,BULKHEAD,1/8NPT FEM-LG	NLA
48219	ENGINE,BLOCK ASSY 35D	54701
48223	ALTERNATOR 12VDC,190A 55B	NLA
48238	ALTERNATOR 12VDC,100A	NLA
48324	GASKET	48134
48325	SEAL,OIL	48143
48351	STUD M 6x100 DIN 939 ZINC PLAT	NLA
48377	CAP,OIL FILL	30237
48436	BEARING,ROD S1 4G PAIR	55654
48437	BEARING,ROD S2 4G PAIR	55655
48438	BEARING,ROD S3 4G PAIR	55656
48563	KEY,HUB TO ARMATURE	NLA
48564	HUB,DRIVE DISC TO ARMATURE	NLA
48596	BRACKET,BELT GUARD TOP LEFT	NLA
48681	ALTERNATOR 24VDC,150A	NLA
48704	THRUSTWASHER SET 1.00 63D	43205
48741	INSERT,SILENCER MOUNT ALUM	NLA
48760	ARMATURE 7.0 BCGC	NLA
48763	STATOR ASSY INCL HSN 7.0 BCGC	NLA
48801	PC BOARD ASSY,OVERSPEED	56075
48846	FLYWHEEL ASSY 3 BPMG	47830
48854	WASHER,ROCKER SHAFT 3.0 BPMG	48886
48894	KEY,CRANKSHAFT DRIVE PULLEY	48895
48899	DOWEL	301701
48906	MANIFOLD,INTAKE	NLA
48907	MANIFOLD,INTAKE	NLA
48909	ENGINE,BLOCK ASSY 64A	NLA
48945	MOTOR,STEPPER	52034
48971	LINE,FUEL PUMP TO FILTER	NLA
48998	BRACKET,FUEL PUMP/FILTER 5SBCG	NLA
48999	LINE,FUEL PUMP TO FILTER	NLA

Old Number	Description	New Number
49014	MANIFOLD,EXHAUST KEEL	NLA
49095	BRACKET,FUEL PUMP/FILTER	NLA
49096	LINE,FUEL PUMP TO FILTER	NLA
49097	BRACKET,FUEL PUMP/FILTER	NLA
49127	LINE,FUEL PUMP TO FILTER	NLA
49134	GENERATOR 15.0 BEG C FR 257078	54826
49158	METER,OIL PRESS UNG 150PSI 12V	55093
49159	METER,OIL PRESS UNG 150PSI 24V	55094
49160	METER,WATER TEMP UNG 250F 12V	55095
49162	METER,VOLT 12VDC UNG VDO OCEAN	55097
49164	METER,HOUR 12/24VDC VDO OCEAN	55099
49176	CLAMP,EXHAUST ELBOW 4.62" MOD	48984
49203	HEAD,CYLINDER KIT E1	NLA
49233	HARNESS,GENSET 20.0-25.0 SBEG	53596
49316	HARNESS,GENSET 8.0-15.0 SBEG	53597
49318	HARNESS,GENSET 5.0-7.0 SBCG	53594
49319	HARNESS,BATTERY CHGR 5-7 SBCG	52799
49321	KIT A 3.0 SBPMG 60HZ	49324
49322	KIT B 3.0 SBPMG	54907
49323	GASKET SET,COMPL	54906
49325	KIT B 3.0 SBPMG-FW	54907
49379	CARBURETOR	52585
49419	O-RING	49435
49420	O-RING	49435
49435	SEAL KIT,PRM80/120	NLA
49517	SCREW 6-32x3/8 SS HEX SLOTHEAD	NLA
49595	GASKET,WATER JACKET PLATE	NLA
49628	PANEL,GENSET CTL	49145
49671	GENERATOR 8.0 BEG C FR 256992	54823
49673	GENERATOR 10.0 BEG C FR 257006	54824
49675	GENERATOR 12.5 BEG C FR 256770	54825
49749	KIT A 3.0 SBPMG 50HZ	49750
49790	PANEL,GENSET CTL	54789
49791	PANEL,GENSET CTL	54789
49792	PANEL,GENSET CTL	54789
49935	TRANSMISSION 2.05:1 ZF10M	NLA - CONSULT FACTORY
49976	ALTERNATOR 12VDC,150A	NLA
49990	ISOLATOR,GEN FLUIDLASTIC	NLA
49998	CABLE,ECU-PC INTERFACE	55410
50006	THERMOSTAT,DIGITAL IVORY	NLA
50007	THERMOSTAT,DIGITAL GREY	NLA
50008	THERMOSTAT,DIGITAL BROWN	NLA
50009	THERMOSTAT,DIGITAL BLACK	NLA
50011	THERMOSTAT BLACK	50010
50028	GRILL,SUPPLY 4" RD GREY	NLA
50037	GRILL,SUPPLY 4x16 TEAK	NLA
50042	GRILL,SUPPLY 6x14 TEAK	NLA
50069	TRANSITION 4x16 W/4" RING	NLA
50072	TRANSITION 5x14	NLA
50074	TRANSITION 6x14	NLA
50081	GRILL,SUPPLY 7x 7 ALUMINUM	NLA
50086	GRILL,SUPPLY 12x 6 ALUMINUM	NLA
50100	GRILL,RETURN 16x10 ALUMINUM	NLA
50148	EVAPORATOR	50535
50150	COMPRESSOR	50604
50151	COMPRESSOR	50607
50155	COMPRESSOR	50608
50156	COMPRESSOR	50609

Old Number	Description	New Number
50157	EVAPORATOR	50536
50167	VALVE,REVERSING	50568-120V 50569-220V
50168	SOLENOID,REVERSING VALVE 120V	50568
50238	CABLE,CTL BOX PIGTAIL-STD STAT	NLA
50242	CONTROL BOX,DIGITAL 110VAC	NLA
50244	MODULE,DIGITAL THERMOSTAT 110V	NLA
50246	SOLENOID,REVERSING VALVE 220V	50569
50255	GRILL,SUPPLY 18.5x 4 ALUMINUM	NLA
50266	FILTER	50387/50388
50311	BRACKET,CONDENSER UPPER 17BTU	NLA
50367	CABLE,THERMOSTAT PIGTAIL	NLA
50381	STRAINER,SEA WATER 1-1/4"	NLA
50401	MODULE,DIGITAL THERM 110V OLD	NLA
50441	CABLE,DIGITAL DISPLAY 25 FT	50440
50443	COMPRESSOR	50445
50445	COMPRESSOR	50611
50502	HARD START	50628
50508	PC BOARD ASSY,CONTROLLER 110V	50625
50542	PC BOARD ASSY,CONTROLLER 220V	50626
52012	COVER,ROCKER 55C	NLA
52021	PANEL,GENSET CTL	NLA
52022	PANEL,GENSET CTL	NLA
52024	PANEL,GENSET CTL	NLA
52030	PLATE,THROTTLE R&D	NLA
52090	PUMP,LIFT 12VDC GAS	53339
52125	WASHER,BANJO M 8	48127
52297	CLAMP,HOSE 03 MINIATURE	54768
52459	PANEL,GENSET CTL	NLA
52468	ADAPTER,TEE 5 PIN MICRO-C	53009
52478	ADAPTER 5/16 INV FL Mx1/8NPTF	NLA
52630	BEARING,ROD CL3 BROWN EB	NLA
52719	PC BOARD ASSY,AC SENSE EC20	53762
52777	PC BOARD ASSY,OVERSPEED 12VDC	52778
52791	CABLE,NMEA 3' M/F MICRO-C	NLA
52809	PANEL,GENSET CTL	52786
52860	PANEL,GENSET CTL	52786
52861	BOX,CIRCUIT BREAKER 5.0 EDC	52842
52921	BOX,CONTROL PANEL	NLA
52922	DIVIDER,PANEL BOX	NLA
52925	COVER,PANEL BOX AC SIDE	NLA
52926	COVER,PANEL BOX DC SIDE	NLA
52927	BRACKET,ECU SUPPORT	NLA
52929	BRACKET,TERMINAL BOARD	NLA
52930	BRACKET,PANEL MTG	NLA
52980	FILTER,OIL	11951
53000	PANEL,GENSET CTL	NLA
53153	PLATE,BREATHER ELEMENT LOWER	NLA
53154	PLATE,BREATHER ELEMENT UPPER	NLA
53187	THRUSTWASHER UPPER STD 33 EDE	55202
53188	THRUSTWASHER LOWER STD 33 EDE	55203
53200	BUSHING,IDLER GEAR 33.0 EDE	55210
53219	HOSE,OIL COOLER TO BLOCK 33EDE	55211
53248	LEVER ASSY,FORK 33.0 EDE	NLA
53281	ALTERNATOR 12VDC, 60A	55417
53291	BEARING SET,ROD STD BLUE	55215
53293	BEARING SET,ROD 0.2MM GREEN	55217
53294	BEARING SET,ROD 0.4MM RED	55218
53297	BEARING,MAIN 0.2MM 33.0 EDE	55220

Old Number	Description	New Number
53304	PLUG,DIPSTICK TUBE	54127
53363	PANEL,GENSET CTL	NLA
53500	KIT,DIAGNOSTIC SOFTWARE	55410
53532	LINE,OIL FILTER TO COOLER	52347
53830	CABLE,ECU-PC INTERFACE OBD1	55410
53964	MANUAL,OPERATOR 17.0 EDE	53852
54141	HOUSING,THERMOSTAT	54244
54148	SHIELD,BREATHER 22.0 EDE	NLA
54164	FILTER,FUEL 22EDE	52985
54199	ENGINE,BLOCK ASSY 5.5/7.6 BTD	55980 49 STATE 6.5KW
54523	BOX,CONTROL PNL 22-33EDE 24UNG	52827
54556	ENGINE,BLOCK ASSY 25.5-33 EDE	NLA
54669	TARGET,CAM SENSOR	NLA
54714	ENGINE,BLOCK ASSY 20C TWO	NLA
54730	CAPACITOR 40MFD	46639
54831	DIFFUSER,EXHAUST	NLA
54897	ENGINE,BLOCK ASSY 170-T6A	NLA
54911	CAPSCREW M10x1.25x80 MODIFIED	NLA
55064	BRACKET,GENERATOR	NLA
55194	CAPSCREW M10x1.25x30 JIS-FL	41429
55195	CAPSCREW M10x1.25x60 JIS-FL	41431
55344	BEARING SET,ROD S1 4G	55654
55351	CABLE,ECU-PC INTERFACE USB	55410
55419	ENGINE,BLOCK ASSY 17.0 EDE	NLA